

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [amzchef](#) /

> [AMZCHEF 30-inch Under Cabinet Range Hood BX2-H-J1EAM01 User Manual](#)

amzchef BX2-H-J1EAM01

AMZCHEF 30-inch Under Cabinet Range Hood User Manual

Model: BX2-H-J1EAM01

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before installation and use. Keep it for future reference. Failure to follow these instructions may result in electric shock, fire, or injury.

- Always disconnect power before servicing or cleaning the unit.
- Ensure proper grounding to reduce the risk of electric shock.
- Do not operate the range hood if the power cord is damaged. Contact qualified service personnel.
- Maintain adequate ventilation in the room when the range hood is used simultaneously with appliances burning gas or other fuels.
- Clean grease filters regularly to prevent grease fires.
- Do not flambé under the range hood.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. PRODUCT OVERVIEW

The AMZCHEF 30-inch Under Cabinet Range Hood is designed to effectively remove smoke, steam, grease, and cooking odors from your kitchen. It features a powerful 700 CFM motor, three-speed fan control, and energy-efficient LED lighting, all housed in a durable stainless steel body.



Image: The AMZCHEF 30-inch Under Cabinet Range Hood installed above a stove in a contemporary kitchen setting.

Included Components:

- Range Hood Unit
- Grease Filters
- LED Lights (pre-installed)
- Installation Hardware (screws, anchors, etc.)
- User Manual

3. SETUP AND INSTALLATION

This range hood supports both under-cabinet and wall-mount installations. Professional installation is recommended for optimal performance and safety.

Dimensions:

- Product Dimensions: 20.47 inches (Depth) x 30 inches (Width) x 10 inches (Height)

- Duct Size: 6 inches (Round)




Image: Technical drawing illustrating the precise dimensions of the range hood, including width, depth, height, and duct opening size.

Installation Steps (General):

1. **Preparation:** Ensure the mounting surface is strong enough to support the hood's weight. Mark the drilling points according to the provided template.
2. **Ducting:** Install the appropriate ductwork. Ensure the ducting is sealed properly to prevent air leaks.
3. **Mounting:** Secure the range hood to the cabinet or wall using the provided hardware. Ensure it is level and firmly attached.
4. **Electrical Connection:** Connect the range hood to a grounded electrical outlet. Consult a qualified electrician if unsure.
5. **Filter Installation:** Insert the grease filters into their designated slots.



AMZCHEF 30 INCH STAINLESS STEEL RANGE HOOD



Image: The range hood in operation, demonstrating its 30-inch wide suction range effectively capturing cooking fumes.

4. OPERATING INSTRUCTIONS

The AMZCHEF range hood features intuitive push-button controls for fan speed and lighting.



Push Button Control

It's as easy as the push of a button to control the speed and light.

Bright LED Lights

Energy efficient, provide bright and high lumen lighting for better visibility at night.



Easy-Care Stainless Steel Body

Brushed stainless steel metal design, easy to clean and long service time!

Image: Detailed view of the control panel with push buttons for fan speeds and light, along with the integrated LED lights and the brushed stainless steel finish.

Fan Operation:

The range hood offers three fan speeds to suit various cooking needs:

- **Speed 1 (Low):** Ideal for simmering or light cooking.
- **Speed 2 (Medium):** Suitable for general cooking and moderate smoke/steam.
- **Speed 3 (High):** Use for heavy frying, grilling, or when significant smoke and odors are present.

Press the corresponding fan speed button to select your desired setting. Press the '0' button to turn the fan off.

3-Speed Fan and Powerful Suction

*Flexible to control the fan for different cooking.

*Suction power up to 700 CFM. Realize highly efficient smoke collection and grease filtering.



Image: Visual representation of the three-speed fan settings and their effectiveness for stewing, frying, and stir-frying, highlighting the 700 CFM suction power.

LED Lighting:

Press the light bulb button to turn the LED lights on or off. The energy-efficient LED lights provide bright illumination for your cooking area.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your AMZCHEF range hood.

Grease Filter Cleaning:

The stainless steel mesh grease filters are designed to capture cooking grease and are easily removable for cleaning. They are dishwasher safe.

- **Removal:** Gently pull the latch on each filter to release it from the hood.
- **Cleaning:** Wash the filters in a dishwasher or by hand using hot water and a mild detergent. Ensure they are

completely dry before reinstallation.

- **Reinstallation:** Align the filters with their slots and push them firmly until they click into place.



Easily removable

Dishwasher safe

Double layer structure

Stainless Steel Grease Filter

Image: A detailed view of the stainless steel mesh grease filter, emphasizing its easy removal mechanism and dishwasher-safe feature, along with its double-layer structure.

Exterior Cleaning:

Clean the stainless steel exterior with a soft cloth and a non-abrasive stainless steel cleaner. Avoid using harsh chemicals or abrasive pads that could scratch the surface.

6. TROUBLESHOOTING

If you encounter issues with your range hood, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fan does not turn on	No power supply Faulty switch	Check power connection and circuit breaker. Contact customer support for switch replacement.
Poor suction	Clogged grease filters Improper ducting Motor issue	Clean or replace grease filters. Check ductwork for obstructions or leaks. Contact customer support.
Excessive noise	Loose parts Motor imbalance Ducting issues	Check for and tighten any loose components. Contact customer support. Inspect ductwork for proper installation and sealing.
Lights not working	Burnt out LED Loose connection	Replace LED light. Check electrical connections.

If the problem persists after trying these solutions, please contact AMZCHEF customer support.



Image: A woman enjoying a quiet moment in her kitchen, illustrating the low noise operation of the AMZCHEF range hood.

7. SPECIFICATIONS

Feature	Specification
Brand	amzchef
Model Number	BX2-H-J1EAM01
Air Flow Capacity	700 Cubic Feet Per Minute (CFM)
Material	Alloy Steel, Stainless Steel
Noise Level	62 Decibels
Mounting Type	Under Cabinet Mount, Wall Mount
Controls Type	Push Button
Number of Speeds	3
Light Source Type	LED
Filter Type	Mesh (Stainless Steel)
Item Weight	40 pounds
Product Dimensions	20.47 x 10 x 30 inches (D x H x W)
Special Features	Energy-saving, Stainless Steel, Low Noise, Durable, LED Lights, Lighting

8. WARRANTY AND SUPPORT

AMZCHEF products are manufactured to high-quality standards. For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official AMZCHEF website.

If you require assistance with installation, operation, or troubleshooting that is not covered in this manual, please contact AMZCHEF customer service for expert guidance.