

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ALPHA BIDET](#) /
- › [ALPHA BIDET GXR Wave Bidet Toilet Seat User Manual](#)

## ALPHA BIDET GXR-EW

# ALPHA BIDET GXR Wave Bidet Toilet Seat User Manual

Model: GXR-EW

## INTRODUCTION

---

The ALPHA BIDET GXR Wave Bidet Toilet Seat is designed to provide advanced personal hygiene with a focus on performance and luxury. This manual provides comprehensive instructions for installation, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your bidet seat.

## SAFETY INFORMATION

---

Please read all safety warnings and precautions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other injuries.

- Ensure the power outlet is 110 Volts and is a Ground Fault Circuit Interrupter (GFCI) outlet.
- Do not immerse the unit in water or spray water directly onto the electrical components.
- Unplug the bidet seat from the power outlet before cleaning or performing any maintenance.
- Keep the remote control dry and away from water.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Supervise children to ensure they do not play with the appliance.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- ALPHA BIDET GXR Wave Bidet Toilet Seat (Elongated)
- Wireless Remote Control
- Mounting Hardware Kit
- User Manual (this document)



Image: The ALPHA BIDET GXR Wave bidet toilet seat in white, shown with its wireless remote control. The seat is elongated and features a sleek, low-profile design.

## SETUP AND INSTALLATION

---

Follow these steps for proper installation of your GXR Wave bidet seat. It is recommended to have basic plumbing knowledge or consult a professional if unsure.

### 1. Preparation:

- Turn off the water supply to your toilet at the shut-off valve.
- Flush the toilet to drain the tank.
- Remove your existing toilet seat and lid.

### 2. Install Mounting Plate:

Attach the provided mounting plate to the toilet bowl using the included bolts and nuts. Ensure it is centered and secure.

### 3. Connect Water Supply:

- Disconnect the existing water supply hose from the toilet tank.
- Install the T-valve (included in mounting hardware) between the toilet fill valve and the water supply hose.
- Connect the bidet seat's water supply hose to the T-valve. Ensure all connections are tight to prevent leaks.



Image: Side profile of the GXR Wave bidet seat, illustrating the water connection point at the rear left. The low-profile design is also visible.

### 4. Attach Bidet Seat:

Slide the bidet seat onto the mounting plate until it clicks securely into place. Ensure it is firmly seated.



Image: The GXR Wave bidet seat installed on a toilet, viewed from the side. A subtle blue LED nightlight glows from beneath the seat, indicating its low-profile design.

### 5. Connect Power:

Plug the bidet seat's power cord into a 110V GFCI electrical outlet.

### 6. Restore Water Supply:

Slowly turn on the water supply to the toilet. Check for any leaks at all connection points. Tighten if necessary.

## OPERATING INSTRUCTIONS

---

Your GXR Wave bidet seat features a wireless remote control for easy operation of its various functions.



Image: Close-up of the wireless remote control for the ALPHA BIDET GXR Wave. It features clearly labeled buttons for various functions such as Stop, Rear, Rear+, Front, Dry, Spray Pressure, Dry Temp, Seat Temp, Water Temp, Nozzle Position, Pulse/LED, Child Mode, Nozzle Clean, and Power Save.

## Remote Control Functions:

- **STOP:** Stops all current operations.
- **REAR / OSCILLATE:** Initiates a standard rear wash. Press again for oscillating spray.
- **REAR+:** Provides a stronger, more concentrated rear wash (approx. 1L/min).
- **FRONT / OSCILLATE:** Initiates a feminine wash. Press again for oscillating spray.
- **DRY:** Activates the warm air dryer.
- **SPRAY PRESSURE (+/-):** Adjusts water spray intensity.
- **DRY TEMP (+/-):** Adjusts warm air dryer temperature.
- **SEAT TEMP (+/-):** Adjusts heated seat temperature.
- **WATER TEMP (+/-):** Adjusts water temperature for washing.
- **NOZZLE POSITION (Up/Down Arrows):** Adjusts the nozzle's forward/backward position.
- **PULSE / LED:** Activates pulsating spray. Hold to toggle LED nightlight.
- **CHILD MODE:** Activates a gentle wash cycle suitable for children.
- **NOZZLE CLEAN:** Initiates an automatic self-cleaning cycle for the stainless steel nozzle.
- **POWER SAVE (eco):** Activates energy-saving mode.

## Key Features:

- **Tankless Heating System:** Provides instant and continuous warm water.
- **Stainless Steel Nozzle:** Durable and hygienic, with self-cleaning function.
- **LED Nightlight:** Soft white illumination for nighttime use.
- **Sittable Lid:** Designed for durability and comfort.

## MAINTENANCE

---

Regular maintenance ensures the longevity and hygienic operation of your bidet seat.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth and mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive pads.
- **Nozzle Cleaning:** Use the "NOZZLE CLEAN" function on the remote for automatic cleaning. For manual cleaning, gently pull out the nozzle and wipe with a soft brush or cloth.
- **Filter Cleaning:** Periodically check and clean the water inlet filter to prevent blockages and maintain spray pressure. Refer to the detailed diagram in the full manual for filter location.
- **Long-Term Storage:** If not using for an extended period, drain the water from the unit and unplug it. Store in a dry, temperate environment.

## TROUBLESHOOTING

---

If you encounter issues with your GXR Wave bidet seat, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No water spray	Water supply valve closed, clogged filter, power issue.	Open water supply valve. Clean the water inlet filter. Check power connection.
Weak spray pressure	Low water pressure, clogged nozzle/filter.	Ensure adequate household water pressure. Clean nozzle and water inlet filter.
Heated seat not working	Power save mode active, temperature setting too low.	Deactivate power save mode. Increase seat temperature setting on remote.
Nightlight not working	Nightlight feature is off.	Press and hold the PULSE/LED button on the remote to toggle the nightlight.
Water leaking	Loose connections, damaged hose/seal.	Check and tighten all water connections. If leak persists, contact customer support.

For issues not listed here, or if solutions do not resolve the problem, please contact ALPHA BIDET customer support.

## SPECIFICATIONS

---

Feature	Detail
Model	GXR-EW
Brand	ALPHA BIDET
Color	White
Shape	Elongated
Material	Stainless Steel (Nozzle)
Product Dimensions	20.8"L x 15"W
Item Weight	12.52 pounds
Operation Mode	Automatic
Voltage	110 Volts
Included Components	Mounting Hardware, Remote control
UPC	683203945790

## WARRANTY AND SUPPORT

---

Your ALPHA BIDET GXR Wave Bidet Toilet Seat comes with a **1 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact ALPHA BIDET customer service. Keep your proof of purchase for warranty validation.

Visit the official ALPHA BIDET store for more information and product registration: [ALPHA BIDET Store](#)

© 2024 ALPHA BIDET. All rights reserved.