



Manuals.plus /

› TOMPROAD /

› TOMPROAD S39 Portable Bluetooth Speaker User Manual

## TOMPROAD S39

# TOMPROAD S39 Portable Bluetooth Speaker User Manual

Model: S39 | Brand: TOMPROAD

## 1. INTRODUCTION

---

This user manual provides detailed instructions for the operation and maintenance of your TOMPROAD S39 Portable Bluetooth Speaker. Designed for versatile audio playback, this speaker features powerful stereo sound with rich bass, LED lights, and multiple connectivity options, making it suitable for various indoor and outdoor environments.



Image: The TOMPROAD S39 Portable Bluetooth Speaker shown with its included remote control, highlighting its compact design and front-facing speaker grille with LED light capabilities.

## 2. WHAT'S IN THE BOX

---

Please check the package contents to ensure all items are present:

- 1 x Bluetooth speaker (TOMPROAD S39)
- 1 x Remote control
- 1 x AUX cable

- 1 x USB cable (for charging)
- 1 x User manual
- 1 x Retail box



Image: A visual representation of the TOMPROAD S39 speaker, its retail box, user manual, remote control, AUX cable, and USB charging cable, as typically found in the product packaging.

### 3. PRODUCT FEATURES

- **Powerful Audio Output:** Equipped with an 11W power output, including one powerful bass speaker and two tweeters, along with a rear heavy bass guide tube for rich stereo and amazing bass sound.
- **Bluetooth 5.0 Connectivity:** Ensures quick and stable wireless transmission up to 33 feet (10 meters) for seamless pairing with Bluetooth-enabled devices.
- **Multi-function Playback:** Supports FM radio, TF Card music playback, AUX input, and U-disk music playback.
- **Intelligent Remote Control:** Allows remote operation of various speaker functions, including mode selection, volume, track control, and FM radio tuning.

- **Dynamic LED Lights:** Features flashing RGB colorful lights that synchronize with music, enhancing the party atmosphere. Lights can be turned on/off via a dedicated button.
- **Portable Design:** Includes a convenient hand-held pull ring for easy transport.
- **Integrated Phone/Tablet Stand:** A stand holder on top supports mobile phones and tablets for convenient viewing while listening.
- **Rechargeable Battery:** Built-in battery provides several hours of music playback on a full charge.



Image: An illustrative diagram highlighting the multi-functional capabilities of the S39 speaker, including Bluetooth 5.0, remote control, microphone support, FM radio, USB, and TF card compatibility.



Image: A split image demonstrating the portability of the S39 speaker with its top handle and its functionality as a mobile phone stand, showing a phone resting in the integrated holder.

## 4. SETUP

---

### 4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator will illuminate. A full charge typically takes approximately 3 hours and provides up to 5.5 hours of battery life, depending on usage volume and LED light activation.

### 4.2 Power On/Off

To power on the speaker, locate the power switch (usually on the back or side panel) and slide it to the "ON" position. To power off, slide the switch to the "OFF" position.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Mode Selection

Press the **MODE** button on the speaker or remote control to cycle through available modes: Bluetooth, FM Radio, TF Card, U-disk, and AUX Input.

## 5.2 Bluetooth Pairing

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED light and an audible prompt.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "S39" from the list of found devices.
4. Once paired, the blue LED light will become solid, and you will hear a confirmation sound.
5. You can now play audio from your device through the speaker.

## 5.3 FM Radio Operation

In FM mode, the speaker can automatically search and save available stations.

- **Automatic Scan:** Long press the **Play/Pause** button (or the corresponding button on the remote) to initiate an automatic scan for FM stations. The speaker will save all found stations.
- **Manual Tuning:** Use the **Previous/Next Track** buttons on the speaker or remote to navigate through saved stations.
- **Direct Frequency Input (Remote Control):** On the remote control, you can directly input a radio station frequency using the number pad.



FM

# SUPPORT FM RADIO



Image: The TOMPROAD S39 speaker in an outdoor setting, emphasizing its FM radio capability, allowing users to enjoy radio broadcasts.

## 5.4 TF Card / U-disk Playback

Insert a TF (Micro SD) card or a USB flash drive into the corresponding slot on the speaker. The speaker will automatically switch to the correct mode and begin playing audio files from the storage device. Use the [Previous/Next Track](#) and [Play/Pause](#) buttons to control playback.

## 5.5 AUX Input

Connect an external audio device (e.g., MP3 player, PC, laptop) to the speaker's AUX input port using the supplied 3.5mm AUX cable. The speaker will automatically switch to AUX mode. Control playback from your connected device.

## 5.6 LED Lights Control

The speaker features colorful LED lights. To turn the lights on or off, press the [LED ON/OFF](#) button located on the front panel of the speaker or on the remote control.

## 5.7 Remote Control Usage

The included remote control provides convenient access to all speaker functions from a distance. Ensure the remote

control has working batteries and is pointed towards the speaker's front panel for optimal performance.

# Remote control



Image: A hand holding the remote control for the TOMPROAD S39 speaker, with the speaker itself shown alongside its dimensions (7.6 inches height, 4.7 inches width, 6.8 inches depth), illustrating the ease of remote operation.

## 6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Resistance:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

## 7. TROUBLESHOOTING

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
No power	Battery is low or depleted.	Charge the speaker using the supplied USB cable.
No sound	Volume is too low; incorrect mode selected; device not paired (Bluetooth); cable not connected (AUX).	Increase volume; press MODE button to select correct input; ensure Bluetooth device is paired; check AUX cable connection.
Bluetooth pairing failed	Speaker is too far from device; speaker is already paired to another device; Bluetooth not enabled on device.	Move speaker closer to device (within 10m); disconnect from other devices; enable Bluetooth on your device.
Poor FM reception	Weak signal; interference.	Relocate the speaker to an area with better signal; extend the antenna if available (or use USB cable as antenna if supported).
Remote control not working	Batteries are dead or incorrectly inserted; remote not pointed at speaker.	Replace remote control batteries; ensure correct polarity; point remote directly at the speaker's front panel.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	TOMPROAD
Model Name	S39
Speaker Type	Subwoofer
Connectivity Technology	Bluetooth, FM, AUX, USB, TF Card
Wireless Communication Technology	Bluetooth, FM
Bluetooth Range	10 Meters (33 feet)
Speaker Maximum Output Power	11 Watts
Audio Output Mode	Stereo
Subwoofer Diameter	3 Inches
Product Dimensions (L x W x H)	6.8"D x 4.7"W x 7.6"H
Item Weight	1230 Grams (2.71 pounds)
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Battery Capacity	2000 Milliamp Hours
Battery Life	5.5 Hours (approx.)
Charging Time	3 Hours (approx.)
Material	Plastic, Wood
Color	Black
Controller Type	Battery Powered, Remote
Compatible Devices	Laptop, MP3 Player, Personal Computer, Phones, Tablet

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the contact details provided on the product packaging or the official TOMPROAD website. Keep your purchase receipt as proof of purchase for any warranty claims.

