

[Manuals.plus](#) /

› [Rapoo](#) /

› Rapoo M100G Multi-Mode Wireless Mouse User Manual

Rapoo M100G

Rapoo M100G Multi-Mode Wireless Mouse User Manual

Model: M100G | Brand: Rapoo

INTRODUCTION

The Rapoo M100G Multi-Mode Wireless Mouse is designed for versatile use, offering seamless connectivity across multiple devices. It supports Bluetooth 3.0, Bluetooth 4.0, and 2.4GHz wireless connections, allowing you to connect to up to three devices simultaneously and switch between them with ease. Its silent click design ensures a quiet working environment, while the ergonomic shape provides comfort for extended use. This manual provides detailed instructions for setting up, operating, and maintaining your Rapoo M100G mouse.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Rapoo M100G mouse.



Figure 1: Rapoo M100G Multi-Mode Wireless Mouse (Black) and its USB receiver.

Personalized productivityand

Unlock the full range of possibilities. Use RAP00 Options Software to easily setup and assign basic , media , mouse feature, windows, sensitivity, advanced features.



Figure 2: Top and bottom views of the mouse, illustrating key features and customizable points.

- **Left/Right Click Buttons:** Designed for silent operation, reducing click noise by 90%.
- **Scroll Wheel:** For smooth vertical scrolling.
- **DPI Switch Button:** Located near the scroll wheel, allows adjustment of cursor sensitivity.
- **Bluetooth Pairing Button:** Located on the underside of the mouse, used for initiating Bluetooth pairing.
- **Power ON/OFF Switch:** Located on the underside, to conserve battery life.
- **USB Receiver Compartment:** Located on the underside, for storing the 2.4G USB receiver.
- **Battery Compartment:** Located on the underside, for the AA battery.

SETUP


1. Battery Installation

The Rapoo M100G mouse requires one AA battery (included). To install:

1. Open the battery compartment cover on the underside of the mouse.
2. Insert one AA battery, ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.
4. Turn the power switch to the "ON" position.

2.4G USB Connecting mode

Plug the USB receiver and turn on the mouse.



Bluetooth Connecting mode

Press the bluetooth button for more than 3 seconds, red LED flashes slowly, the mouse in searching situation for 2 minutes



The Same way to connect your bluetooth device B

Shortly press the bluetooth button to switch a channel



Figure 3: Underside of the mouse showing the battery compartment, USB receiver storage, and connection buttons.

2. Connecting Your Mouse

The Rapoo M100G offers three connection modes: 2.4GHz wireless via USB receiver, Bluetooth 3.0, and Bluetooth 4.0. You can connect to up to three devices and switch between them.

2.1. 2.4GHz Wireless Connection (USB Receiver)

1. Locate the USB receiver stored inside the mouse's battery compartment.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the mouse using the ON/OFF switch on the underside.
4. The mouse should automatically connect to your computer.



Figure 4: The Rapoo M100G supports both 2.4GHz wireless and Bluetooth connections.

2.2. Bluetooth Connection (BT3.0 / BT4.0)

The mouse supports two Bluetooth channels (Bluetooth 3.0 and Bluetooth 4.0) for connecting to two separate devices.

1. Turn on the mouse using the ON/OFF switch.
2. Press and hold the Bluetooth pairing button on the underside of the mouse for more than 3 seconds. The red LED will flash slowly, indicating the mouse is in searching (pairing) mode for 2 minutes.
3. On your device (PC, tablet, laptop, cellphone), go to Bluetooth settings and search for new devices.
4. Select "RAPOO BleMouse" (for Bluetooth 4.0) or "RAPOO BT3.0 Mouse" (for Bluetooth 3.0) from the list of available devices to pair.
5. Once connected, the LED will stop flashing.
6. Repeat the process for a second Bluetooth device using the other Bluetooth channel.

WIDE COMPATIBILITY




Figure 5: Wide compatibility with various operating systems and devices.

2.3. Switching Between Connected Devices

To switch between the 2.4GHz wireless connection and the two Bluetooth connections:

- Simply short press the Bluetooth button on the underside of the mouse. Each short press will cycle through the connected devices (2.4G, Bluetooth 1, Bluetooth 2).

Your browser does not support the video tag.

Video 1: Demonstrates how to switch between up to 3 devices with the Rapoo M100G mouse.

OPERATING INSTRUCTIONS

Silent Click Design

The Rapoo M100G features a 90% noise reduction for its click buttons, providing a quiet user experience ideal for shared workspaces or late-night use.




Figure 6: The silent click feature of the Rapoo M100G mouse.

High Precision Optical Engine

The mouse is equipped with a high-precision optical engine, allowing it to be used on various surfaces without the need for a mouse pad, including leather, cloth, paper, wood, or resin.

HIGH PERFORMANCE ENGINE CAN BE USED ON VARIOUS SURFACE



Figure 7: The high-performance optical engine allows use on diverse surfaces.

MAINTENANCE

Battery Life and Replacement

The Rapoo M100G mouse is designed for extended battery life, offering up to 9 months of use under normal conditions thanks to its low-power technology and power-saving design. When the mouse's performance degrades or the indicator light suggests low power, replace the AA battery following the installation steps in the Setup section.

Cleaning

To maintain your mouse's performance and appearance:

- Use a soft, dry cloth to wipe the exterior of the mouse.
- For stubborn dirt, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive cleaners.
- Ensure no liquid enters the mouse's internal components.

TROUBLESHOOTING

If you encounter issues with your Rapoo M100G mouse, please refer to the following common solutions:

Problem	Possible Cause / Solution
Mouse not responding (2.4GHz)	Ensure the USB receiver is securely plugged into a working USB port. Check if the mouse is turned ON. Try plugging the receiver into a different USB port. Replace the battery if it's low.
Mouse not connecting via Bluetooth	Ensure Bluetooth is enabled on your device. Press and hold the Bluetooth pairing button on the mouse for 3+ seconds until the LED flashes slowly. Remove previous pairings of the mouse from your device's Bluetooth settings and try pairing again. Ensure the mouse is within the effective Bluetooth range (typically 10 meters). Check battery level.
Cursor movement is erratic or slow	Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface (avoid highly reflective or transparent surfaces). Replace the battery.
Cannot switch between devices	Ensure all devices are properly paired/connected to their respective channels (2.4G, BT1, BT2). Short press the Bluetooth button on the underside to cycle through channels.

SPECIFICATIONS

Feature	Detail
Model	M100G
Connectivity Technology	Bluetooth 3.0, Bluetooth 4.0, 2.4GHz Wireless (USB)
Movement Detection Technology	Optical
Special Features	Wireless, Portable, Lightweight, Ergonomic Design, Soundless (Silent Click)
Product Dimensions	3.92 x 2.41 x 1.4 inches
Item Weight	1.98 ounces
Batteries	1 AA battery (included)
Manufacturer	Shenzhen Rapoo Technology Co., Ltd
Country of Origin	China
Date First Available	January 5, 2021



Figure 8: Physical dimensions of the Rapoo M100G mouse.

WARRANTY AND SUPPORT

Rapoo provides comprehensive support for its products:

- **One-Year Warranty:** All Rapoo products come with a one-year warranty from the date of purchase.
- **30-Day Return Policy:** Enjoy hassle-free 30-day returns for refund or replacement.
- **Customer Support:** For any inquiries or assistance, please visit the official Rapoo website or contact their customer service.

© 2024 Rapoo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question