

Vosswitch JL301

Vosswitch JL300 / JL800 / JL120 Button Stickers User Manual

INTRODUCTION

This manual provides instructions for the proper application and care of your Vosswitch JL300, JL800, and JL120 Button Stickers. These stickers are designed to customize and label the buttons on your Vosswitch switch panels, enhancing functionality and organization. Please read these instructions carefully before proceeding with installation.

PRODUCT FEATURES

- **Compatibility:** Specifically designed to fit Vosswitch JL300, JL800, and JL120 switch panels.
- **Material:** Constructed from durable Polyethylene (PE) for longevity.
- **Water Resistance:** Features a waterproof design suitable for outdoor use.
- **Reusability:** Designed to be reusable, allowing for repositioning or transfer if needed.
- **Finish:** Powder-coated finish for enhanced durability.

SETUP AND INSTALLATION

Proper preparation of the surface is crucial for optimal adhesion and appearance of the stickers.

1. **Clean the Surface:** Ensure the button surface on your Vosswitch panel is clean, dry, and free of dust, grease, or any residues. Use a mild cleaner if necessary, and allow it to dry completely.
2. **Identify Sticker Placement:** Carefully select the appropriate sticker for each button function.
3. **Peel and Apply:** Gently peel the desired sticker from its backing sheet. Align the sticker precisely over the button, then apply it slowly from one edge to the other to minimize air bubbles.
4. **Smooth Out:** Once applied, gently press down on the sticker, working from the center outwards, to ensure full adhesion and to remove any trapped air bubbles.



Image: A sheet of Voswitch button stickers, displaying various icons and labels for different vehicle accessories and functions. This image illustrates the variety and design of the stickers included in the product.

OPERATING INSTRUCTIONS

The Voswitch button stickers serve as visual indicators for the functions assigned to each button on your JL300, JL800, or JL120 switch panel. Once applied, they provide clear and immediate identification of each switch's purpose, improving user experience and operational efficiency. No specific operational steps are required for the stickers themselves beyond their initial application.

MAINTENANCE

To maintain the appearance and longevity of your Voswitch button stickers:

- **Cleaning:** Wipe the stickers gently with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these may damage the sticker's surface or adhesive.

- **Reusability:** Due to their reusable nature, stickers can be carefully peeled off and reapplied if repositioning is needed. Ensure the adhesive side remains clean to maintain stickiness.
- **Storage:** If removing stickers for storage, place them back on their original backing sheet or a clean, non-adhesive surface to protect the adhesive.

TROUBLESHOOTING

- **Sticker Not Sticking:** Ensure the surface was thoroughly cleaned and dry before application. If the adhesive is compromised, the sticker may need replacement.
- **Air Bubbles:** If air bubbles appear after application, gently press them towards the edge of the sticker with your finger or a soft cloth to push the air out.
- **Misaligned Sticker:** If the sticker is misaligned, carefully peel it off and reapply, ensuring the adhesive side remains clean.
- **Damaged Sticker:** If a sticker becomes damaged or loses its adhesive properties, replacement stickers may be available from Voswitch.

SPECIFICATIONS

Specification	Detail
Brand	Voswitch
Model Number	JL301
ASIN	B08S2TD7HZ
GTIN / UPC	717373633741
Material	Polyethylene (PE)
Color	Beige
Special Feature	Waterproof, Reusable
Indoor/Outdoor Usage	Outdoor
Item Weight	0.317 ounces
Package Dimensions	6.3 x 4.09 x 0.59 inches

WARRANTY AND SUPPORT

For any questions regarding your Voswitch button stickers, including product information, installation assistance, or replacement parts, please contact Voswitch customer support. Specific warranty details for this accessory may vary; refer to your purchase documentation or the official Voswitch website for the most current information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question