

[Manuals.plus](#) /

› [Little Live Pets](#) /

› Little Live Pets 26371 Lil Hamster and House Playset S1 User Manual

Little Live Pets 26371

Little Live Pets Lil Hamster and House Playset S1 - Model 26371 User Manual

Brand: Little Live Pets | Model: 26371

INTRODUCTION

Welcome to the world of Little Live Pets Lil Hamsters! This playset features an interactive Lil Hamster that moves and makes sounds just like a real hamster. This manual provides essential information for setting up, operating, and maintaining your Lil Hamster and House Playset to ensure a fun and engaging experience.

SAFETY INFORMATION

- **Age Recommendation:** This product is suitable for children aged 36 months (3 years) and up.
- **Battery Safety:** Always follow battery installation and replacement instructions carefully. Do not mix old and new batteries, or different types of batteries. Remove batteries if the toy will not be used for an extended period.
- **Choking Hazard:** Contains small parts. Not suitable for children under 3 years due to potential choking hazards.
- **Supervision:** Adult supervision is recommended during play.

PACKAGE CONTENTS

Your Little Live Pets Lil Hamster and House Playset includes the following items:

- 1 x Lil Hamster (Popmello)
- 1 x Hamster House
- 1 x Hamster Wheel
- 3 x LR44 Batteries (pre-installed or included)



Image: The Little Live Pets Lil Hamster and House Playset, showing the hamster, house, and wheel.

SETUP INSTRUCTIONS

1. Battery Installation

Your Lil Hamster requires 3 x LR44 batteries. These are typically included and may be pre-installed. If replacement is needed:

1. Locate the battery compartment on the underside of the Lil Hamster.
2. Using a small screwdriver, open the battery compartment cover.
3. Insert 3 new LR44 batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

2. Playset Assembly

The Little Live Pets Lil Hamster and House Playset does not require complex assembly. The Hamster House and Hamster

Wheel are designed for easy placement and interaction with your Lil Hamster.



Image: A child's hands gently holding the Lil Hamster, ready for play.

OPERATING INSTRUCTIONS

1. Activating Your Lil Hamster

To begin playing with your Lil Hamster:

- Locate the ON/OFF switch on the underside of the hamster and slide it to the "ON" position.
- Your Lil Hamster is now ready to interact.

2. Interacting with Your Lil Hamster

The Lil Hamster is designed to be interactive:

- **Petting:** Gently hold and pet your Lil Hamster. It will react to your touch by making sounds.

- **Exploration:** Place your Lil Hamster on a flat surface or inside its Hamster House. Watch as it scurries around and explores its environment.
- **Hamster Wheel:** Place the Lil Hamster inside its Hamster Wheel. It will run and move within the wheel, simulating real hamster behavior.

MAINTENANCE

1. Cleaning

- To clean your Lil Hamster and playset, gently wipe with a damp cloth.
- Do not immerse the electronic parts in water.
- Avoid using harsh chemicals or abrasive cleaners.

2. Battery Care

- Always replace all batteries at the same time.
- Remove batteries if the toy is not used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lil Hamster does not move or make sounds.	• ON/OFF switch is in "OFF" position. • Batteries are depleted or incorrectly installed.	• Ensure the ON/OFF switch is set to "ON". • Replace batteries with new LR44 batteries, ensuring correct polarity.
Movement is sluggish or sounds are faint.	Batteries are low.	Replace all batteries with new LR44 batteries.
Hamster gets stuck in the house or wheel.	Obstruction or improper placement.	Ensure the play area is clear and the hamster is placed correctly within the house or wheel.

PRODUCT SPECIFICATIONS

Brand	Little Live Pets
Model Number	26371
Animal Theme	Hamster
Character	Lil' Hamster (Popmello)
Material	Plastic (Outer material: Cotton/Flocked texture)
Color	Multi-colored
Batteries Required	Yes, 3 x LR44 batteries (included)
Recommended Age	36 months to 144 months (3 to 12 years)

Special Features	Sound, Interactive Sound
Item Dimensions (L x W x H)	21.4 x 14.8 x 17.5 cm
GTIN/UPC	630996263716

WARRANTY INFORMATION

This product comes with a **2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance, or need to make a warranty claim, please contact the manufacturer or your retailer.

For further information, please refer to the official Little Live Pets website or contact their customer service department.

© 2026 Little Live Pets. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08S34HD7P>

More documents and user manuals: <https://manuals.plus/>