

Swann SWIFI-CAMWPK5-GL

Swann Wire-Free 1080p Security Camera 5 Pack User Manual

Model: SWIFI-CAMWPK5-GL

1. PRODUCT OVERVIEW

The Swann Wire-Free 1080p Security Camera 5 Pack (Model: SWIFI-CAMWPK5-GL) provides comprehensive surveillance for both indoor and outdoor environments. These cameras are designed for ease of use with their wire-free operation and rechargeable batteries, offering flexible placement options.

Key features include:

- **Full 1080p HD Quality:** Captures clear, detailed video footage.
- **Ultra-Wide 180-Degree+ View:** Provides extensive coverage, minimizing blind spots.
- **True Detect Heat & Motion Sensing:** Accurately detects moving warm objects like people and cars, reducing false alarms.
- **Infrared Night Vision:** Offers clear visibility up to 26ft (8m) in low light conditions.
- **Two-Way Talk:** Allows for communication with visitors or deterrence of intruders via the built-in speaker and microphone.
- **Siren Functionality:** Enables activation of an audible siren to deter unwanted activity.
- **Weatherproof Design:** Built to withstand various weather conditions, suitable for year-round outdoor use.
- **Smart Surveillance Integration:** Compatible with Alexa-enabled devices (Echo Show, Echo Spot, 4K Fire TV) and Google Assistant (Chromecast, Google Home Hub).
- **Swann Security App Control:** Manage and monitor cameras, view live video, and receive push notifications directly from your smartphone.



Image 1.1: The Swann Wire-Free 1080p Security Camera 5 Pack, showcasing the five individual cameras.

2. WHAT'S INCLUDED

Your Swann Wire-Free 1080p Security Camera 5 Pack includes the following components:

- 5 x Swann Wire-Free 1080p Full HD Indoor & Outdoor Waterproof Rechargeable Security Cameras
- Mounting Screws and Plugs
- USB Charging Cables
- Security Stickers
- Mounting Bases/Stands



Image 2.1: All components included in the Swann Wire-Free 1080p Security Camera 5 Pack, including cameras, mounting hardware, and cables.

3. SETUP GUIDE

Follow these steps to set up your Swann Wire-Free Security Cameras:

3.1 Charging the Cameras

Before initial use, fully charge each camera. Locate the charging port on the back of the camera, typically protected by a rubber flap. Use the provided USB charging cables to connect the cameras to a USB power adapter (not included) or a computer USB port. The charging indicator light will show the charging status.





Image 3.1: Rear view of a Swann Wire-Free camera, highlighting the reset button and the USB charging port with its protective cover.

3.2 Downloading the Swann Security App

The Swann Security app is essential for controlling and monitoring your cameras. Download it from the Apple App Store (for iOS devices) or Google Play Store (for Android devices).

- Search for "Swann Security" in your device's app store.
- Install the app and create an account or log in if you already have one.

3.3 Pairing Cameras with the App

Once the cameras are charged and the app is installed:

1. Open the Swann Security app and follow the on-screen prompts to add a new device.
2. Power on each camera. The camera will enter pairing mode, indicated by a specific LED light pattern.
3. Scan the QR code on the camera or manually enter its device ID when prompted by the app.
4. Follow the app's instructions to connect the camera to your Wi-Fi network. Ensure your Wi-Fi signal is strong at the camera's intended location.

3.4 Mounting the Cameras

The cameras are designed for wall mounting and can be used both indoors and outdoors. Choose a location that provides the desired viewing angle and has a stable Wi-Fi connection.

1. Attach the mounting base to the desired surface using the provided screws and wall plugs.
2. Securely attach the camera to the mounting base.
3. Adjust the camera angle to cover the desired area.



Image 3.2: A single Swann Wire-Free camera securely mounted on a wall, demonstrating its compact design.

4. OPERATING INSTRUCTIONS

Operate your Swann Wire-Free Security Cameras primarily through the Swann Security app.

4.1 Live View

Open the Swann Security app and select the desired camera from your device list to view its live feed. This allows real-time monitoring of your property.

4.2 Motion Detection and Recording

The cameras utilize True Detect Heat & Motion Sensing to identify significant activity. When motion is detected, the camera will automatically begin recording and send push notifications to your smartphone. You can customize motion detection sensitivity and recording schedules within the app settings.

4.3 Two-Way Talk

While viewing the live feed, use the microphone icon in the app to activate two-way talk. This allows you to speak through the camera's speaker and hear audio from the camera's microphone.

4.4 Night Vision

The cameras automatically switch to infrared night vision in low-light conditions, providing clear black and white video up to 26 feet (8 meters). No manual activation is required.

4.5 Siren Activation

In the event of suspicious activity, you can manually activate the camera's siren through the Swann Security app to deter intruders.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your security cameras.

5.1 Battery Charging

Monitor the battery level of your cameras via the Swann Security app. Recharge cameras promptly when the battery is low to ensure continuous surveillance. Battery life can vary based on activity and settings.

5.2 Cleaning the Camera Lens

Periodically clean the camera lens with a soft, lint-free cloth to remove dust, dirt, or smudges that may affect image clarity. Do not use harsh chemicals or abrasive materials.

5.3 Firmware Updates

Ensure your camera's firmware is up to date. The Swann Security app will typically notify you of available updates. Follow the in-app instructions to perform firmware updates, which can improve performance, add new features, and enhance security.

6. TROUBLESHOOTING

If you encounter issues with your Swann Wire-Free Security Cameras, refer to the following common troubleshooting steps:

6.1 Camera Offline or Disconnecting

- **Check Wi-Fi Connection:** Ensure your Wi-Fi router is functioning correctly and the camera is within range of a strong Wi-Fi signal. Obstructions like thick walls can weaken the signal.
- **Recharge Battery:** A low battery can cause disconnections. Fully charge the camera.
- **Restart Camera:** Power off the camera, wait a few seconds, and then power it back on.
- **Restart Router:** Power cycle your Wi-Fi router.
- **Re-pair Camera:** If the issue persists, try removing the camera from the app and re-pairing it as per the setup instructions.

6.2 Poor Video Quality (Grainy/Unclear)

- **Clean Lens:** Ensure the camera lens is clean and free of dirt, dust, or smudges.
- **Check Wi-Fi Signal:** A weak Wi-Fi signal can lead to degraded video quality. Try moving the camera closer to the router or using a Wi-Fi extender.
- **Lighting Conditions:** Ensure adequate lighting during the day. At night, confirm night vision is active and

there are no strong light sources directly facing the camera that could cause glare.

6.3 Short Battery Life

- **Reduce Motion Events:** Frequent motion detections and recordings consume more battery. Adjust motion sensitivity settings in the app to reduce unnecessary recordings.
- **Optimize Placement:** Avoid placing the camera in high-traffic areas if continuous recording is not desired.
- **Temperature:** Extreme temperatures (very cold or very hot) can affect battery performance.
- **Charging Cycle:** Ensure the camera is fully charged each time.

6.4 Audio Issues (Dim/Unclear)

- **Check App Volume:** Ensure the volume on your smartphone and within the Swann Security app is turned up.
- **Microphone/Speaker Obstruction:** Ensure nothing is blocking the camera's microphone or speaker.
- **Network Latency:** Poor network connection can affect audio quality.

7. SPECIFICATIONS

Feature	Detail
Model Name	SWIFI-CAMWPK5-GL
Indoor/Outdoor Usage	Indoor, Outdoor
Video Capture Resolution	1080p Full HD
Connectivity Technology	Wireless (Wi-Fi)
Power Source	Battery Powered (Rechargeable)
Night Vision Range	Up to 26 Feet (8 meters)
Motion Detection	True Detect Heat & Motion Sensing
Two-Way Audio	Yes
Siren	Yes
Compatible Devices	Smartphone (iOS, Android), Alexa-enabled devices, Google Assistant devices
Controller Type	App (Swann Security App)
Mounting Type	Wall Mount
Color	White
International Protection Rating	IP65 (Weatherproof)
Product Dimensions	8.27 x 7.87 x 8.27 inches
Item Weight	4.31 pounds (total for pack)
UPC	840236128853

8. WARRANTY AND SUPPORT

8.1 Warranty Information

For detailed warranty information regarding your Swann Wire-Free 1080p Security Camera 5 Pack, please refer to the official Swann website or the warranty card included with your product. Warranty terms and conditions may vary by region.

8.2 Customer Support

If you require further assistance, technical support, or have questions not covered in this manual, please visit the official Swann support website or contact their customer service. You can find more information and resources on the [Swann Store on Amazon](#) or their dedicated support portal.