

tectake tuinmeubelset van wicker

tectake Garden Furniture Set Instruction Manual

Model: tuinmeubelset van wicker

[Introduction](#) [Safety Instructions](#) [Package Contents](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the tectake Garden Furniture Set. This set is designed to provide a comfortable and stylish outdoor seating and dining solution for up to 10 people. Featuring a durable wicker design with an aluminum frame, it includes 6 chairs, 1 table, and 4 stools, along with a protective cover and water-repellent cushions. This manual provides detailed instructions for assembly, safe use, and maintenance to ensure the longevity and enjoyment of your furniture set.

2. SAFETY INSTRUCTIONS

- **Read all instructions carefully:** Before assembly and use, ensure you understand all instructions and warnings.
- **Adult assembly required:** Assembly should be performed by competent adults. Keep children away during assembly.
- **Check all fasteners:** Ensure all screws and bolts are securely tightened before use. Periodically check and re-tighten as necessary.
- **Weight limits:** Do not exceed the specified weight limits for chairs (150 kg) and stools (150 kg).
- **Stable surface:** Always place the furniture set on a flat, stable, and level surface to prevent tipping.
- **Weather protection:** While the set is weather-resistant, use the provided protective cover during harsh weather conditions (heavy rain, strong winds, snow) or prolonged periods of non-use to extend its lifespan.
- **Glass table top:** Handle the glass table tops with care. Avoid placing extremely hot items directly on the glass without protection. Do not sit or stand on the table.
- **Moving furniture:** When moving the furniture, lift it rather than dragging to prevent damage to the frame and flooring.
- **Flammable materials:** Keep the furniture away from open flames, heaters, and other heat sources.

3. PACKAGE CONTENTS

Please verify that all components listed below are present in your package. If any parts are missing or damaged, please contact customer support.

- 6 x Chairs with seat and back cushions
- 1 x Table with 3 glass plates
- 4 x Stools with cushions
- 1 x Protective cover
- Assembly materials (screws, bolts, tools if included)
- Assembly instructions (this manual)



Image 3.1: Complete tectake Garden Furniture Set components.

4. SETUP AND ASSEMBLY

The tectake Garden Furniture Set requires assembly. Please follow these steps carefully. It is recommended to assemble the furniture on a soft, clean surface to prevent scratches.

4.1 Unpacking

1. Carefully remove all components from the packaging.
2. Check the package contents against the list in Section 3.
3. Keep all packaging materials until assembly is complete, in case any parts were overlooked.

4.2 Chair Assembly

Assemble each chair by attaching the backrest and armrests to the seat frame using the provided screws and tools. Ensure all connections are firm but do not overtighten until all parts are aligned.

tectake

garden

Productinformatie

AFMETINGEN	TECHNISCHE DETAILS	INHOUD
<p>Totale afmetingen stoel 54 x 58 x 82 cm</p> <p>Totale afmetingen hocker 45 x 45 x 33 cm</p> <p>Totale afmetingen tafel 178 x 114 x 72 cm</p> <p>Afmetingen zijn bij benadering</p>	<p>Draagkracht stoel 150 kg Draagkracht hocker 150 kg Draagkracht tafel 75 kg Gewicht stoel ca. 6 kg Gewicht hocker ca. 2 kg Gewicht tafel ca. 36 kg Materiaal polyethyleen, aluminium, 100% polyester, polyurethaan, glas</p>	<p>6 fauteuils met zit- en rugkussens Tafel met 3 glasplaten Hoetenzet in de kleur beige Hoetenzet in de kleur grijs 4 hockers Beschermhoes Montagemateriaal Montagehandleiding</p>

Image 4.1: Chair and stool dimensions for assembly reference.

4.3 Stool Assembly

Assemble the stools by connecting the side panels to the top and bottom frames. Secure with screws. The stools are designed to be compact and fit under the table.

4.4 Table Assembly

Assemble the table frame. Once the frame is stable, carefully place the three glass plates into the designated slots on the table top. Ensure the glass plates are seated securely.



Deze **ruime zitgroep** biedt een individuele uitstraling dankzij de 2 verwisselbare hoezensets.



De **verwijderbare veiligheidsglasplaten** met elegante uitstraling scoren met hun hoge slag- en stootvastheid.



Dankzij de **opklapbare rugleuningen** kunnen de stoelen volledig onder de tafel geschoven worden.



Met de **duurzame beschermhoes** kan de set effectief worden beschermd tegen weersinvloeden.

Image 4.2: Table with glass tops and protective cover.

4.5 Final Checks

1. Once all components are assembled, gently shake each piece to ensure stability.
2. Re-tighten all screws and bolts if necessary, but avoid overtightening which can strip threads.
3. Place the cushions on the chairs and stools.

5. OPERATING INSTRUCTIONS

This garden furniture set is designed for versatile outdoor use, offering both dining and lounging options.

5.1 Seating Arrangement

Arrange the 6 chairs and 4 stools around the table as desired. The set is designed to comfortably accommodate up to 10 people for dining or social gatherings.

5.2 Compact Storage Feature

One of the key features of this set is its space-saving design. The chairs and stools can be neatly tucked under the table

when not in use. To do this, the backrests of the chairs can be folded down, allowing them to slide completely under the table, with the stools fitting into the remaining spaces.



tectake
garden

Geniet van warme avonden en gezellige barbecues op deze luxe wicker zitgroep, waarvan de hoge rugleuningen, comfortabele armleuningen en dikke kussens voor eersteklas comfort zorgen. Superhandig: na gebruik worden stoelen en hockers onder de eettafel opgeborgen.

Image 5.1: Compact storage configuration.

5.3 Using the Protective Cover

When the furniture set is not in use, especially during adverse weather conditions or for extended periods, cover it with the provided protective cover. This will shield the furniture from rain, dust, UV rays, and other environmental elements, significantly extending its lifespan.

ABSOLUUT WIND- & Weerbestendig




Image 5.2: Weather resistance and protection.

6. MAINTENANCE

Proper care and maintenance will ensure your tectake Garden Furniture Set remains in excellent condition for years to come.

6.1 Cleaning the Wicker and Frame

- Wipe down the wicker and aluminum frame with a soft cloth dampened with mild soap and water.
- Rinse thoroughly with clean water to remove any soap residue.
- Avoid using harsh chemicals, abrasive cleaners, or stiff brushes, as these can damage the material.
- Allow to air dry completely before covering or storing.

6.2 Cushion Care

- The cushions are water-repellent. For light spills, wipe immediately with a clean, dry cloth.
- For deeper cleaning, remove the cushion covers (if removable) and hand wash with mild soap and cold water, or follow specific care instructions on the label.

- Allow covers to air dry completely before reattaching to the cushions. Do not machine wash or tumble dry unless specified.
- Store cushions indoors during prolonged periods of rain or when not in use to prevent mildew and fading.



Image 6.1: Water-repellent cushion feature.

6.3 Glass Table Top Care

- Clean glass surfaces with a standard glass cleaner and a soft, lint-free cloth.
- Avoid abrasive materials that could scratch the glass.

6.4 Seasonal Storage

During winter months or extended periods of non-use, it is recommended to store the furniture set in a dry, sheltered area. If outdoor storage is necessary, ensure the protective cover is securely fastened.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your garden furniture set.

7.1 Instability/Wobbling

- **Cause:** Uneven surface or loose fasteners.
- **Solution:** Ensure the furniture is placed on a flat, level surface. Check and tighten all assembly screws and bolts.

7.2 Wicker Damage

- **Cause:** Sharp objects, excessive force, or prolonged exposure to extreme weather without cover.
- **Solution:** Minor fraying can sometimes be carefully trimmed. For significant damage, contact customer support for advice. Always use the protective cover.

7.3 Cushion Stains/Mildew

- **Cause:** Spills not cleaned promptly, or prolonged dampness.
- **Solution:** Clean spills immediately. For mildew, use a solution of mild soap and water, scrub gently, rinse thoroughly, and allow to air dry completely in the sun. Store cushions indoors when not in use.

8. SPECIFICATIONS

Feature	Detail
Model Number	tuinmeubelset van wicker
Overall Product Dimensions (L x W x H)	178 x 114 x 72 cm
Item Weight	65 Kilograms
Chair Dimensions (L x W x H)	54 x 58 x 82 cm
Stool Dimensions (L x W x H)	45 x 45 x 33 cm
Chair Load Capacity	150 kg
Stool Load Capacity	150 kg
Table Load Capacity	75 kg
Material Type	Metal, Fabric, Glass, Polyethylene (Wicker)
Color	Black
Assembly Required	Yes

9. WARRANTY & SUPPORT

9.1 Warranty Information

tectake products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. The warranty period typically covers 30 days for returns/replacements from the date of purchase. Please retain your proof of purchase for any warranty claims.

The warranty does not cover damage caused by improper assembly, misuse, neglect, accidents, alterations, or normal wear and tear. Using the product for purposes other than its intended use may void the warranty.

9.2 Customer Support

If you have any questions regarding the assembly, operation, maintenance, or warranty of your tectake Garden Furniture Set, please do not hesitate to contact our customer support team. For the quickest assistance, please have your model number (tuinmeubelset van wicker) and proof of purchase ready.

Online Support: Visit the tectake official website for FAQs and contact options.

Email: Refer to your purchase documentation for specific contact email.

Phone: Refer to your purchase documentation for specific contact phone number.