Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- tectake /
- User Manual for tectake 800866 Padded Velvet Effect Chairs

tectake 800866

User Manual for tectake 800866 Padded Velvet Effect Chairs

Model: 800866

INTRODUCTION

This manual provides essential information for the assembly, proper use, maintenance, and troubleshooting of your new tectake 800866 Padded Velvet Effect Chairs. Please read this manual carefully before assembly and use to ensure safe and optimal performance of your chairs. These chairs are designed for versatile use in various indoor settings such as kitchens, dining rooms, or offices, offering both comfort and a stylish aesthetic.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. The package should contain:

- 4 x Chair Seats (Padded Velvet Effect)
- 4 x Sets of Chair Legs (Steel, Black Finish)
- Necessary Assembly Hardware (screws, washers, Allen key)



Image: A complete set of four tectake 800866 chairs, as received in the package.

SETUP AND ASSEMBLY

Assembly of the tectake 800866 chairs is straightforward and requires minimal tools. It is recommended to assemble the chairs on a soft, clean surface to prevent scratching the floor or the chair components.

- 1. **Unpack Components:** Carefully remove all chair components and hardware from the packaging. Lay them out to ensure all parts are accounted for.
- 2. **Attach Legs to Seat:** Align the leg frame with the pre-drilled holes on the underside of the chair seat. Insert the provided screws and washers.
- 3. Hand-Tighten Screws: Initially, hand-tighten all screws to allow for minor adjustments. Do not fully tighten yet.
- 4. **Adjust and Fully Tighten:** Once all screws are in place, gently place the chair upright on a flat surface. Apply slight pressure to ensure the chair is level, then fully tighten all screws using the provided Allen key. Ensure all connections are secure.

5. **Check Stability:** Before use, gently rock the chair to ensure it is stable and does not wobble. If wobbling occurs, loosen the screws slightly, adjust, and re-tighten.



Image: A diagram illustrating the key dimensions of the tectake 800866 chair, useful for understanding its structure during assembly.

OPERATING INSTRUCTIONS

The tectake 800866 chairs are designed for comfortable seating in various indoor environments. To ensure longevity and safety, please adhere to the following guidelines:

• Intended Use: These chairs are intended for indoor use only. Avoid prolonged exposure to direct sunlight or

extreme temperatures, which can damage the velvet fabric and frame.

- Weight Capacity: The maximum load capacity for each chair is 120 kg (approximately 264 lbs). Do not exceed this weight limit to prevent damage or injury.
- Proper Seating: Always sit centrally on the chair. Avoid standing on the chair or using it as a step stool.
- Floor Protection: The chairs are equipped with plastic caps on the feet to protect your flooring. Ensure these caps are intact and clean to prevent scratches.



Image: tectake 800866 chairs in a dining room setting, illustrating their intended use.

MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and extend the lifespan of your tectake 800866 chairs.

- Fabric Care (Velvet Effect):
 - For general cleaning, gently vacuum the fabric using an upholstery attachment to remove dust and loose debris.

- For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain and damage the velvet pile.
- For stubborn stains, a mild fabric cleaner designed for velvet or upholstery can be used. Test on an inconspicuous area first. Follow the cleaner's instructions carefully.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture.

• Frame Care (Steel Legs):

- Wipe the steel legs with a soft, damp cloth. Dry immediately to prevent water spots.
- Avoid abrasive cleaners or scouring pads that can scratch the finish.
- Plastic Caps: Periodically check the plastic caps on the feet for wear or damage. Replace if necessary to continue protecting your floors.
- Hardware Check: Every few months, check all screws and connections to ensure they remain tight. Re-tighten if loose.



TROUBLESHOOTING

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Chair wobbles after assembly.	Screws not tightened evenly or fully. Uneven floor surface.	Loosen all leg screws slightly, place the chair on a flat surface, apply gentle downward pressure, then re-tighten all screws firmly and evenly. Ensure the floor is level.
Scratches on floor.	Damaged or missing plastic caps on chair feet. Debris stuck to caps.	Inspect plastic caps. Clean any debris. Replace damaged or missing caps.
Fabric appears matted or discolored.	Accumulated dust/dirt. Improper cleaning. Prolonged direct sunlight exposure.	Gently vacuum the fabric. Follow recommended cleaning instructions. Avoid direct sunlight.
Squeaking noise during use.	Loose connections in the frame.	Check and re-tighten all assembly screws.

SPECIFICATIONS

Feature	Detail
Brand	tectake
Model Name	tectake 800866
Color	Brown-black
Product Dimensions (W x D x H)	Approx. 58 cm x 62 cm x 82 cm (22.83"W x 24.41"D x 32.28"H)
Seat Area (W x D)	Approx. 40 cm x 42 cm (15.75"W x 16.54"D)
Seat Height	Approx. 47 cm (18.5 inches)
Backrest Height	Approx. 40 cm (15.75 inches)
Height of Armrests from Ground	Approx. 63 - 66 cm (24.8 - 26 inches)
Distance Between Armrests	Approx. 47 cm (18.5 inches)
Maximum Load Capacity	120 kg (264 lbs)
Item Weight (per chair)	Approx. 5.9 kg (13 lbs)
Material (Coating)	100% Polyester (Velvet Effect)
Material (Padding)	Polyurethane
Material (Feet)	Steel

Feature	Detail
Included Components	4 Chairs
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your tectake 800866 Padded Velvet Effect Chairs, please contact tectake customer service. While specific warranty details are not provided in this manual, tectake stands behind the quality of its products.

For further assistance, please visit the official tectake store or contact their customer support channels. You can often find support information on the brand's official website or through the retailer where the product was purchased.

Online Store: Visit the tectake Store on Amazon

© 2025 tectake. All rights reserved.

Related Documents - 800866



TecTake Cabinet Assembly Instructions - Models 402483, 402938

Comprehensive assembly guide for TecTake cabinets (models 402483, 402938), featuring a detailed parts list and step-by-step instructions with textual descriptions of diagrams.



Tectake Non-Stick Cookware Set Instruction Manual

This manual provides comprehensive instructions for the Tectake non-stick cookware set (Model N250609004-V1), including parts identification, safety guidelines, usage instructions, and cleaning procedures.




TecTake 400926/400927 Lift Desk Assembly Instructions

Step-by-step assembly guide for the TecTake 400926 and 400927 lift desk, including a detailed parts list and safety warnings.



TecTake Safe Instruction Manual - Operation, Installation, and Disposal

Comprehensive guide for TecTake safes, detailing parts, how to open, set user and master codes, installation steps, proper disposal procedures, and important information regarding default password reset.



TecTake Rattan Garden Furniture Assembly Instructions

Comprehensive assembly instructions for TecTake rattan garden furniture sets, including a detailed parts list and step-by-step visual guidance. Model numbers: 403696, 403697, 403880, 403881.



tectake GmbH Chair Assembly and Care Instructions

Comprehensive guide for assembling and caring for the tectake GmbH chair, including parts list, step-by-step instructions, and multilingual support.