

[Manuals.plus](#) /

› [Ped Egg](#) /

› Ped Egg Pedi Vac Instruction Manual

Ped Egg Pedi Vac (Model 14375)

Ped Egg Pedi Vac Instruction Manual

Model: Pedi Vac (Model 14375)

Brand: Ped Egg

1. INTRODUCTION AND OVERVIEW

The Ped Egg Pedi Vac is an electric callus remover designed to provide professional foot care results in the comfort of your home. It features a powerful motor with 2000 RPMs and a built-in vacuum for mess-free exfoliation, effectively removing dead skin and hard calluses to reveal smooth, soft feet.



Image: The Ped Egg Pedi Vac device shown with its retail packaging.

2. SAFETY INFORMATION

Please read and understand all safety precautions before using the Ped Egg Pedi Vac.

- Keep away from water. This device is not waterproof.
- Use with care on sensitive skin. Discontinue use if irritation occurs.
- Do not use for extended periods of time on a single area to prevent excessive exfoliation or skin damage.
- Keep out of reach of children.

3. SETUP

Before first use, or when the battery is low, charge your Pedi Vac device. The device is rechargeable, eliminating the need for disposable batteries.

1. Clean the device thoroughly before its initial use.
2. Connect the charging cable to the Pedi Vac. The charging port is located at the top of the device.
3. Charge the device for approximately 40 minutes. A full charge provides up to an hour of powerful use.

Cordless & Rechargeable!



Image: The Pedi Vac device connected to a charging cable, highlighting its rechargeable feature.

4. OPERATING INSTRUCTIONS

Follow these steps for effective and mess-free callus removal:

1. Ensure the device is fully charged.
2. To turn on the device, press and hold the power button for a few seconds. The device features two speed settings; press the button again to switch between speeds.
3. Gently move the device over the callused area on your feet. The nano-abrasion heads will rotate at high speed to effortlessly remove dead skin and hard calluses.
4. The built-in vacuum will automatically suck up the shavings as you use the device, ensuring a mess-free experience.

5. The Pedi Vac is suitable for all areas on your feet, including the heel, toe, side, and ball.
6. A built-in LED light illuminates the area you are working on for improved visibility.
7. Turn off the device by pressing and holding the power button when finished.

Gently Removes *Calluses & Dry Skin* in SECONDS!

Vacuum
Action Sucks Up
the Mess!



Image: Before and after results showing smooth feet after using the Pedi Vac.

Nano-Abrasion Head Spins at 2000 RPMs!

Two Speed
Settings!



Image: Detail of the nano-abrasion head and its two speed settings.

Built-In LED Light So You Can See!




Image: The Pedi Vac showing its built-in LED light for enhanced visibility.

**Perfect
for All
Areas
on Your
Feet!**



Image: A diagram illustrating the various foot areas where the Pedi Vac can be used.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Pedi Vac.

1. After each use, turn off the device.
2. The built-in vacuum collects shavings in an internal compartment. To clean, gently open the device (as shown in the image below) and dispose of the collected dead skin in the trash.
3. Wipe the exterior of the device with a clean, dry cloth. Do not submerge the device in water.
4. Store the device in a dry place, away from direct sunlight and moisture.

Easily Dispose Shavings in the Trash!



Image: Demonstrating how to easily dispose of collected shavings from the Pedi Vac.

Mess-Free — Built-In Vacuum Sucks Up the Shavings!

New Look,
Same Great
Results!



Image: The Pedi Vac in action, showing how the built-in vacuum collects shavings for a mess-free experience.

6. TROUBLESHOOTING

If you encounter issues with your Ped Egg Pedi Vac, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Device not turning on or spinning.	Ensure the device is fully charged. If the light comes on but it doesn't spin, check for any obstructions in the abrasion head. If the device has been dropped, internal components may be damaged, which could prevent proper operation.
Weak vacuum or messy operation.	The collection compartment may be full. Empty it regularly during use, especially if you have a large amount of dead skin to remove.

Problem	Possible Cause / Solution
Device not charging.	Ensure the charging cable is properly connected to the port. The charging port may be at an angle, requiring careful connection to ensure full contact.

7. SPECIFICATIONS

Feature	Detail
Item Form	Roller
Number of Items	1
Model Name	Pedi Vac
Style	Modern
Unit Count	1.00 Count
Manufacturer	Ped Egg
UPC	097298051821
Item Package Dimensions (L x W x H)	9.09 x 6.18 x 3.11 inches
Package Weight	0.3 Kilograms
Part Number	14375
Size	1 Count (Pack of 1)
Material	Plastic
Color	White
Item Weight	0.3 Kilograms
Is Electric	Yes

8. WARRANTY AND SUPPORT

Ped Egg stands behind the quality of its products. The Pedi Vac comes with a standard manufacturer's warranty.

Your satisfaction is our top priority. If you are not completely satisfied with your Pedi Vac, please contact Ped Egg customer support for assistance and a quick solution. Refer to the product packaging or the official Ped Egg website for specific contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question