

Hermitlux HMX-DW03

Hermitlux HMX-DW03 Mini Countertop Dishwasher User Manual

Model: HMX-DW03

1. PRODUCT OVERVIEW

The Hermitlux HMX-DW03 is a compact countertop dishwasher designed for small living spaces, RVs, or as a secondary dishwashing solution. It offers efficient cleaning for up to 4 place settings and features flexible water supply options, including a built-in water tank or direct tap connection.



Image 1.1: Front view of the Hermitlux HMX-DW03 Mini Countertop Dishwasher with dishes loaded.

Key Features:

- **4 Place Setting Capacity:** Accommodates dishes up to 25 cm in diameter.
- **5 Wash Programs:** Standard, Quick, ECO, Powerful, and Fruit Wash.
- **High-Temperature Sterilization:** Up to 75°C for thorough cleaning and hygiene.
- **360-Degree Cleaning:** Dual spray arms ensure comprehensive washing.
- **Flexible Water Supply:** Integrated 5-liter water tank for manual filling or direct connection to a tap.
- **Drying Function:** PTC hot air drying to keep dishes dry and odor-free.
- **Compact Design:** Dimensions of 42.5 x 42.8 x 45.8 cm, suitable for limited kitchen spaces.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before operating the dishwasher to prevent injury or damage to the appliance.

- Ensure the dishwasher is placed on a stable, level surface.

- Do not operate the dishwasher if the power cord is damaged.
- Keep children and pets away from the dishwasher during operation.
- Use only detergents specifically designed for automatic dishwashers.
- Do not open the door during a wash cycle, especially during high-temperature phases.
- Always unplug the appliance before cleaning or performing maintenance.
- Avoid touching the heating element immediately after a cycle.
- Ensure proper ventilation around the appliance.

3. PRODUCT COMPONENTS

The following items are included with your Hermitlux HMX-DW03 Mini Countertop Dishwasher:



Image 3.1: All included components for the Hermitlux HMX-DW03 dishwasher.

- Hermitlux 220V Countertop Dishwasher
- Storage Rack
- Cutlery Basket
- Dish Basket
- Inlet Hose

- Drain Hose
- Fruit Basket
- Cup
- Hose Clamp
- User Manual
- Funnel

4. SETUP AND INSTALLATION

4.1 Placement and Dimensions

Place the dishwasher on a flat, stable surface. Ensure there is at least 50.5 cm of vertical clearance between your countertop and any overhead cabinets for proper operation and water filling.




Image 4.1: Dimensions of the Hermitlux HMX-DW03 dishwasher (42.5 cm depth, 42.8 cm width, 45.8 cm height, 50.5 cm total height with funnel).

4.2 Water Supply Options

The dishwasher supports two methods for water supply:

1. Built-in 5-Liter Water Tank (Manual Fill):

This mode requires no permanent plumbing installation. Simply pour water into the designated opening using the provided funnel until the tank is full. The dishwasher will emit a beep and display a red signal when the water level is sufficient.



Image 4.2: Diagram illustrating the manual water filling process into the 5-liter internal tank.

RAPPEL AUTOMATIQUE
Quand l'eau est pleine



RÉSERVOIR D'EAU 5L
Permet d'ajouter de l'eau manuellement

Image 4.3: Using the funnel to add water to the dishwasher, ensuring no spills.

2. Direct Tap Connection:

For a continuous water supply, connect the inlet hose to a compatible tap. Ensure the connection is secure to prevent leaks. The inlet hose length is 1.2 meters.



Image 4.4: Connecting the dishwasher's inlet hose to a standard G3/4" tap connection.

4.3 Drain Hose Connection

Connect the drain hose to an appropriate drainage point, such as a sink or a bucket. Ensure the hose is securely positioned to prevent accidental dislodgement during operation.

5. OPERATING INSTRUCTIONS

5.1 Control Panel

The dishwasher features an LED display and touch controls for easy program selection and monitoring.

5.2 Loading Dishes

Arrange dishes in the baskets, ensuring that water spray can reach all surfaces. Avoid overcrowding. The dishwasher can accommodate up to 4 place settings, including plates up to 25 cm in diameter, cups, and cutlery.



Image 5.1: Example of dish loading, showing capacity for plates, cups, and cutlery.

5.3 Adding Detergent

Use only liquid or powder dishwasher detergent. Standard dishwasher tablets may be too large for this compact model, and liquid/powder allows for more precise dosing. There is no separate compartment for rinse aid or salt.

5.4 Wash Programs

Select the appropriate program based on the soil level of your dishes:



Lavage standard
69 minutes et 68°C



Lavage rapide
29 minutes et 62°C



Eco-lavage
59 minutes et 68°C



Lavage fort
89 minutes et 75°C



lavage de fruits
19 minutes & eau froide



mode sec
Élimine l'humidité et
les odeurs pendant
73 heures

PROGRAMMES 5+1

Répondre à vos différents
besoins de lavage



Image 5.2: Overview of the 5 wash programs and drying mode.

- **Standard Wash:** 69 minutes at 68°C. For daily dishwashing.
- **Quick Wash:** 29 minutes at 62°C. For lightly soiled dishes.
- **ECO Wash:** 59 minutes at 68°C. Energy-saving program.
- **Powerful Wash:** 89 minutes at 75°C. For heavily soiled items and baby products.
- **Fruit Wash:** 19 minutes with cold water. For cleaning fruits and vegetables (no detergent needed).

5.5 Drying Mode

The dishwasher includes a drying function that uses PTC hot air to eliminate humidity and odors for up to 73 hours. You can activate this mode after any wash cycle (except Fruit Wash) or separately. To stop the storage function, press and hold the power button for 3-5 seconds.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your dishwasher.

6.1 Cleaning the Filter

The filter should be cleaned regularly to prevent blockages and ensure effective washing. After cleaning,

ensure the filter is securely tightened clockwise. Improperly fixed filters can allow debris to enter and cause malfunctions.



Image 6.1: Instructions for cleaning and re-securing the dishwasher filter.

6.2 Descaling

If you live in an area with hard water, descaling the dishwasher every two weeks is recommended to prevent limescale buildup. Refer to the full user manual for detailed descaling procedures.

6.3 Cleaning Spray Arms

Periodically check the spray arms for any blockages in the nozzles and clean them as needed to maintain 360-degree cleaning efficiency.



Image 6.2: Illustration of the 360-degree cleaning action from the dual spray arms.

7. TROUBLESHOOTING

If you encounter issues with your dishwasher, refer to the following common troubleshooting tips. For specific error codes (e.g., E6), consult the comprehensive user manual.

- **Dishwasher not starting:** Ensure the power cord is securely plugged in and the door is fully closed.

Check if the water tank is filled or the tap connection is active.

- **Dishes not clean:** Check if the filter is clean and properly installed. Ensure spray arms are not blocked and can rotate freely. Verify that enough detergent was used and the correct wash program was selected.
- **Water leakage:** Check all hose connections for tightness. Ensure the door seal is clean and intact.
- **Unusual noise:** Ensure dishes are loaded correctly and not obstructing the spray arms. Check for any foreign objects in the filter area.

8. SPECIFICATIONS

Detailed technical specifications for the Hermitlux HMX-DW03 Mini Countertop Dishwasher:

Parameter	Value
Model Number	HMX-DW03
Dimensions (L x W x H)	42.5 x 42.8 x 45.8 cm
Weight	13 Kilograms
Capacity	4 Place Settings
Water Tank Capacity	5 Liters
Water Consumption (per cycle)	5 Liters
Annual Water Consumption	500 Liters
Annual Energy Consumption	175 kWh/year
Voltage	220 Volts (AC)
Wattage	950 Watts
Noise Level	60 dB
Drying Efficiency Class	A
Number of Wash Cycles	5
Inlet Hose Length	1.2 Meters
Special Features	Touch Screen

Fiche d'information sur le produit

RÈGLEMENT DÉLÉGUÉ (UE) 2019/2017 DE LA COMMISSION en ce qui concerne l'étiquetage énergétique des lave-vaisselle ménagers

Nom du fournisseur ou marque commerciale: hermitlux

Adresse du fournisseur: Like Sun GmbH, planckstr.5916-6, 45147 Essen, DE

Référence du modèle: HMX-DW03

Paramètres généraux du produit:

Paramètre	Valeur	Paramètre	Valeur
Capacité nominale ^{a)} (ps)	2	Dimensions en cm	Hauteur 42
			Largeur 42
			Profondeur 45
IEE ^{a)}	61,0	Classe d'efficacité énergétique ^{a)}	F
Indice de performance de lavage ^{a)}	1,000	Indice de performance de séchage ^{a)}	1,000
Consommation d'énergie en kWh [par cycle], sur la base du programme eco avec alimentation en eau froide. La consommation réelle d'énergie dépend des conditions d'utilisation de l'appareil.	1,000	Consommation d'eau en litres [par cycle], sur la base du programme eco. La consommation d'eau réelle dépend des conditions d'utilisation de l'appareil et de la dureté de l'eau.	4,5
Durée du programme ^{a)} (h:min)	2:02	Type	À pose libre
Émissions de bruit acoustique dans l'air ^{a)} Hrup (dB(A) re 1 pW)	60	Classe d'émission de bruit acoustique dans l'air ^{a)}	D
Mode arrêt (W) (le cas échéant)	1,00	Mode veille (W) (le cas échéant)	1,00
Démarrage différé (W) (le cas échéant)	0,00	Mode veille avec maintien de la connexion au réseau (W) (le cas échéant)	0,00

Durée minimale de la garantie offerte par le fournisseur: 12 mois

Informations supplémentaires:

Lien internet vers le site web du fournisseur où se trouvent les informations visées à l'annexe II, point 6, du règlement (UE) 2019/2022 de la Commission https://www.amazon.de/sp?_encoding=UTF8&asin=&isAmazonFulfilled=&isCBA=&marketplaceID=A1PA6795UKMFR9&orderID=&protocol=current&seller=A2WKSQSV7IQ00K&sshPath=

^{a)} pour le programme eco.

Image 8.1: Official product information sheet with detailed specifications.







9. WARRANTY AND SUPPORT


Your Hermitlux HMX-DW03 Mini Countertop Dishwasher comes with a **12-month manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For technical assistance, warranty claims, or any questions regarding your product, please contact Hermitlux customer support. Refer to the contact information provided in the physical user manual or on the official Hermitlux website.

All dishwashers undergo rigorous testing before shipment. It is normal for a small amount of moisture to remain inside the appliance after testing.

Related Documents - HMX-DW03

	Hermitlux Tabletop Dishwasher HMX-DW03 User Manual Comprehensive user manual for the Hermitlux HMX-DW03 tabletop dishwasher, covering installation, operation, maintenance, troubleshooting, and specifications.
	Hermitlux Tabletop Dishwasher HMX-DW03 User Manual Comprehensive user manual for the Hermitlux HMX-DW03 tabletop dishwasher, covering safety instructions, product introduction, control panel functions, installation, operation, maintenance, troubleshooting, specifications, and RoHS requirements.
	Hermitlux Tabletop Dishwasher Manual HMX-DW03 User manual for the Hermitlux HMX-DW03 tabletop dishwasher, covering installation, operation, maintenance, and troubleshooting.
	Hermitlux Tabletop Dishwasher HMX-DW03 User Manual Comprehensive user manual for the Hermitlux Tabletop Dishwasher, model HMX-DW03. Includes safety instructions, product introduction, control panel guide, installation steps, tableware display recommendations, operation instructions, functions overview, maintenance and cleaning tips, troubleshooting guide, specifications, and RoHS compliance information.
	Hermitlux HMX-DW03 Tabletop Dishwasher User and Installation Manual Comprehensive guide for the Hermitlux HMX-DW03 tabletop dishwasher, covering installation, operation, functions, maintenance, troubleshooting, safety, specifications, and RoHS compliance. Features detailed diagrams and step-by-step instructions.
	Hermitlux HMX-DW04 Tabletop Dishwasher User Manual User manual for the Hermitlux HMX-DW04 tabletop dishwasher, providing detailed instructions on safety, installation, operation, maintenance, functions, and troubleshooting for this compact kitchen appliance.




[pdf]

A B C D E F G But Page 1 hermitlux HMX DW03 39 kWh 100 2x 2 02 4 5 L 60 dB ABCD 2019 2017 0605556595170 media but fr products |||

hermitlux A B C D E F G 39 kWh **HMX-DW03** F 100 2x 2:02 4,5 L 60 dB ABCD 2019/2017 ...

lang: **score:45** filesize: 70.13 K page_count: 1 document date: 2021-10-18



[pdf]

Constructional Data Report Standard Gil Diaz 325706 4840803 ETL Countertop Dishwasher With Delay Start No Hookup Needed 5 1 Wash Programs 360° Dual Spray 167° High temp 5l Built in Tank Portable For Apartments Rvs Small Homes FOHERE fhbr1042 TDQR01FOHERE TDQR01325706 etl secure img1 ag wfcdn dm document eb006208 2b91 4fc8 a7c6 c9dd1210516c etl |||

AUTHORIZATION TO MARK This authorizes the application of the Certification Marks shown below to t ... , TZQR03, TSJ04, TSQ04, TSJR04, TSQR04, TDJ04, TDQ04, TDJR04, TDQR04, TZJ04, TZQ04, TZJR04, TZQR04. **HMX-DW03**, HMX-DW04, KPS-XWJ01, HS-DW01WA, HS-DW01BA, HS-DW01WB, HS-DW01GA, HSDW01GB, DW-5, TT-DW001....

lang:en **score:27** filesize: 133.43 K page_count: 1 document date: 2022-05-17



Intertek Authorization to Mark for Countertop Dishwashers

Authorization to Mark document from Intertek for Guangdong Jienuo Electric Appliances Co., Ltd., certifying Countertop Dishwashers under UL 749 and CSA C22.2#167 standards, listing multiple brands and model numbers.

lang:en **score:27** filesize: 149.4 K page_count: 2 document date: 2021-05-14



[Hermitlux HMX-DW03 Lavastoviglie da Tavolo - Manuale Utente](#)

Manuale utente completo per la lavastoviglie da tavolo Hermitlux HMX-DW03.

Fornisce istruzioni dettagliate su sicurezza, installazione, funzionamento, funzioni, manutenzione, risoluzione dei problemi, specifiche e conformità RoHS.

lang:en score:19 filesize: 7.12 M page_count: 22 document date: 2024-01-22