Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Livoo /
- > Livoo DOM430 2-in-1 Slushie and Crushed Ice Maker Instruction Manual

Livoo DOM430

Livoo DOM430 2-in-1 Slushie and Crushed Ice Maker Instruction Manual

Model: DOM430

1. Introduction

Thank you for purchasing the Livoo DOM430 2-in-1 Slushie and Crushed Ice Maker. This appliance is designed to quickly and efficiently prepare refreshing slushies and crushed ice for various beverages and desserts. Please read this manual carefully before first use to ensure proper operation, maintenance, and safety.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the motor unit in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- · Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or
 mental capabilities, or lack of experience and knowledge, unless they have been given supervision or
 instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Livoo DOM430 ice maker:

- 1. Main Unit (Motor Housing)
- 2. Lid
- 3. Ice Shaving Chamber
- 4. Ice Blade/Mechanism
- 5. 1.1 Liter Collection Pitcher
- 6. Stirring Paddle (for slushie function)
- 7. Control Knob (for ice size selection: "Glace Pilée" / "Granité" or "Coarse" / "Fine")
- 8. Power Switch



Image 3.1: Exploded view showing the main unit, lid, ice shaving chamber, collection pitcher, and stirring paddle.

4. SETUP AND FIRST USE

Before using your Livoo DOM430 for the first time, please follow these steps:

- 1. Unpack: Carefully remove all components from the packaging.
- 2. **Clean:** Wash the collection pitcher, lid, and stirring paddle in warm, soapy water. Rinse thoroughly and dry. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.

3. Assemble:

- Place the main unit on a stable, flat, and dry surface.
- Insert the ice shaving chamber into the main unit.
- Place the collection pitcher under the ice outlet.
- If making slushies, ensure the stirring paddle is correctly inserted into the pitcher.
- 4. **Power Connection:** Ensure the appliance is switched off before plugging it into a suitable power outlet.

5. OPERATING INSTRUCTIONS

Your Livoo DOM430 offers two functions: Crushed Ice and Slushie.

5.1 Making Crushed Ice

- 1. Ensure the collection pitcher is in place. The stirring paddle is not required for crushed ice.
- 2. Open the lid of the ice shaving chamber.
- 3. Add ice cubes to the ice shaving chamber. Do not overfill. (Refer to Image 5.1)
- 4. Close the lid securely. The appliance will not operate if the lid is not properly closed.
- 5. Turn the control knob to the "Glace Pilée" (Crushed Ice) or "Coarse" setting. (Refer to Image 5.2)
- 6. Switch on the appliance. The ice will be shaved and dispensed into the collection pitcher.
- 7. Once the desired amount of crushed ice is produced, switch off the appliance and unplug it.
- 8. Serve immediately or store in a freezer.



Image 5.1: Ice cubes loaded into the shaving chamber.



Image 5.2: Front view of the appliance, showing the control knob for ice size selection.

5.2 Making Slushies

- 1. Ensure the collection pitcher with the stirring paddle is correctly inserted.
- 2. Open the lid of the ice shaving chamber.
- 3. Add ice cubes to the ice shaving chamber.
- 4. Close the lid securely.
- 5. Turn the control knob to the "Granité" (Slushie) or "Fine" setting.
- 6. Switch on the appliance. The ice will be finely shaved into the pitcher.
- 7. Once the ice is shaved, add your desired liquid (juice, syrup, soda) to the pitcher.
- 8. Allow the stirring paddle to mix the shaved ice and liquid until a slushie consistency is achieved. This typically takes less than 5 minutes.
- 9. Once the slushie is ready, switch off the appliance and unplug it.
- 10. Serve immediately.



Image 5.3: The Livoo DOM430 preparing a slushie, with a refreshing drink ready.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your appliance.

- 1. Always unplug the appliance before cleaning.
- 2. Disassemble: Remove the lid, ice shaving chamber, collection pitcher, and stirring paddle.
- 3. **Wash Parts:** Wash the lid, ice shaving chamber, collection pitcher, and stirring paddle in warm, soapy water. Use a soft brush if necessary to remove any ice residue. Rinse thoroughly and dry completely. These parts may also be dishwasher safe (check product markings for confirmation).
- 4. **Clean Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water or any other liquid.
- 5. **Storage:** Once all parts are clean and dry, reassemble the appliance or store it in a clean, dry place. The power cord can be stored in the compartment under the appliance for convenience.

7. TROUBLESHOOTING

If you encounter any issues with your Livoo DOM430, please refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Lid not securely closed; Power switch off.	Ensure the appliance is plugged in; Close the lid properly; Turn the power switch to ON.
Ice is not shaving or shaving poorly.	Too much ice; Ice cubes are too large; Blade is dull or obstructed.	Reduce the amount of ice; Use smaller ice cubes; Check for obstructions and clean the blade area (unplug first).
Slushie consistency is not right.	Incorrect ice size setting; Insufficient mixing time; Wrong liquid-to-ice ratio.	Ensure control knob is on "Granité" / "Fine"; Allow more mixing time; Adjust liquid and ice amounts.
Loud noise during operation.	Normal operation noise; Ice cubes are too large or jammed.	Some noise is normal during ice shaving. If excessive, check for jammed ice cubes and clear them (unplug first).

8. SPECIFICATIONS

• Model: DOM430

• Brand: Livoo

• Type: 2-in-1 Slushie and Crushed Ice Maker

• Capacity: 1.1 Liters (collection pitcher)

• Power: 25 Watts

• Ice Production: Approximately 250g/minute

• **Dimensions:** 31 x 21.9 x 19.5 cm

Weight: 1.65 kgColor: White

9. WARRANTY AND SUPPORT

Livoo products are designed and manufactured to the highest quality standards. For information regarding warranty terms, technical support, or spare parts, please refer to the warranty card included with your product or contact your local Livoo customer service. Keep your purchase receipt as proof of purchase. For further assistance, please visit the official Livoo website or contact their customer support channels.

© 2023 Livoo. All rights reserved.

This manual is subject to change without prior notice.

