

[Manuals.plus](#) /

› [Babymoov](#) /

› Babymoov NutriSmart Bottle and Breast Milk Warmer Instruction Manual A002032

Babymoov A002032

Babymoov NutriSmart Bottle and Breast Milk Warmer

MODEL: A002032

Instruction Manual

1. Introduction

The Babymoov NutriSmart is a versatile and efficient device designed to warm baby bottles, breast milk bags, and baby food jars. It offers two heating modes: a gentle bain marie mode for preserving breast milk nutrients and a fast steam mode for quick warming. With programmable features and adapters for both home and car use, the NutriSmart provides convenience for parents on the go or at home.

Nutri Smart



Der All-in-One Babykost-,
Muttermilch- und Flaschenwärmer.



LEBENSLANGE
Garantie*



Image: The Babymoov NutriSmart warmer shown with various baby feeding items it can heat, including a bottle, a breast milk storage bag, and two small food jars.

2. Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plugs in water or other liquids.
- Always supervise children near the appliance.
- Do not operate the appliance if it has a damaged cord or plug, or if it malfunctions or has been damaged in any way.
- Use only accessories recommended by the manufacturer.
- Ensure the voltage indicated on the appliance matches your mains voltage.
- Always unplug the appliance when not in use and before cleaning. Allow it to cool before handling.
- Hot surfaces: The heating plate and surrounding areas become hot during use. Avoid contact.
- Always check the temperature of the warmed food or milk before feeding your baby.

3. Package Contents

Please check that all components are present:

- NutriSmart Warmer Unit
- Home Power Adapter (220/240V)
- Car Power Adapter (12V)
- Heating Basket
- Lid/Adapter Ring

4. Product Features

- **Precise Heating:** Automatically adjusts heating time based on the quantity (ml/g) and initial temperature (ambient, fridge, or frozen) of the contents.
- **Breast Milk Nutrient Preservation:** The 'bain marie' mode gently warms breast milk up to a maximum of 65°C to preserve its nutritional qualities.
- **Programmable Start:** Features an automatic or delayed start function, allowing you to set heating to begin between 15 minutes and 12 hours later.
- **Fast Warming:** The steam mode can warm 65ml of water (at ambient temperature) in approximately 80 seconds.
- **Portable Design:** Compact and includes both home and car adapters for convenient use anywhere.
- **Automatic Keep Warm:** Maintains the contents at an ideal temperature of 37°C for 1 hour after heating.
- **Multi-Use:** Suitable for warming milk, baby food, and gentle defrosting.
- **Universal Compatibility:** Accommodates most bottles, baby food jars, and breast milk bags up to 8cm in diameter.

Angepasste Heizzeit je nach Menge oder Umgebungstemperatur (Raum, Kühlschrank oder gefroren).

Praktisch für unterwegs dank der zwei mitgelieferten Stecker: für zu Hause und im Auto.



Image: The NutriSmart's digital display, highlighting its adjustable heating time feature based on quantity and initial temperature, and its portability for on-the-go use.

5. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wipe the internal and external surfaces with a damp cloth. The heating basket and lid can be washed in a dishwasher or by hand.
3. **Power Connection:**
 - **For Home Use:** Connect the home power adapter to the warmer and then plug it into a standard electrical outlet (220/240V).
 - **For Car Use:** Connect the car power adapter to the warmer and then plug it into your vehicle's cigarette lighter socket (12V).
4. **Place Basket:** Insert the heating basket into the warmer unit.



Schnell

- Angepasste Aufwärmzeit
- 80 Sek.* zum Aufwärmen einer 65 ml-Flasche

*geprüft mit 65 ml Wasser bei Raumtemperatur und 20°C (Dampfmodus).



Image: The NutriSmart warmer shown in a car, demonstrating its portability with the included car adapter. The image also displays both the home and car power adapters.

6. Operating Instructions

The NutriSmart features an intuitive digital display and control buttons.

1. **Add Water:** Pour the appropriate amount of water into the heating chamber. The manual will specify exact quantities for different heating modes and volumes.
2. **Place Item:** Place the bottle, breast milk bag, or baby food jar into the heating basket. Ensure the lid is securely placed on the warmer.
3. **Select Mode:** Use the control buttons to select your desired heating mode:
 - **Bain Marie Mode:** Ideal for breast milk and defrosting baby food. This mode heats gently up to 65°C to preserve nutrients.
 - **Steam Mode:** For rapid warming of formula milk and baby food jars.
4. **Set Parameters:** Indicate the quantity of liquid/food (ml/g) and its initial temperature (ambient, refrigerated, or frozen). The NutriSmart will automatically calculate the optimal heating time to reach 37°C.
5. **Delayed Start (Optional):** To use the delayed start function, select the desired delay time (15 minutes to 12 hours) before confirming your heating settings. The warmer will start automatically after the set delay.
6. **Start Heating:** Press the 'OK' button to begin the heating cycle.

7. **Keep Warm Function:** After the heating cycle is complete, the NutriSmart automatically enters a 'keep warm' mode, maintaining the contents at 37°C for up to 1 hour.
8. **Remove Item:** Carefully remove the warmed item using the basket handle. Always check the temperature of the contents before feeding your baby.



Funktional

Wärmt Ihre Babyflaschen, Muttermilchbeutel und Gläschen auf.

Praktisch

- Wasserbadfunktion zur Erhaltung der Nährstoffe beim Erwärmen von Muttermilch
- Dampfmodus zum Erhitzen



Image: Three NutriSmart units demonstrating various functions: one set for a 12-hour delayed start, another actively heating, and a third showing a 90ml quantity setting.

7. Cleaning and Maintenance

- Always unplug the appliance and allow it to cool completely before cleaning.
- **External and Internal Surfaces:** Wipe with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- **Removable Parts:** The adapter ring, lid, and heating basket are dishwasher safe. Alternatively, wash them by hand with warm soapy water and rinse thoroughly.
- **Descaling:** Over time, mineral deposits may accumulate on the heating plate. To descale, mix 100ml of white vinegar with 100ml of cold water and pour into the heating chamber. Let it sit for 1-2 hours, then empty and rinse thoroughly. Do not turn on the appliance during descaling.

8. Troubleshooting

- **Appliance not turning on:** Ensure the power adapter is correctly plugged into both the warmer and the power source (wall outlet or car socket). Check the power source for functionality.

- **Food/Milk not warming sufficiently:**
 - Verify that the correct quantity and initial temperature settings were entered.
 - Ensure sufficient water was added to the heating chamber.
 - For bain marie mode, ensure the water level is appropriate for the item being warmed.
 - If using the car adapter, ensure the vehicle's engine is running for optimal power supply.
- **No audible signal after heating:** The NutriSmart does not emit an audible signal immediately after the heating cycle completes. It transitions to the automatic 'keep warm' function. An alert may sound after the 1-hour keep-warm period.
- **Error message on display:** Refer to the full user manual for specific error codes and their solutions. If the issue persists, contact customer support.

9. Specifications

Model Number	A002032
Dimensions (L x W x H)	12 x 13 x 16.5 cm
Weight	890 grams
Power (Car)	12V - 100W
Power (Home)	220/240V - 300W
Materials	Polypropylene, ABS / BPA-free



Image: The NutriSmart warmer with its dimensions (12 cm width, 13 cm depth, 16.5 cm height) clearly marked.

10. Warranty and Support

The Babymoov NutriSmart comes with a lifetime warranty, reflecting our commitment to quality and durability. For warranty claims, technical support, or any questions regarding your product, please contact Babymoov customer service through our official website or the contact information provided with your purchase.

Please retain your proof of purchase for warranty purposes.