Manuals+

Q & A | Deep Search | Upload

OttLite CSP9300W

OttLite ClearSun Flex LED Floor Lamp User Manual

Model: CSP9300W

INTRODUCTION


Thank you for choosing the OttLite ClearSun Flex LED Floor Lamp. This lamp is designed to provide balanced, natural illumination, reducing eyestrain and enhancing visual clarity for various tasks such as reading, crafting, and general lighting needs. Its flexible neck and touch-activated controls offer versatile and convenient operation.



The OttLite ClearSun Flex LED Floor Lamp providing bright, clear light in a home environment.

KEY FEATURES

- ClearSun LED Technology: Designed to match the spectral output of natural sunlight, reducing eyestrain by up to 51% and providing a Color Rendering Index (CRI) of 95+.
- Adjustable Rubberized Flex Neck: Allows for precise light positioning, with the shade extending from 49 to 71 inches in height.
- Touch-Sensitive Controls: Easily adjust brightness levels with a simple touch.
- Smart Memory Feature: The lamp remembers your last brightness setting for convenience.
- **Versatile Use:** Ideal for various activities including reading, sewing, knitting, puzzles, painting, and general office or home illumination.




Overview of the lamp's key features, including dimmable light, smart memory, touch controls, and a flexible neck.



ClearSun LED technology is designed to reduce eyestrain by matching natural daylight spectrum.



The 95+ Color Rendering Index (CRI) of ClearSun LEDs ensures accurate and vivid color representation.



OttLite's commitment to healthy lighting is rooted in the pioneering research of Dr. John Nash Ott.

SETUP AND ASSEMBLY

The OttLite ClearSun Flex LED Floor Lamp requires minimal assembly. Please follow these steps:

- 1. Carefully unpack all components from the packaging.
- 2. Connect the lamp pole sections by screwing them together securely. Ensure all connections are firm to maintain stability.
- 3. Attach the assembled lamp pole to the base, twisting until it is tightly fastened.
- 4. Plug the power cable into the lamp's power input, then into a standard electrical outlet.

Ensure the lamp is placed on a stable, flat surface to prevent tipping.

OPERATING INSTRUCTIONS

The OttLite ClearSun Flex LED Floor Lamp features intuitive touch controls for easy operation.

- Power On/Off: Lightly touch the power icon on the lamp pole to turn the lamp on or off.
- Adjust Brightness: While the lamp is on, touch and hold the power icon to cycle through different brightness levels. Release your finger when the desired brightness is reached. The smart memory feature will recall this setting when the lamp is turned on again.
- Adjusting the Flex Neck: Gently bend and position the rubberized flex neck to direct the light precisely where needed. The sturdy neck will hold its position.

Your browser does not support the video tag.

Official OttLite video demonstrating the ClearSun technology and its benefits for eye health and visual clarity. This video highlights how OttLite lamps provide balanced, natural light.



Perfect for reading in your favorite chair or sewing in your craft room

The adjustable height and flexible neck make the lamp suitable for various tasks like sewing or reading.

CARE AND MAINTENANCE

• Cleaning: To clean the lamp, ensure it is unplugged and cool. Wipe with a soft, damp cloth. Do not use abrasive

cleaners or solvents, as they may damage the finish.

- LED Longevity: The integrated LEDs are designed for long-lasting performance and are not replaceable.
- **Storage:** If storing the lamp, ensure it is clean, dry, and disassembled if necessary, then store in its original packaging or a protective container in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Power cable not securely plugged in. No power from outlet.	Ensure power cable is fully inserted into the lamp and wall outlet. Test the outlet with another device to confirm power supply.
Light flickers or is dim.	Loose connection. Power fluctuation.	Check all lamp pole connections and ensure they are tight. Try plugging the lamp into a different outlet.
Touch controls are unresponsive.	Dust or debris on the touch sensor. Temporary electronic glitch.	Wipe the touch sensor area with a clean, dry cloth. Unplug the lamp for 30 seconds, then plug it back in to reset.

If issues persist after attempting these solutions, please contact OttLite customer support for further assistance.

PRODUCT SPECIFICATIONS

Attribute	Detail
Model Number	CSP9300W
Dimensions (H x W x D)	Adjustable from 49" to 71" H x 12.5" W x 10.3" D
Light Source	Integrated LED (ClearSun Technology)
Color Temperature	5000 Kelvin
Color Rendering Index (CRI)	95+
Brightness	745 Lumens
Wattage	8.7 watts
Power Source	Corded Electric (120 Volts)
Switch Type	Touch-Activated
Material	Plastic (Shade), Rubber (Base)
Item Weight	9.58 pounds
Included Components	Power Cable


WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or visit the official OttLite website. Contact information for customer service is typically available on the manufacturer's website or product packaging.

Note: Specific warranty terms may vary by region and retailer. Please retain your proof of purchase for warranty claims.

© 2025 OttLite. All rights reserved. For more information, visit OttLite Store


Documents - OttLite - CSP9300W




[pdf] User Manual Owner's Manual Instructions Warranty Accessories

Owner Manual OttLite Flex LED Floor Lamp with Touch Controls Adjustable Neck Smart Memory Feature pbwx1124 CSP9300WOttLite CSP9300W543 instructions csp9300w flex led floor lampsecure img1 ag wfcdn dm document 1f771ea6 d57c 4643 90ee 6803d86688c7 543 lamp |||

Q DO NOT USE SHADE OR ACCESSORIES IN THIS AREA Flex LED Floor Lamp **CSP9300W** INS190541 H G F E D Figure 3 C Figure 4 B O N P A K L M FIGURE 1 Usable area for shade and accessory 30 30 J Figure 2 ACDL10F-FS ENGLISH CONGRATULATIONS You ve purchased the finest in natural lighting tec... lang:en score:48 filesize: 211.01 K page_count: 1 document date: 2019-11-25





Q DO NOT USE SHADE OR ACCESSORIES IN THIS AREA Flex LED Floor Lamp **CSP9300W** INS190541 H G F E D Figure 3 C Figure 4 B O N P A K L M FIGURE 1 Usable area for shade and accessory 30 30 J Figure 2 ACDL10F-FS ENGLISH CONGRATULATIONS You ve purchased the finest in natural lighting tec... lang:en score:43 filesize: 211.01 K page_count: 1 document date: 2019-11-25

