

## TACAHE TCH-CFL02

# TACAHE Minimalist Corner Floor Lamp

Model: TCH-CFL02

## INTRODUCTION

Thank you for purchasing the TACAHE Minimalist Corner Floor Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before assembly and operation, and retain them for future reference.

This LED floor lamp is designed to provide ambient lighting with adjustable brightness and color temperature, suitable for various indoor settings such as living rooms and bedrooms. It features a minimalist design and convenient remote control operation.

## SAFETY INFORMATION

- Indoor Use Only:** This lamp is designed for indoor use. Do not expose it to water or high humidity.
- Electrical Safety:** Ensure the power outlet matches the lamp's voltage requirements. Do not use if the power cord is damaged.
- Stable Placement:** Place the lamp on a flat, stable surface to prevent tipping.
- Cleaning:** Disconnect from power before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Children and Pets:** Keep the lamp out of reach of children and pets to prevent accidental damage or injury.
- Disassembly:** Do not attempt to disassemble or modify the lamp. This may void the warranty and pose a safety risk.

## PACKAGE CONTENTS

Please check the package contents to ensure all parts are present and undamaged:

- LED Floor Lamp (multiple sections)
- Lamp Base
- Power Adapter
- Remote Control
- User Manual

## SETUP AND ASSEMBLY

The TACAHE Minimalist Corner Floor Lamp is designed for quick and easy assembly, typically within 5 minutes.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Lamp Pole:** Connect the individual sections of the lamp pole by gently twisting them together clockwise until secure. Ensure the internal wiring is not pinched.
3. **Attach to Base:** Screw the assembled lamp pole into the lamp base clockwise until it is firmly attached and stable.
4. **Connect Power:** Insert the power adapter into the lamp's power port, then plug the adapter into a standard electrical outlet.
5. **Remote Control Setup:** Ensure the remote control has batteries installed (not included). The lamp and remote are typically pre-paired.



The TACAHE Minimalist Corner Floor Lamp, fully assembled and illuminated in a living room setting, demonstrating its sleek design and ambient light output.




Diagram illustrating the dimensions of the TACAHE Minimalist Corner Floor Lamp, showing a height of 57 inches and a base width of 5.51 inches.

## OPERATING INSTRUCTIONS

The TACAHE Minimalist Corner Floor Lamp is controlled using the included touch-sensitive remote control.

### Remote Control Functions

- **Power On/Off:** Press the power button to turn the lamp on or off.
- **Brightness Adjustment:** Use the brightness buttons (typically marked with sun icons or +/-) to increase or decrease the light intensity. The lamp offers 10 brightness presets.
- **Color Temperature Adjustment:** Use the color temperature buttons (often marked with K values or a color spectrum) to adjust the light from warm white (2700K) to cool white (6500K). This lamp features stepless color temperature adjustment.
- **Memory Function:** The lamp retains the last brightness and color temperature settings when turned off and on again.




Visual representation of the lamp's key features, including remote control, memory setting, dimmable functionality, easy installation, and 12V safety voltage.

## Brightness Presets

The lamp offers various brightness levels to suit different moods and activities:

- **10% Night Light:** Ideal for subtle illumination in dark rooms.
- **50% Mood Light:** Suitable for creating a relaxed atmosphere.
- **100% Working/Ambient Light:** Provides maximum illumination for general ambient lighting.



## 10 Brightness Presets

- More Brightness Options


Illustrates the three primary brightness presets: 10% for night light, 50% for mood lighting, and 100% for general ambient or working light.

## Color Temperature Range

Adjust the color temperature to match your preference or environment:

- **2700K (Warm White):** Provides a cozy, inviting glow.
- **6500K (Cool White):** Offers a bright, energetic light.

- **Stepless Adjustment:** The remote allows for smooth, continuous adjustment between 2700K and 6500K.



Demonstrates the stepless color temperature adjustment feature, allowing users to select any shade from warm 2700K to cool 6500K.

## MAINTENANCE

Proper care will ensure the longevity and optimal performance of your TACAHE Minimalist Corner Floor Lamp.

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry, lint-free cloth to wipe the lamp pole and base. Avoid using water, cleaning sprays, or abrasive materials, as these can damage the finish or electrical components.
- **Bulb Replacement:** The LED light source is integrated and not user-replaceable. If the LED light fails, please contact customer support.
- **Storage:** If storing the lamp for an extended period, disassemble it and store it in its original packaging in a dry, cool place.

## TROUBLESHOOTING

If you encounter issues with your lamp, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection, remote control battery dead.	Check if the power adapter is securely plugged into the lamp and the wall outlet. Ensure the outlet is functional. Replace remote control batteries.

Problem	Possible Cause	Solution
Remote control is unresponsive.	Remote control battery dead, remote out of range, interference.	Replace remote control batteries. Ensure you are within the effective range of the lamp. Remove any obstructions between the remote and the lamp.
Light flickers or changes color unexpectedly.	Unstable power supply, internal wiring issue.	Try plugging the lamp into a different outlet. Ensure all lamp sections are securely twisted together. If the problem persists, contact customer support.
Lamp is unstable.	Base not securely attached, uneven surface.	Ensure the lamp pole is tightly screwed into the base. Place the lamp on a flat, level surface.

## SPECIFICATIONS





Feature	Detail
Model Number	TCH-CFL02
Product Dimensions	5.51"D x 5.51"W x 57"H (14cm x 14cm x 145cm)
Item Weight	2.81 pounds (1.28 kg)
Material	Metal (Base), Plastic (Shade)
Finish Type	Polished
Light Source Type	LED
Wattage	12 Watts
Voltage	12 Volts
Color Temperature	2700K - 6500K (Dimmable, Stepless Adjustment)
Control Method	Remote Control
Cable Length	57 Inches
Indoor/Outdoor Usage	Indoor Only
Assembly Required	Yes
Included Components	Remote Control


## WARRANTY AND SUPPORT

TACAHE is committed to providing quality products and customer satisfaction. If you encounter any product issues or require assistance, please contact our professional after-sale service team. For support, please refer to the contact information provided with your purchase or visit the official TACAHE brand store on Amazon: [TACAHE Amazon Store](#).

© 2025 TACAHE. All rights reserved.

## Related Documents - TCH-CFL02






## TACAHE RGB Corner Lamp User Manual

User manual for the TACAHE RGB Corner Lamp, detailing installation, remote control operation, color settings, and troubleshooting.




02



### REMOTE MANUAL

Touch-Sensitive Remote



**Code Matching:**

Long Press & Hold "Blue" for 3-5s until the lamp flash "Blue" light for 3 times.

**Clear the Code Matching:**

Long Press & Hold "Yellow" for 3-5s until the lamp flash "Yellow" light for 3 times.

03



First, press any key of the color wheel.

Second, press "M" to select the solid color (red, green, blue, teal, yellow, purple, 6000K MIX WHITE).

MrSelect key

04



The loop mode will change the light automatically in more than 300+ patterns.

1. Press any key of the color wheel.  
2. Press "Auto" button.  
AutoPause

05



Step 1: Remote Troubleshoot

Does the remote indicator flash when you press?

If not, contact us for replacement remote.  
Indicator

If yes, follow step 2.

Step 2: Check the light of the lamp.

1. The lamp stay in Colorful Light and remote doesn't work. Follow the remote instruction, and clear the code matching by Long Press & Hold "Yellow" for 3-5s until the lamp flash "Yellow" light for 3 times.

2. The lamp stay in White/Blue and remote doesn't work. Contact us or request an replacement from Amazon.

3. The lamp can not be turn on. Contact us or request an replacement from Amazon.

If there are other issue or product inquiry, please contact us.

06



	<p><a href="#"><u>Fusion Climb 1015 EN 12277 UIAA Harness: User Manual and Safety Guide</u></a></p> <p>Comprehensive user manual and safety guide for Fusion Climb 1015 EN 12277 UIAA harnesses. Includes instructions, warnings, care, maintenance, and product specifications.</p>
	<p><a href="#"><u>TROTEC TCH 1510 E / TCH 2510 E Convector Heater Operating Manual</u></a></p> <p>Comprehensive operating manual for the TROTEC TCH 1510 E and TCH 2510 E convector heaters, covering safety, installation, operation, maintenance, and technical specifications. Learn how to use your convector heater safely and efficiently.</p>
	<p><a href="#"><u>DeLonghi TCH Series Ceramic Fan Heater - User Manual</u></a></p> <p>Comprehensive user manual for the DeLonghi TCH Series ceramic fan heater, detailing electrical connections, operational controls, safety warnings, and assembly instructions.</p>
	<p><a href="#"><u>TROTEC TCH 2010 E / TCH 2011 E Designer Glass Convector Operating Manual</u></a></p> <p>Comprehensive operating manual for the TROTEC TCH 2010 E and TCH 2011 E Designer Glass Convector, covering safety, operation, maintenance, and technical specifications.</p>