

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LINSY HOME](#) /

› [LINSY HOME 3-Tier Open Storage TV Stand Instruction Manual](#)

LINSY HOME 3-Tier Open Storage TV Stand (B08SLTWLWW)

LINSY HOME 3-Tier Open Storage TV Stand Instruction Manual

Model: 3-Tier Open Storage TV Stand (B08SLTWLWW)

Brand: LINSY HOME

INTRODUCTION

Thank you for choosing the LINSY HOME 3-Tier Open Storage TV Stand. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This TV stand is designed to accommodate televisions up to 55 inches and features three open storage tiers for media devices, accessories, and decorative items. Its robust metal frame and durable wooden shelves offer both stability and a modern industrial aesthetic.

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended to have two people for assembly. Ensure all parts are present before starting. A detailed assembly guide is included in the packaging.

Package Contents

- Wooden Shelf Panels
- Metal Frame Components
- Assembly Hardware (screws, bolts, Allen wrench)
- Adjustable Feet
- Instruction Manual

Assembly Steps

- 1. Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to identify each piece.
- 2. Assemble the Metal Frame:** Connect the vertical and horizontal metal frame components using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten initially.

3. **Attach Shelf Panels:** Place the wooden shelf panels onto the designated sections of the metal frame. Secure them with the appropriate hardware. Start with the bottom shelf and work your way up.
4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the metal frame. These feet help stabilize the stand on uneven surfaces.
5. **Final Tightening:** Once all components are assembled, go back and securely tighten all screws. Do not overtighten to avoid damaging the material.
6. **Positioning:** Carefully move the assembled TV stand to its desired location. Adjust the feet as needed to ensure the stand is level and stable.




Image: The LINSY HOME 3-Tier Open Storage TV Stand integrated into a living room environment, showcasing its design and functionality.



Image: Detail of the robust metal frame connection, highlighting the structural integrity of the TV stand.



Image: Close-up of the adjustable foot, designed to provide stability and level the stand on various floor types.

OPERATING INSTRUCTIONS

The LINSY HOME TV Stand is designed for straightforward use as a media console and storage unit.

Placement of Television

- Carefully place your television on the top shelf of the stand. Ensure the TV's base is fully supported and centered to prevent tipping.
- This stand is suitable for TVs up to 55 inches. Always check your TV's weight and dimensions against the stand's specifications to ensure compatibility and safety.

Utilizing Storage Shelves

- The two lower open shelves provide ample space for media players, gaming consoles, soundbars, and other electronic devices.
- Organize cables neatly to prevent clutter and ensure proper ventilation for electronic components.
- Avoid overloading shelves beyond their weight capacity to maintain stability and prevent damage.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your LINSY HOME TV Stand.

Cleaning

- For general cleaning, wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Promptly wipe up any spills to prevent staining, especially on the wooden surfaces.

Surface Protection

- The stand features a water-resistant surface, offering protection against minor spills.
- Despite its resistance, it is advisable to use coasters under drinks and protective pads under heavy or sharp objects to prevent marks and scratches.



Image: Water droplets on the surface of the TV stand, demonstrating its water-resistant properties.

Structural Integrity

- Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- Avoid dragging the stand when moving it; always lift it to prevent damage to the frame or floor.

TROUBLESHOOTING

This section addresses common issues you might encounter with your TV stand.

Stand is Wobbly or Uneven

- **Check Connections:** Ensure all screws and bolts are securely tightened. Loose connections can cause instability.
- **Adjust Feet:** Use the adjustable feet at the bottom of the stand to level it on uneven floors. Turn them clockwise or counter-clockwise until the stand is stable.
- **Verify Assembly:** Double-check that all parts were assembled according to the instruction manual. Incorrectly installed components can affect stability.

Damaged or Missing Parts

- If you discover any damaged or missing parts upon unboxing, do not proceed with assembly.
- Contact LINSY HOME customer support immediately for assistance. Provide your purchase details and a description of the issue.

SPECIFICATIONS

Brand	LINSY HOME
Model Identifier (ASIN)	B08SLTWLWW
Material	Metal, Wood
Dimensions (L x W x H)	152.4 x 39.9 x 81.3 cm (60 x 15.7 x 32 inches)
Product Weight	18.14 kg (40 lbs)

Color	Dark Brown
Style	Industrial
Assembly Required	Yes
Care Instructions	Wipe with a damp cloth

WARRANTY INFORMATION

Specific warranty details for the LINSY HOME 3-Tier Open Storage TV Stand may vary by retailer and region. Please refer to your purchase documentation or the retailer's website for precise warranty terms and conditions.

Generally, products are covered against manufacturing defects for a limited period from the date of purchase. This warranty typically does not cover damage resulting from improper assembly, misuse, accidents, or normal wear and tear.

CUSTOMER SUPPORT

For any questions regarding assembly, missing parts, or product issues, please contact LINSY HOME customer support or the retailer from whom you purchased the product.

When contacting support, please have the following information ready:

- Product Model: LINSY HOME 3-Tier Open Storage TV Stand (B08SLTWLWW)
- Date of Purchase
- Place of Purchase
- A detailed description of the issue

We are committed to providing assistance and ensuring your satisfaction with LINSY HOME products.