

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Full Size Metal Loft Bed with Desk and Shelves - Instruction Manual

Bellemave B08SLV4ZGX (Double White with Desk)

Bellemave Full Size Metal Loft Bed with Desk and Shelves - Instruction Manual

Model: B08SLV4ZGX (Double White with Desk)

PRODUCT OVERVIEW

The Bellemave Full Size Metal Loft Bed is designed to maximize space efficiency in bedrooms, particularly for children, teenagers, or small living areas. This innovative bed frame combines a comfortable sleeping area with a functional workstation and integrated shelving underneath, offering a versatile solution for studying, working, or creative activities. Constructed from durable metal and engineered wood, the loft bed features a robust frame with full-length guardrails and an integrated ladder for safety and stability. The design eliminates the need for a box spring, providing a cost-effective and streamlined setup.



Image: Front view of the Bellemave Full Size Metal Loft Bed, showcasing the white metal frame, integrated wooden desk, and triangular shelves. The bed is set up in a room with a laptop on the desk and decorative items on the shelves.

SETUP AND ASSEMBLY

Assembly of the Bellemave Full Size Metal Loft Bed is required. All necessary hardware and an instruction manual are included with the product to facilitate the assembly process.

Before You Begin:

- Unpack all components and verify that all parts listed in the included manual are present and undamaged.
- Ensure you have adequate space for assembly.
- Gather any required tools not included (e.g., Phillips head screwdriver, if not provided).

Assembly Steps:

1. Follow the step-by-step instructions provided in the physical assembly manual included in the packaging.
2. Carefully identify each part by its label before beginning assembly.
3. Tighten all bolts and screws securely, but do not overtighten until instructed to do so.
4. Ensure all safety features, such as guardrails and ladder, are correctly installed and secured.




Image: Technical diagram illustrating the overall dimensions and key measurements of the loft bed, including the height, width, length, and dimensions of the desk and shelves.



Image: Close-up detail of the metal frame construction, showing the secure connections and the attachment point for the ladder, emphasizing the bed's sturdy design.

OPERATING INSTRUCTIONS

The Bellemave Loft Bed is designed for multi-functional use, providing both a sleeping area and a dedicated workspace.

Using the Bed:

- The top bed is designed for a full-size mattress with a recommended thickness of 6 inches.

- Always use the integrated ladder to access the top bunk. Do not climb on the frame directly.
- Ensure the weight on the top bed does not exceed the maximum capacity of **250 pounds**.
- The full-length guardrails are essential safety features; do not remove or modify them.

Using the Desk and Shelves:

- The integrated desk provides a spacious area for studying, working on a computer, or engaging in hobbies.
- The desk has a maximum weight capacity of **120 pounds**. Avoid placing excessively heavy items on it.
- The triangular shelves are suitable for storing books, school supplies, decorative items, or small electronics.
- Each shelf has a maximum weight capacity of **60 pounds**. Distribute weight evenly.



Image: Detailed view of the wooden desk surface and the two triangular shelves, highlighting their design and potential for organization and display.

MAINTENANCE

Regular maintenance will help prolong the life and ensure the safety of your Bellemave Loft Bed.

Cleaning:

- For general cleaning, wipe the metal frame and wooden surfaces with a soft, dry cloth.
- Avoid using abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth.

Inspection:

- Periodically check all bolts, screws, and connections to ensure they remain tight. Retighten if necessary.
- Inspect the ladder and guardrails for any signs of wear or damage.
- Ensure all slats are securely in place and undamaged.
- Do not use the bed if any part is broken, missing, or damaged.

TROUBLESHOOTING

If you encounter issues with your Bellemave Loft Bed, consider the following common solutions:

Problem: Bed feels wobbly or unstable.

- **Solution:** Check all assembly bolts and screws. Ensure they are fully tightened. Over time, connections can loosen, requiring periodic retightening.
- **Solution:** Verify that the bed is placed on a flat, level surface. Uneven flooring can contribute to instability.

Problem: Squeaking noises.

- **Solution:** Squeaking often indicates loose connections. Retighten all bolts and screws.
- **Solution:** Ensure the mattress is properly seated and not causing friction against the frame.

Problem: Missing or damaged parts.

- **Solution:** Refer to the parts list in your assembly manual. Contact the retailer or manufacturer's customer support for assistance with replacement parts. Do not attempt to use the bed with missing or damaged components.

PRODUCT SPECIFICATIONS

Product Type	Loft Bed
Model	B08SLV4ZGX
Size	Full (Matrimonial)
Color	White (with Brown Desk/Shelves)
Material	Metal (Alloy Steel) and Engineered Wood (MDF)
Overall Product Dimensions (L x W x H)	79.5 inches x 57 inches x 71.6 inches (201.93 cm x 144.78 cm x 181.86 cm)
Desk Dimensions (W x L)	13.8 inches x 54.7 inches
Shelf Dimensions (W x L)	15.3 inches x 12.2 inches
Space Under Bed	Approx. 59 inches
Total Product Weight	108 lbs (48.99 kg)
Weight Capacity - Top Bed	250 lbs
Weight Capacity - Desk	120 lbs
Weight Capacity - Shelves	60 lbs
Recommended Mattress Thickness (Top Bed)	6 inches

Number of Slats	21
Box Spring Required	No
Assembly Required	Yes (Full Assembly)
Care Instructions	Wipe clean with a dry cloth



Image: Side perspective of the loft bed, providing a clear view of the ladder and the functional desk and shelving unit beneath the bed frame.

WARRANTY INFORMATION

Specific warranty details for the Bellemave Full Size Metal Loft Bed are typically provided within the product packaging or on the manufacturer's official website. Please refer to the documentation included with your purchase for comprehensive warranty terms and conditions.

In general, warranties cover manufacturing defects and material flaws under normal use. Damage resulting from improper assembly, misuse, neglect, or unauthorized modifications is usually not covered.

CUSTOMER SUPPORT

For any questions regarding assembly, missing parts, product functionality, or warranty claims, please contact the retailer from whom you purchased the product or the manufacturer directly.

Manufacturer: **Bellemave**

Please have your product model number (B08SLV4ZGX) and purchase date available when contacting support to expedite assistance.

You may also visit the [Bellemave Brand Store on Amazon](#) for more information and contact options.



