Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave MF642AAN

Bellemave MF642AAN Twin Over Twin Metal Bunk Bed with Trundle Instruction Manual

Model: MF642AAN | Brand: Bellemave

1. Safety Information

For safe use, ensure that the weight on the upper and bottom beds does not exceed 250 lbs, and the trundle bed should not exceed 250 lbs. Always use the built-in ladder and full-length guardrails on the top bunk to prevent falls. Inspect all parts before and during assembly to ensure there are no sharp edges or potential pinch points.

WARNING: Failure to follow these warnings could result in serious injury.

- Always use the recommended mattress size and thickness for each bed.
- Ensure all connections are securely tightened before use.
- Do not allow children under 6 years of age on the upper bunk.
- Periodically check and ensure that the guardrail, ladder, and other components are in their proper position and free from damage.

2. Product Overview

The Bellemave MF642AAN is a sturdy metal twin-over-twin bunk bed designed for small spaces, featuring a convenient pull-out trundle bed. Its streamlined steel-crafted frame with a chrome silver powder-coated finish offers both durability and a modern aesthetic. This bunk bed efficiently accommodates multiple users, providing a versatile sleeping solution.

Key Features:

- **Twin Over Twin Design with Trundle:** Provides three sleeping spaces, ideal for guests or shared rooms. The trundle includes four easy-glide casters (2 locking, 2 non-locking) for smooth operation.
- **Solid Stability:** Constructed with a quality-tested steel frame for enhanced stability and durability.
- **Elegant Appearance:** Sleek silhouette and chrome silver powder-coated finish complement various home decor styles.
- **Space-saving:** An efficient solution for maximizing space in bedrooms.
- **Easy Assembly:** Comes with clear instructions and all necessary tools for straightforward setup.



Figure 2.1: Bellemave Twin Over Twin Bunk Bed with Trundle.

3. Package Contents

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Upper Bunk Frame Components
- Lower Bunk Frame Components
- Trundle Bed Frame Components
- Ladder Components
- Safety Rails
- Bed Slats (for upper, lower, and trundle beds)
- Hardware Pack (bolts, washers, nuts, Allen wrench)
- Instruction Manual

4. Setup and Assembly Instructions

Follow these steps carefully to assemble your Bellemave bunk bed. It is recommended to have two adults for assembly.

4.1 Assembly Overview Video

Your browser does not support the video tag.

Video 4.1: General assembly process for a metal bunk bed with trundle. Note: Specific parts may vary slightly from your model.

4.2 Step-by-Step Assembly

1. **Assemble Headboards and Footboards:** Attach the horizontal bars to the vertical posts for both the upper and lower bed sections. Ensure all bolts are finger-tightened initially.
2. **Connect Side Rails:** Attach the side rails to the assembled headboards and footboards for both the upper and lower bed sections.
3. **Install Center Support Legs:** Secure any center support legs to the lower bed frame.
4. **Attach Slats:** Place and secure the bed slats onto the frame for both the upper and lower beds. Ensure even spacing and secure attachment.
5. **Assemble Trundle Bed:** Assemble the trundle frame, including its side rails and slats. Attach the casters to the trundle frame.
6. **Attach Ladder:** Securely attach the ladder to the designated side of the bunk bed.
7. **Final Tightening:** Once all components are in place, fully tighten all bolts and fasteners using the provided Allen wrench. Do not overtighten.



Figure 4.2: Product dimensions for planning and assembly.



Figure 4.3: Detail of the sturdy metal slats providing mattress support.

4.3 Construction and Stability Video

Your browser does not support the video tag.

Video 4.4: Demonstrates the robust construction and stability of a similar metal bunk bed.

5. Operating Instructions

5.1 Using the Trundle Bed

The trundle bed is designed for easy access and storage. To use, simply pull the trundle frame out from under the lower bunk. The casters allow for smooth movement. To store, push the trundle back under the lower bunk until it is fully concealed.

SIZE:INCH




Figure 5.1: Trundle bed extended from under the lower bunk.



Figure 5.2: Trundle bed retracted, saving space.

5.2 Trundle Bed Operation Video

Your browser does not support the video tag.

Video 5.3: Demonstrates the smooth operation of the trundle bed.

5.3 Using the Ladder

The bunk bed is equipped with a built-in ladder for safe access to the upper bunk. Always use the ladder when climbing up or down. Ensure a firm grip on the ladder rungs and maintain three points of contact (two hands and one foot, or two feet and one hand) at all times.



Figure 5.4: Detail of the integrated ladder for upper bunk access.

6. Maintenance

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Fastener Checks:** Periodically check all bolts and fasteners to ensure they remain tight. Re-tighten as necessary to maintain stability and safety.
- **Mattress Care:** Follow the manufacturer's guidelines for mattress care. Rotate and flip mattresses regularly to prolong their lifespan.
- **Trundle Casters:** Keep trundle casters free of debris to ensure smooth operation.

7. Troubleshooting

- **Squeaking Noises:** If the bed squeaks, check all bolts and connections. Tighten any loose fasteners. Applying a small amount of lubricant to metal-on-metal contact points can also help.
- **Wobbly Frame:** A wobbly frame usually indicates loose connections. Re-check and tighten all assembly hardware. Ensure the bed is on a level surface.
- **Trundle Not Sliding Smoothly:** Check the trundle casters for any obstructions (e.g., carpet fibers, dust). Clean the casters and ensure they are properly aligned.
- **Missing Parts:** If you discover any missing parts during assembly, refer to the 'Package Contents' section and

contact Bellemave customer support for assistance.

8. Specifications

Feature	Detail
Model Number	MF642AAN
Size	Twin over Twin
Product Dimensions	78.1"L x 80.4"W x 62.3"H
Color	Silver
Material	Metal
Finish Type	Painted
Special Feature	Ladder & Safety Rails
Included Components	Ladder, Safety Rails
Compatible Mattress Size	Twin
Recommended Mattress Thickness (Upper)	6 inches
Recommended Mattress Thickness (Bottom)	8 inches
Assembly Required	Yes
UPC	788634288253

9. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact Bellemave directly. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08SM1H8HB

More documents and user manuals: **https://manuals.plus/**