Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hasbro FurReal F1927

Hasbro Furreal Friends Fuzzalots Rabbit F1927 Instruction Manual

Model: F1927

Introduction

Welcome to the world of Furreal Friends Fuzzalots! This interactive pet rabbit is designed to provide engaging play with over 25 sounds and reactions. This manual provides essential information for setting up, operating, and maintaining your Fuzzalots Rabbit.



Image: The Furreal Friends Fuzzalots Rabbit toy displayed in its original packaging.



Image: The back of the product packaging, indicating 25+ sounds and reactions and care instructions.

Important Safety Information

- **Age Recommendation:** Suitable for ages 4 and up.
- **Choking Hazard:** Small parts. Not for children under 3 years.
- **Battery Safety:**
  - Requires 1 AA battery (included).
  - Always use fresh batteries of the required type.
  - Do not mix old and new batteries.
  - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
  - Remove exhausted batteries promptly.
  - Remove batteries if the product is not used for an extended period.
  - Dispose of batteries properly.

Package Contents

Ensure all items are present before beginning setup:

- 1 x Furreal Friends Fuzzalots Rabbit
- 1 x Feeding Accessory (Carrot Bottle)
- 1 x AA Battery (pre-installed)



Image: The Fuzzalots Rabbit toy shown alongside its carrot bottle accessory.

Setup

Battery Installation

Your Fuzzalots Rabbit comes with one AA battery pre-installed. If replacement is needed, follow these steps:

1. Locate the battery compartment on the underside of the toy.
2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Remove the old battery and insert a new 1.5V AA alkaline battery, ensuring correct polarity (+/-).

4. Replace the battery compartment cover and secure it with the screw.

The toy is now ready for use.

Operating Instructions

The Fuzzalots Rabbit responds to interaction with over 25 sounds and reactions. Its color-changing belly indicates its mood.

Interacting with Your Fuzzalots Rabbit

- **Petting:** Gently pet the Fuzzalots Rabbit on its head or back. It will respond with sounds and its belly will light up, indicating happiness or other moods.



Image: A hand gently petting the head of the Fuzzalots Rabbit.

- **Feeding:** Use the included carrot bottle accessory to feed your Fuzzalots Rabbit. Place the bottle near its mouth, and it will make feeding sounds and its belly will change color.



Image: The Fuzzalots Rabbit being fed with its orange carrot bottle accessory.

- **Mood Indication:** Observe the color of its belly. Different colors indicate different moods or needs. For example, a glowing belly might indicate happiness or a need for attention.



Image: The Fuzzalots Rabbit with its belly glowing purple, indicating an interactive response.

Maintenance

Cleaning Instructions

- Surface clean only. Do not immerse the toy in water.
- Use a soft, damp cloth to wipe away dirt.
- Do not use harsh chemicals or abrasive cleaners.
- Allow the toy to air dry completely before further use.

Storage

Store the Fuzzalots Rabbit in a cool, dry place away from direct sunlight when not in use for extended periods. Remove batteries if storing for several months.

Troubleshooting

Problem	Possible Cause	Solution
Toy does not respond.	Low or dead battery. Incorrect battery installation.	Replace with a fresh 1.5V AA alkaline battery, ensuring correct polarity.
Sounds are distorted or weak.	Low battery power.	Replace the battery.
Toy is not interacting as expected.	Interference from other electronic devices.	Move the toy away from other electronic devices. Try resetting the toy by removing and reinserting the battery.

Specifications

- **Model:** F1927
- **Brand:** FurReal (Hasbro)
- **Product Dimensions:** 7.94 x 13.97 x 12.7 cm (L x W x H)
- **Weight:** 168 grams
- **Material:** Plastic
- **Battery:** 1 x 1.5V AA Alkaline Battery (included)
- **Age Recommendation:** 4+ years
- **Features:** Interactive, 25+ sounds and reactions, color-changing belly.

Warranty and Support

For warranty information or customer support, please refer to the official Hasbro website or contact their customer service department. Specific warranty details may vary by region.
Online Support: Visit www.hasbro.com for product information and support resources.
Contact: Refer to the product packaging for regional contact information or visit the Hasbro website for details.

© 2021 Hasbro. All Rights Reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08SPD184C

More documents and user manuals: **https://manuals.plus/**