

[Manuals.plus](#) /

› [LALISU](#) /

› LALISU Industrial Adjustable Floor Lamp (Black) - User Manual

LALISU LALISUJOM-F720

LALISU Industrial Adjustable Floor Lamp (Black)

Model: LALISUJOM-F720

INTRODUCTION

Thank you for choosing the LALISU Industrial Adjustable Floor Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read it thoroughly before assembly and operation, and retain it for future reference.



Figure 1: LALISU Industrial Adjustable Floor Lamp in a bedroom setting.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions carefully before use.
- Do not operate the lamp with a damaged cord or plug. If damaged, contact customer support.
- Ensure the lamp is unplugged before cleaning, changing the bulb, or performing any maintenance.
- This lamp is designed for indoor use only. Do not expose to water or high humidity.
- Keep the lamp away from flammable materials.
- Ensure the base is stable and placed on a flat, level surface to prevent tipping.
- Use only E26 base LED bulbs with a maximum wattage of 12W.
- Do not attempt to modify the lamp in any way.

WHAT'S IN THE BOX

Carefully unpack all components and ensure you have the following:

- Lamp Head with integrated power cord
- Upper Pole Section
- Middle Pole Section(s) (quantity may vary for adjustable height)
- Lower Pole Section
- Heavy-Duty Base
- LED Bulb (E26, 9W, non-dimmable)
- User Manual (this document)

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing and simple assembly process of the LALISU Floor Lamp, showing the various components included.

SETUP AND ASSEMBLY

1. **Attach the Base:** Carefully thread the lower pole section into the heavy-duty base. Turn clockwise until securely tightened.
2. **Connect Pole Sections:** Thread the middle pole section(s) onto the lower pole section. Ensure the power cord passes through each section smoothly.
3. **Attach Lamp Head:** Thread the upper pole section (with the lamp head attached) onto the assembled pole. Gently pull any excess cord from the bottom of the base to ensure a snug fit.
4. **Install the Bulb:** Carefully screw the provided E26 LED bulb into the lamp head socket. Do not overtighten.
5. **Position the Lamp:** Place the assembled lamp on a stable, flat surface.
6. **Plug In:** Insert the power plug into a standard 110-130V AC outlet.

Upgrade Model

(Temperature LED Bulb)



Figure 2: Visual guide for assembling the lamp pole and base.

Your browser does not support the video tag.

Video 2: This video illustrates the assembly process, including connecting the pole sections and securing the base.

OPERATING INSTRUCTIONS

Turning On/Off

The LALISU Floor Lamp features a convenient rotary On/Off switch located on the lamp head. Simply twist the knob clockwise to turn the lamp on, and counter-clockwise to turn it off.



Figure 3: The rotary On/Off switch is located on the lamp head for easy access.

Adjusting Height

The lamp's height can be adjusted between 34.25 inches and 57.48 inches by adding or removing the middle pole sections during assembly. This allows you to customize the lamp's height to suit various spaces and needs.



FULLY ADJUSTABLE:
Adjust height between and
65" to accommodate
various spaces



Figure 4: The lamp's height can be adjusted by adding or removing pole sections.

Adjusting Lamp Head Angle

The lamp head can be swiveled 180 degrees, allowing you to direct light upwards, downwards, or to the side. This flexibility is ideal for task lighting, reading, or ambient illumination.



Figure 5: The lamp head offers 180-degree rotation for versatile lighting.

MAINTENANCE

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp. Avoid abrasive cleaners or solvents that may damage the finish.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely before attempting to replace it. Unscrew the old bulb and screw in a new E26 base LED bulb (max 12W).
- **Cord Care:** Regularly inspect the power cord for any signs of damage. Do not place heavy objects on the cord or run it under carpets.

Your browser does not support the video tag.

Video 3: This video demonstrates how to replace the light bulb in the LALISU Floor Lamp, highlighting the E26 base.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet.	Check if the outlet is working by plugging in another device. Check circuit breaker.
Lamp does not turn on.	Bulb is loose or faulty.	Ensure the bulb is screwed in tightly. Replace the bulb if it is burnt out.
Lamp flickers.	Loose bulb or connection.	Tighten the bulb. Check all pole connections for tightness.
Lamp is unstable.	Base not securely tightened or uneven surface.	Ensure the base is fully tightened to the pole. Place the lamp on a flat, stable surface.

SPECIFICATIONS

Feature	Detail
Model Number	LALISUJOM-F720
Product Dimensions	14.56"D x 8.26"W x 57.48"H
Item Weight	5.5 Pounds
Material Type	Metal
Finish Type	Coated+Plating
Color	Black
Bulb Base	E26
Light Source Type	LED
Wattage	9 watts (Max 12W)
Voltage	110-130V
Switch Type	Rotary On/Off
Indoor/Outdoor Use	Indoor Use Only
Special Features	Adjustable Height, Adjustable Lamp Head

WARRANTY INFORMATION

The LALISU Industrial Adjustable Floor Lamp comes with a **2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any issues with your LALISU Floor Lamp or have questions not covered in this manual, please contact our customer support team. We are committed to providing premium quality products and a good shopping experience. For assistance, please email us, and we will reply to you to solve the problem quickly and friendly.

Contact Information: Refer to your purchase documentation or the LALISU brand store on Amazon for the most up-to-date contact details.

© 2026 LALISU. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08SR68WFD>

More documents and user manuals: <https://manuals.plus/>