

Tefal H852SA55

TEFAL Nordica H852SA55 Cookware Set User Manual

Set of Steel pots with lid 10-Piece: Pot 18/20/24 cm, High Pot 22cm, Saucepan 16cm

1. INTRODUCTION

Thank you for choosing the TEFAL Nordica H852SA55 Cookware Set. This set is designed for durability and ease of use, crafted from high-quality 18/10 stainless steel with a thick induction bottom for optimal cooking performance. The thoughtful design, including lids with integrated straining holes, enhances your cooking experience.

Key features of your Nordica Cookware Set include:

- Made of premium 18/10 stainless steel for long-lasting durability.
- Thick Induction Bottom ensures even heat distribution and compatibility with induction cooktops.
- Patented double steel handles for secure grip and special lids with built-in straining holes for convenient draining.

2. SAFETY INSTRUCTIONS

- Always use oven mitts or pot holders when handling hot cookware, as handles can become hot during use.
- Do not leave cookware unattended on a hot stovetop.
- Ensure lids are properly seated to prevent steam burns.
- Avoid sudden temperature changes, such as placing a hot pot under cold water, as this can cause warping or damage.
- Keep children and pets away from the cooking area.
- This cookware set is not oven safe. Do not place in an oven.

3. SETUP

3.1. Unpacking and Initial Cleaning

Upon receiving your TEFAL Nordica Cookware Set, carefully remove all packaging materials. Wash all pots, pans, and lids thoroughly with warm, soapy water before first use. Rinse well and dry completely to prevent water spots.

3.2. Inspecting the Cookware

Before first use, inspect each piece for any signs of damage or manufacturing defects. If any issues are found, contact customer support immediately.

4. OPERATING INSTRUCTIONS

4.1. Heat Source Compatibility

Your TEFAL Nordica cookware is compatible with all stovetop types, including induction, gas, electric, and ceramic hobs. The thick induction bottom ensures efficient heat transfer.



Image: The base of a Nordica pot, highlighting its induction compatibility and Thermo-Fusion Integral technology for even heating.

4.2. Cooking with Your Pots and Pans

Always match the pot or pan size to the burner size to ensure efficient heating and prevent heat from damaging handles. Use low to medium heat settings for most cooking tasks. High heat should only be used for boiling water.



Image: A close-up view of the interior of a Nordica pot, showing the convenient measurement markings for precise cooking.

4.3. Using the Straining Lids

The Nordica lids feature two types of straining holes: small holes for draining fine ingredients like rice, and larger holes for pasta or vegetables. Simply align the desired straining holes with the pouring spout on the pot and tilt to drain liquid safely.



Image: A user demonstrating the innovative straining feature of the Nordica lid, allowing for easy and safe draining of liquids.

5. MAINTENANCE

5.1. Cleaning

This cookware set is dishwasher safe for convenient cleaning. For hand washing, use warm, soapy water and a soft sponge or cloth. Avoid abrasive cleaners, steel wool, or harsh scouring pads, as these can scratch the stainless steel surface.

For stubborn food residue, soak the pot or pan in warm, soapy water for a period before cleaning. A paste of baking soda and water can be used for gentle scrubbing of tough spots.

5.2. Storage

Store your cookware in a dry place. To prevent scratches when stacking, place a cloth or paper towel between pots and pans.



Image: The complete Tefal Nordica cookware set, showcasing its sleek design and how it can be stored.

6. TROUBLESHOOTING

- **Food Sticking:** Ensure you are using enough cooking oil or liquid. Preheat the pan properly before adding food.
- **Discoloration:** High heat or certain foods can sometimes cause blue or rainbow discoloration on stainless steel. This is harmless and can often be removed with a stainless steel cleaner or a mixture of vinegar and water.
- **Water Spots:** To prevent water spots, dry the cookware immediately after washing. For existing spots, a solution of vinegar and water can help.
- **Handles Getting Hot:** This is normal for stainless steel handles. Always use oven mitts or pot holders.

7. SPECIFICATIONS

Feature	Detail
Brand	Tefal
Model Number	H852SA55
Material	18/10 Stainless Steel
Color	Silver
Number of Pieces	10
Included Components	Pot 18cm, Pot 20cm, Pot 24cm, High Pot 22cm, Saucepan 16cm, and corresponding lids.
Handle Material	Stainless Steel

Induction Compatible	Yes
Dishwasher Safe	Yes
Oven Safe	No
Item Weight	9.5 Kilograms (20.9 pounds)
Product Dimensions	14.17 x 21.26 x 11.81 inches

8. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the documentation provided with your purchase or visit the official Tefal website. For customer support, inquiries, or to report any issues, please contact Tefal customer service through their official channels.

You can often find support contact information on the manufacturer's website or on the product packaging.
