

Nerf NER0288

Nerf Digital Flip Target Instruction Manual

Brand: Nerf | Model: NER0288

1. OVERVIEW

The Nerf Digital Flip Target is designed to enhance your blasting skills and provide engaging target practice. It features a digital scoreboard to track hits and bullseyes across multiple game modes, supporting both single-player training and multi-player competitions. The unique flipping targets provide dynamic feedback upon impact, making practice sessions more interactive and challenging.

Key Features:

- **Digital Scoreboard:** Tracks hits and bullseyes for accurate performance monitoring.
- **Multiple Game Modes:** Offers three distinct game modes for varied training and competitive play.
- **Single and Multiplayer Options:** Allows for solo practice or head-to-head challenges.
- **Flipping Targets:** Targets flip inward and outward upon impact, providing immediate visual confirmation of a hit.
- **Compatibility:** Fully compatible with all other Nerf ELITE equipment.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

Always use the product as intended. Do not modify the target or use it with projectiles other than those designed for Nerf blasters. Keep away from eyes and face. Adult supervision is recommended for younger users.

3. WHAT'S IN THE BOX

- 1 x Nerf Digital Flip Target (Model NER0288)
- Instruction Manual

Note: Blasters and darts are sold separately.

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment on the underside of the target base.
2. Using a Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. Insert 3 x 1.5V AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

4.2 Initial Placement

Place the Nerf Digital Flip Target on a flat, stable surface. Ensure there is adequate space around the target for safe play and to prevent damage to surrounding objects or persons from ricocheting darts.



Figure 1: Nerf Digital Flip Target in default position.

5. OPERATING INSTRUCTIONS

5.1 Powering On

Press the Power button located on the front of the target base. The digital display will illuminate, indicating the target is ready for use.

5.2 Selecting Game Modes

The Nerf Digital Flip Target offers three distinct game modes. Use the Mode button on the base to cycle through the available options. The selected mode will be displayed on the LCD screen.

- **Game Mode 1: Flip Out** - Targets flip inward when hit. Score points for each successful hit.
- **Game Mode 2: Reverse Flip** - Targets start flipped inward and flip outward when hit.
- **Game Mode 3: Ultimate Flip** - A dynamic mode combining elements of the other two, challenging players to hit targets as they reset.



Figure 2: Target with some panels flipped inward after being hit.



Figure 3: Target with all panels flipped inward, indicating successful hits.

5.3 Scoring and Gameplay

Once a game mode is selected, the central Nerf logo will light up, and a game clock will begin counting down. Hit the targets with your Nerf blasters to score points. The digital scoreboard will automatically track your score and bullseyes. Each target flips upon impact, providing clear visual feedback.

5.4 Target Reset

Depending on the game mode, targets will automatically reset or require manual resetting by hitting the opposite side. Refer to the specific game mode rules for details on target reset mechanics.

Your browser does not support the video tag.

Video 1: An overview of Nerf targets and accessories, demonstrating various target types and gameplay scenarios.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Nerf Digital Flip Target, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the target surface with a soft, dry cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** Store the target in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the target will not be used for an extended period to prevent leakage.

7. TROUBLESHOOTING

If you encounter any issues with your Nerf Digital Flip Target, please refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
Target does not power on.	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with fresh AAA batteries.
Targets do not flip when hit.	Insufficient force from dart, or mechanism jammed.	Ensure darts are fired with adequate force. Check for any obstructions in the flipping mechanism.
Digital display is not working correctly.	Low batteries or internal malfunction.	Replace batteries. If problem persists, contact customer support.

8. SPECIFICATIONS

Attribute	Detail
Model Number	NER0288
Brand	Nerf
Dimensions	13.5 x 3.25 x 16 inches
Item Weight	14.9 ounces (approx. 423 Grams)
Material	Plastic
Color	Blue and Orange
Power Source	3 x 1.5V AAA Batteries (not included)
Recommended Age	8 years and up
Release Date	December 15, 2021
Manufacturer	Jazwares

9. WARRANTY AND SUPPORT

This product is manufactured by Jazwares under license from Hasbro. For any warranty claims, technical support, or inquiries regarding your Nerf Digital Flip Target, please refer to the contact information provided on the product packaging or visit the official Nerf or Jazwares website for the most up-to-date support details.

Please retain your proof of purchase for warranty purposes.



[pdf]

Untitled 6597c34f0da19 web 2023 toys f erc distribution md upload uploaded files 391 |||
4 18 36 24 54 , 4 : Smart Koala. 8 : Twinkly . 18 ... ,5 ; ; ; . Nerf 180 / ERC Content /
2023 NERF DIGITAL FLIP TARGET : **NER0288** Nerf Elite , . Nerf Elite Digital Target .
, , ...
lang:de score:12 filesize: 37.6 M page_count: 248 document date: 2024-01-04

Item	ASIN	Item Desc	QTY	LPN	UNIT	RETAIL
1	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
2	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
3	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
4	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
5	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
6	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
7	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
8	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
9	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	
10	B0852PZ11F	NERF NER0288 - Aufblasbares Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren	1	LPNHK293809350	9,6...	

[pdf] User Manual

Amazon 11 Paul Rance Schneider Hier klicken um Artikelliste der Palette zu öffnen Retouren 16655917
Spielzeug Learning Sonstiges Black Forest Deals v 1725306183 cdn shopify s files 1 0730 0186 1462 |||
Pallet ID ASIN Item Desc QTY LPN UNIT RETAIL 16655917 B0CSVJN69L Magic:
The Gathering Modern Ho ... tngngiges Handling, leuch1teLnPdNeRFPa0rb1e8n7-
81d6er6O9 riginal C9u,6b2e 16655917 B0852PZ11F NERF **NER0288** - Aufblasbares
Ziel, 1,20 m hohes 3-Zonen-Ziel, Spielzeug ab 8 Jahren 1 LPNHK293809350 9,6...
lang:it score:10 filesize: 115.1 K page_count: 6 document date: 2024-09-02