

Jensen RBTTX10

Jensen Portable Wireless Audio Transmitter & Receiver User Manual

Model: RBTTX10

1. INTRODUCTION

The Jensen RBTTX10 is a versatile portable wireless audio transmitter and receiver designed to add Bluetooth connectivity to a wide range of audio devices. This device allows you to either transmit audio wirelessly from non-Bluetooth sources to Bluetooth-enabled headphones or speakers, or receive audio wirelessly from Bluetooth-enabled devices to non-Bluetooth audio systems.

With a range of up to 32 feet and a built-in rechargeable battery providing up to 13 hours of playback, the RBTTX10 offers flexible audio solutions for your home, car, or portable entertainment needs.



Image: The Jensen RBTTX10 unit, a compact black rectangular device with a power button on top and an audio jack and TX/RX switch on one end.

2. KEY FEATURES

- **Dual Functionality:** Operates as both a Bluetooth audio transmitter (TX) and receiver (RX).
- **Wide Compatibility:** Connects to TVs, sound systems, car audio, Nintendo Switch, and other devices via AUX input/output.
- **Bluetooth Connectivity:** Enables wireless audio streaming with a range of up to 32 feet.
- **Extended Playback:** Up to 13 hours of continuous audio playback on a single charge.
- **Rechargeable Battery:** Built-in battery allows for portable use and continuous streaming while charging.
- **Low Latency:** Designed for real-time, high-quality audio streaming with minimal lag.



Image: The Jensen RBTTX10 unit shown alongside icons indicating its 13-hour playtime, compatibility with TV/sound systems, and 32-foot Bluetooth range.

Receiver Mode

Add Bluetooth functionality to your non-Bluetooth device




Image: The Jensen RBTTX10 connected to a home audio receiver, demonstrating its use for real-time audio with low latency, with a television displaying a basketball game in the background.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Jensen RBTTX10 Wireless Audio Transmitter & Receiver Unit
- Micro-USB Charging Cable
- AUX Cable (3.5mm audio cable)
- User Manual (this document)

4. DEVICE LAYOUT



Image: A close-up side view of the Jensen RBTTX10, highlighting the 3.5mm audio jack and the TX/RX mode switch.



Image: A close-up side view of the Jensen RBTTX10, showing the micro-USB charging port and three small indicator lights. Familiarize yourself with the device's ports and controls:

- **Power Button:** Located on the top surface, used to turn the device on/off and for pairing.
- **TX/RX Switch:** Located on one end, used to select Transmitter (TX) or Receiver (RX) mode.
- **3.5mm Audio Jack:** For connecting to audio sources or output devices via the AUX cable.
- **Micro-USB Port:** For charging the device using the provided micro-USB cable.
- **LED Indicators:** Small lights indicating power, charging status, and Bluetooth pairing status.

5. CHARGING THE DEVICE

Before first use, fully charge the RBTTX10. The device can also stream audio while charging.

1. Connect the supplied micro-USB charging cable to the micro-USB port on the RBTTX10.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, off or blue for fully charged, refer to specific LED behavior in the full manual if available).
4. A full charge typically takes approximately 2-3 hours and provides up to 13 hours of playback.

6. OPERATING MODES

6.1. Transmitter Mode (TX)

In Transmitter (TX) mode, the RBTTX10 sends audio from a non-Bluetooth device (e.g., TV, MP3 player, computer) to Bluetooth-enabled headphones or speakers.

1. Set the TX/RX switch on the RBTTX10 to the **TX** position.
2. Connect one end of the 3.5mm AUX cable to the RBTTX10's audio jack.
3. Connect the other end of the AUX cable to the audio output (e.g., headphone jack, AUX out) of your non-

Bluetooth device (e.g., TV, computer, MP3/MP4 player).

4. Turn on the RBTTX10 by pressing and holding the power button until the LED indicator flashes, indicating pairing mode.
5. Place your Bluetooth headphones or speakers in pairing mode.
6. The RBTTX10 will automatically search for and connect to nearby Bluetooth audio devices. Once connected, the LED indicator will change (e.g., solid blue).
7. Play audio on your non-Bluetooth device, and it will be transmitted wirelessly to your Bluetooth headphones or speakers.

Transmitter Mode

Transform a non-Bluetooth device into a Bluetooth transmitter




Image: A diagram illustrating the Transmitter Mode (TX) setup, showing the Jensen RBTTX10 connected via AUX cable to a TV, MP3/MP4 player, or computer, and wirelessly transmitting audio to Bluetooth headphones or speakers.

6.2. Receiver Mode (RX)

In Receiver (RX) mode, the RBTTX10 receives audio wirelessly from a Bluetooth-enabled device (e.g., smartphone, tablet, gaming console) and outputs it to a non-Bluetooth audio system (e.g., wired headphones, wired speakers, car AUX input).

1. Set the TX/RX switch on the RBTTX10 to the **RX** position.

2. Connect one end of the 3.5mm AUX cable to the RBTTX10's audio jack.
3. Connect the other end of the AUX cable to the audio input (e.g., AUX in) of your non-Bluetooth audio system (e.g., wired headphones, wired speakers, car stereo).
4. Turn on the RBTTX10 by pressing and holding the power button until the LED indicator flashes, indicating pairing mode.
5. On your Bluetooth-enabled device (e.g., smartphone), go to Bluetooth settings and search for "RBTTX10" (or similar device name). Select it to pair.
6. Once paired, the LED indicator on the RBTTX10 will change (e.g., solid blue).
7. Play audio on your Bluetooth-enabled device, and it will be received by the RBTTX10 and outputted to your connected audio system.



REAL-TIME AUDIO WITH LOW LATENCY

Image: A diagram illustrating the Receiver Mode (RX) setup, showing a phone, gaming console, or tablet wirelessly transmitting audio to the Jensen RBTTX10, which is then connected via AUX cable to wired earphones or wired speakers.

7. SPECIFICATIONS

Feature	Specification
Model Number	RBTTX10
Product Dimensions	4 x 6.1 x 1.1 inches
Item Weight	0.704 ounces (0.02 Kilograms)
Connectivity Technology	Auxiliary, Bluetooth, USB
Bluetooth Range	Up to 32 feet
Battery Life	Up to 13 hours playback
Battery Type	1 Lithium Ion battery (required)
Audio Output Mode	Stereo
Color	Black
Manufacturer	Voxx Accessories Corp.

8. TROUBLESHOOTING

If you encounter issues with your Jensen RBTTX10, please refer to the following common solutions:

Problem	Possible Solution
Device does not turn on.	Ensure the device is fully charged. Connect it to a power source using the micro-USB cable.
Cannot pair with a Bluetooth device.	<ul style="list-style-type: none">◦ Ensure the RBTTX10 is in the correct mode (TX for transmitting, RX for receiving).◦ Make sure both devices are in pairing mode and within the 32-foot range.◦ Turn both devices off and on again.◦ Clear previous Bluetooth connections on your source device if necessary.
No audio output/input.	<ul style="list-style-type: none">◦ Check that the 3.5mm AUX cable is securely connected to both the RBTTX10 and the audio source/output device.◦ Verify the volume levels on both the RBTTX10 (if applicable) and the connected audio devices.◦ Ensure the correct input/output is selected on your external audio system.
Audio quality is poor or intermittent.	<ul style="list-style-type: none">◦ Reduce the distance between the RBTTX10 and the paired Bluetooth device.◦ Remove any obstacles (walls, large metal objects) that may interfere with the Bluetooth signal.◦ Ensure there are no other strong wireless signals nearby causing interference.

9. SAFETY INFORMATION

Please read and follow these safety guidelines to ensure safe operation of your device:

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.

- Do not disassemble, repair, or modify the device yourself. Refer all servicing to qualified personnel.
- Keep the device away from water and other liquids.
- Use only the provided charging cable.
- Dispose of the device and its battery responsibly according to local regulations.

10. WARRANTY AND SUPPORT




For warranty information and technical support, please refer to the official Jensen website or contact their customer service directly. Keep your purchase receipt as proof of purchase.


You can visit the Jensen Store on Amazon for more information:[Jensen Store](#)




© 2024 Jensen. All rights reserved.

Related Documents

 <p>17.74x10.15x2.55in</p>	<p>Jensen RBTTX10 Wireless Audio Transmitter & Receiver - High-Quality Audio Streaming</p> <p>Jensen RBTTX10 is a wireless audio transmitter and receiver designed for high-quality, real-time audio streaming. It supports Bluetooth connectivity for both transmitting audio from non-Bluetooth devices and receiving audio on wired speakers or headphones. Features include a 32-foot range and 13-hour playtime.</p>
 <p>CMN86 6.8" 2 DIN CAPACITIVE TOUCH SCREEN MULTIMEDIA MECHLESS RECEIVER</p> <p>AM/FM/RS with Navigation USB Multimedia Player Front & Rear Camera Inputs</p> <p>INSTALLATION & OWNER'S MANUAL</p> <p>Bluetooth</p> <p>JENSEN</p>	<p>JENSEN CMN86 Installation and Owner's Manual: Features, Setup, and Operation</p> <p>Comprehensive installation and owner's manual for the JENSEN CMN86 6.8-inch 2 DIN multimedia mechless receiver. Learn about navigation, Bluetooth, camera inputs, and system operation.</p>
 <p>CM701MIR 7" TOUCH SCREEN MULTIMEDIA MECHLESS RECEIVER</p> <p>AM/FM Bluetooth USB Mirroring Front & Rear Camera Input</p> <p>INSTALLATION & OWNER'S MANUAL</p> <p>Bluetooth</p> <p>JENSEN</p>	<p>Jensen CM701MIR 7" Multimedia Mechless Receiver: Installation & Owner's Manual</p> <p>Comprehensive guide for the Jensen CM701MIR 7-inch touchscreen multimedia mechless receiver. Covers installation, operation, features like Bluetooth, USB mirroring, camera inputs, audio settings, troubleshooting, and warranty.</p>

	<p>Jensen VX7022 Operation Manual - 6.2" Multimedia Receiver</p> <p>Comprehensive operation manual for the Jensen VX7022 Double DIN Multimedia Receiver. Discover features like DVD/CD playback, SiriusXM Ready, Bluetooth, iPod/iPhone integration, Pandora, built-in navigation, and smartphone connectivity via HDMI/MHL. Includes setup, controls, troubleshooting, and specifications.</p>
--	---


Documents - Jensen – RBTTX10



[\[pdf\]](#) User Manual Quick Start Guide Guide Accessories Diagram

User Manual Voxx Accessories Corp RBTTX10 Wirless Audio Transmitter Receiver VIXRBTTX10 rbttx10 wireless audio transmitter receiver quick start guide Get ready for the ultimate flexibility with ... to your Bluetooth speaker or headphone. 5. On your phone, tablet, or gaming system, choose Jensen **RBTTX10** from the list of available Bluetooth connections. In a few seconds the transmitter/ receive...


lang:en score:37 filesize: 3.43 M page_count: 18 document date: 2020-11-06



[\[pdf\]](#) Quick Start Guide Guide Diagram

RBTTX10 QS Index of docs common rcaudiovideo ||| wireless audio transmitter receiver quick start guide Get ready for the ultimate flexibility with ... to your Bluetooth speaker or headphone. 5. On your phone, tablet, or gaming system, choose Jensen **RBTTX10** from the list of available Bluetooth connections. In a few seconds the transmitter/ receive...

lang:en score:30 filesize: 3.33 M page_count: 16 document date: 2020-10-02



[VOXX Accessories CES 2021 Product Guide](#)

Explore the comprehensive 2021 product catalog from VOXX Accessories, featuring UVC sanitizers, SINGSATION karaoke, RCA antennas, clocks, remotes, wall mounts, audio, connectivity, and more.

lang:en score:29 filesize: 17.73 M page_count: 148 document date: 2020-12-17

[\[pdf\] Instructions](#)

Important Information Ecology Product Make sure to read this entire manual< b> • Do not use product for anything other than its intended 4 Keep away from heat sources and direct sunlight 6 expose extremely high or low temperatures Use it in an ambient temperature between 32°F (0°C) 95°F (35°C)

RBTTX10_WC rcaudiovideo docs common RBTTX10 Jensen RISK OF ELECTRIC SHOCK Aucune pièce réparable par l'utilisateur ne se DO NOT OPEN CAUTION Caution: To reduce the risk of electric shock do remove cover (or back) RBTTX10_SAFETY_INS

Important Information for Jensen **RBTTX10** CAUTION RISK OF ELECTRIC SHOCK. DO NOT OPEN. Caution: To reduce the risk of electric shock, do not remove cover or back . No user serviceable parts inside. Refer servicing to qualified service personnel. Important Safety Instructions Failure to follow the...

lang:en score:27 filesize: 102.38 K page_count: 2 document date: 2020-10-13

