LeCuag 738631326465

LeCuag Dual Ionic Detox Foot Machine User Manual

Model: 738631326465

1. Product Overview

The LeCuag Dual Ionic Detox Foot Machine is designed to facilitate a foot soaking spa experience for up to two individuals simultaneously. This system incorporates ionic technology and features an integrated MP3 player for enhanced relaxation during use.



Image 1.1: The LeCuag Dual Ionic Detox Foot Machine with included accessories, including two arrays, two wrist straps, and two earphones.

Key Features:

- Dual user system for simultaneous operation.
- 30-minute programmed operation with 5 selectable modes.
- Integrated MP3 player for personalized audio during sessions.
- Wrist straps for grounding and static-free operation.
- Fused protection against high instant current.

2. Package Contents

Upon unpacking, please verify that all the following items are included in your 7-piece set:

- 1 x LeCuag Dual Ionic Detox Foot Spa Machine

- 2 x Arrays
- 2 x Earphones
- 2 x Wrist Straps

3. Safety Information

Important: Read all safety instructions before use.

- Always wear the wrist straps during operation to ensure proper grounding and prevent static discharge.
- The machine is equipped with fused protection to safeguard against high instant current. Do not attempt to bypass or modify this safety feature.
- This device is not intended to diagnose, treat, cure, or prevent any disease or health condition. Consult a healthcare professional for any health concerns.
- Keep the device away from water sources when not in use.
- Ensure the power cord is not damaged and is properly connected to a suitable power outlet.
- Do not operate the machine if it appears damaged or is not functioning correctly.

4. Setup Guide

Follow these steps to set up your LeCuag Dual Ionic Detox Foot Machine:

1. **Prepare the Foot Basin:** Fill a foot basin (not included) with warm water. The machine does not heat water, so ensure the water is at a comfortable temperature.
2. **Add Salt:** Add approximately 0.1g of salt to the water in the foot basin and mix thoroughly. This helps improve conductivity.
3. **Connect the Array:** Plug one or both arrays into the "ARRAY" ports on the front of the machine. Place the arrays into the water in the foot basin(s).
4. **Connect Wrist Straps:** Attach the wrist straps to the "Wrist strap" ports. Ensure the metal plate on the wrist strap makes direct contact with your skin when worn.
5. **Connect Earphones (Optional):** If desired, plug the earphones into the "Earphone" ports for audio playback.
6. **Power Connection:** Connect the power cord to the "ELETREAL SOKET" on the back of the machine and then to a power outlet.



Image 4.1: Visual guide demonstrating the connection of salt, wrist band, array, MP3, power, and feet placement for the foot spa.

5. Operating Instructions

Once the machine is set up, follow these steps to begin your foot spa session:

1. **Turn On:** Press the "ON/OFF" button located on the back of the machine to power it on.
2. **Wear Wrist Straps:** Ensure both users wear their wrist straps with the metal plate in direct contact with their wrist.
3. **Place Feet in Water:** Submerge your feet into the prepared foot basin(s) with the arrays.
4. **Select Mode:** The machine offers 5 modes for different detox needs. Use the control panel to select your desired mode. The display will show salinity, "A" or "B" mode, and time.
5. **Start Session:** Press the "ON/OFF" button on the control panel to start the "A" and "B" foot spa sessions. The default session duration is 30 minutes.
6. **MP3 Player Operation:**
    - To play/stop music, press the "STOP/PLAY" button.
    - To skip to the next song, press the "NEXT SONG" button.
    - You can download your favorite music to the device via the USB port.
7. **End Session:** The machine will automatically stop after 30 minutes. You can also manually stop the session by pressing the "STOP/PLAY" button.



Image 5.1: Detailed view of the control panel, indicating displays for salinity, mode, and time, along with buttons for mode selection, power, and MP3 control. Also shows the rear panel with cooling hole, ON/OFF switch, fuse, electrical socket, and USB port.



Image 5.2: An illustration of two users enjoying a foot spa session with the LeCuag Dual Ionic Detox Foot Machine, demonstrating its dual functionality.

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your device:

- **Cleaning the Arrays:** After each use, clean the arrays thoroughly with water and a brush to remove any residue. Ensure they are completely dry before storage.
- **Cleaning the Machine:** Wipe the main unit with a soft, damp cloth. Do not use abrasive cleaners or submerge the unit in water.
- **Storage:** Store the machine and its components in a cool, dry place away from direct sunlight and extreme temperatures.
- **Fuse Replacement:** If the machine does not turn on, check the fuse located on the back panel. Replace it with a fuse of the same specification if it is broken.

7. Troubleshooting

Refer to the following table for common issues and their solutions:




Image 7.1: A troubleshooting guide detailing common issues such as flickering "A-TIME" indicator, "0.0" amperage reading, and the appliance not turning on, along with their possible causes and solutions.

Issue	**Possible Cause(s)**	**Solution(s)**
"A-TIME" indicator is flickering	No circuit.	Ensure the steel plate on the wrist strap contacts your wrist directly. Make sure your feet are placed in the water.
Value of 0.0 shows up on the "Amperage" indicator but the "A-TIME" indicator doesn't flicker.	Array is broken.	Replace with another array.
The appliance doesn't turn on even when connected to power.	The fuse is broken.	Change the fuse. The fuse slot is on the back of the appliance.

8. Specifications

- **Model Number:** 738631326465
- **Product Dimensions:** 17 x 15 x 6 inches
- **Item Weight:** 8.38 Pounds
- **Power Source:** Corded Electric
- **Material:** Acrylonitrile Butadiene Styrene, Metal
- **Manufacturer:** LeCuag



Image 8.1: The LeCuag Dual Ionic Detox Foot Machine with key dimensions highlighted: 15.7 inches length, 10.6 inches width, and 4 inches height.

9. Customer Support

For any questions, concerns, or assistance with your LeCuag Dual Ionic Detox Foot Machine, please contact LeCuag customer support directly. Refer to the product packaging or the seller's information for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question