

Nerf F09582210

Nerf Ultra Select Fully Motorized Blaster User Manual

MODEL: F09582210

Product Overview

The Nerf Ultra Select Fully Motorized Blaster offers versatile dart firing for both distance and accuracy. This blaster is designed for high-performance play, featuring a unique dual-clip system that allows users to switch between different dart types during battle. It is a fully motorized blaster, providing rapid-fire action for an engaging experience.



Image: The Nerf Ultra Select Blaster, showcasing its design, included clips, and darts, alongside its product packaging.

Safety Information

WARNING: Do not aim at eyes or face. Use of eyewear recommended for players and people within range. Use only official Nerf darts. Other darts may not meet safety standards. Do not modify darts or blaster.

WARNING: CHOKING HAZARD - Small parts may be generated. Not for children under 3 years.

What's in the Box

- Nerf Ultra Select Blaster
- 2 x 10-dart clips
- 10 Nerf Ultra distance darts
- 10 Nerf Ultra accuracy darts
- Instructions manual



Image: Contents of the Nerf Ultra Select package, including the blaster, two dart clips, and the two distinct types of Nerf Ultra darts.

Setup

1. **Battery Installation:** The blaster requires 6x 1.5V C batteries (not included). Locate the battery compartment, typically on the side or bottom of the blaster. Use a Phillips head screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the compartment.
2. **Loading Darts:** The Nerf Ultra Select comes with two types of darts: 10 Nerf Ultra distance darts (black) and 10 Nerf Ultra accuracy darts (white with red tips). Load 10 darts of one type into each of the two included 10-dart clips. Ensure darts are fully seated in the clips.
3. **Inserting Clips:** Insert the loaded clips into the designated slots on the blaster. The blaster is designed to hold both clips simultaneously.

Operating Instructions

1. **Powering On:** Hold down the acceleration button (usually located on the grip) to power up the blaster's motor. You will hear the motor whirring, indicating it is ready to fire.
2. **Selecting Dart Type:** The blaster features a selector switch, typically located near the clip area, which allows you to choose which loaded clip you want to fire from. Move the switch to align with the clip containing your desired dart type (distance or accuracy).

3. **Firing Darts:** While holding down the acceleration button, press the trigger to fire darts. The blaster is fully motorized and will rapid-fire darts as long as the trigger is held and darts are available in the selected clip.
4. **Reloading During Play:** The clips are designed to allow for dart loading even while they are attached to the blaster, minimizing downtime during intense play.



Image: A user demonstrating the aiming posture with the Nerf Ultra Select Blaster in an outdoor setting.



Image: A close-up view of a person holding the Nerf Ultra Select Blaster, highlighting the grip and trigger area.

Maintenance

- **Cleaning:** Wipe the blaster clean with a damp cloth. Do not submerge the blaster in water or use harsh chemicals.
- **Dart Care:** Keep darts clean and dry. Avoid bending or damaging darts, as this can affect performance and accuracy. Replace worn or damaged darts with official Nerf Ultra darts.
- **Battery Storage:** If the blaster will not be used for an extended period, remove the batteries to prevent leakage and corrosion.

Troubleshooting

- **Blaster Not Firing:**
 - Ensure fresh batteries are correctly installed.
 - Check if the acceleration button is fully pressed and held down.
 - Verify that a loaded clip is properly inserted and the selector switch is aligned with the active clip.
 - Check for any dart jams in the firing mechanism. Clear any obstructions carefully.
- **Darts Not Flying Far/Accurately:**
 - Ensure you are using official Nerf Ultra darts.
 - Check darts for damage or wear; replace if necessary.
 - Confirm the correct dart type is selected for your desired performance (distance darts for range, accuracy darts for precision).

Specifications







Product Dimensions	28 x 3.1 x 12 inches
Item Weight	14.4 ounces
Item Model Number	F09582210
Manufacturer Recommended Age	8 years and up
Batteries Required	6 C batteries (not included)
Release Date	August 1, 2021
Manufacturer	Hasbro

Warranty and Support

For any product inquiries, technical support, or warranty information, please contact Hasbro customer service directly. Refer to the packaging or the official Nerf website for the most current contact details and warranty policies.

© 2023 Nerf. All rights reserved.

Related Documents - F09582210

	NERF ULTRA DORADO Blaster: Instructions and Safety Guide Official instructions for the NERF ULTRA DORADO blaster, including loading, firing, safety warnings, and troubleshooting. Learn how to use your NERF ULTRA DORADO safely and effectively.
	Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.
	Nerf Roblox Arsenal Pulse Laser Blaster Instructions Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.
	Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.
	Nerf Pro Stryfe X Dart Blaster: User Manual and Safety Instructions Comprehensive guide to operating the Nerf Pro Stryfe X Dart Blaster, including charging, loading, firing, safety warnings, and storage. Features detailed instructions for safe play and regulatory information.
	Nerf N-Strike Elite Strongarm Blaster: User Guide Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.