

SADES EK-10

SADES EK-10 Wired Gaming Keyboard and Mouse User Manual

Brand: SADES | Model: EK-10

1. INTRODUCTION

This manual provides detailed instructions for the SADES EK-10 Wired Gaming Keyboard and Mouse combo. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. Please read this manual thoroughly before using the product.



Image: The SADES EK-10 Pink Wired Gaming Keyboard, showcasing its full layout and LED backlighting.

Key Features:

- **Practical & Ergonomic Design:** Metal surface keyboard for stability and ergonomic design for comfortable, long-term use.
- **Colorful Backlights:** 7-color LED backlighting with adjustable brightness and breathing modes for enhanced visibility and ambiance.
- **104-Key Standard Layout:** Full-size keyboard with membrane switches, 11 multimedia keys, non-slip, and splash-

proof design. Detachable suspended keycaps for easy cleaning.

- **Precision Mouse Control:** 4 adjustable DPI settings (800 / 1200 / 2400 / 3200) with a DPI switch indicator, 6 buttons, and an ultra-precise scroll wheel.
- **Wide Compatibility:** Plug-and-play functionality with USB 2.0, compatible with Windows Vista/7/8/10, MAC, and Linux operating systems.

2. SETUP

2.1 Package Contents


- SADES EK-10 Wired Gaming Keyboard
- SADES Gaming Mouse (included as part of the combo)
- USB Cable (integrated)

2.2 System Requirements


- Operating System: Windows Vista/7/8/10, MAC, Linux, Win XP, Win 2000
- Available USB 2.0 Port

2.3 Connecting the Device

1. Locate an available USB 2.0 port on your computer.
2. Plug the USB connector from the SADES EK-10 Keyboard and Mouse into the USB port.
3. The device is plug-and-play; no additional drivers are typically required. Your operating system should automatically detect and install the necessary drivers.



Data line



Comfort button



Rubber pad

Image: The SADES EK-10 keyboard highlighting its integrated data line, comfort button, and rubber pads for stability.

WIDELY COMPATIBLE & EASY TO USE



Compatible with Windows XP / Windows VISTA
Windows 7 / Windows 8 / Windows ME / Windows 10

Image: The SADES EK-10 keyboard shown with various Windows operating system logos, illustrating its wide compatibility.

3. OPERATING INSTRUCTIONS

3.1 Keyboard Functions

The SADES EK-10 keyboard features a full 104-key layout with multimedia functions accessible via the 'FN' key.

Description & Specification Special Function:



FN+F1	music player	FN+F7	play/pause
FN+F2	volume-	FN+F8	next one
FN+F3	volume+	FN+F9	Email
FN+F4	mute	FN+F10	web
FN+F5	Music stop	FN+F11	Lock
FN+F6	previous one	FN+F12	Calculator

- FN + LED = Open LED breathing mode
- FN + "Pg Up +" = Control the LED breathing brightness +
- FN + "Pg Up -" = Control the LED breathing brightness -

(The lowest level effect is equivalent to "Turn off" the backlight)

Image: A close-up of the SADES EK-10 keyboard, detailing the layout and the various functions accessible by pressing the 'FN' key in combination with other keys.

Multimedia and Shortcut Keys (FN + Function Key):

- **FN + F1:** Media Player
- **FN + F2:** Volume Down
- **FN + F3:** Volume Up
- **FN + F4:** Mute
- **FN + F5:** CD Stop
- **FN + F6:** Previous Track
- **FN + F7:** Play/Pause
- **FN + F8:** Next Track
- **FN + F9:** Email
- **FN + F10:** Web Browser/Home

- **FN + F11:** Lock (Keyboard)
- **FN + F12:** Calculator

Backlight Control:

- **FN + LED:** Toggles LED breathing mode on/off.
- **FN + Pg Up (+):** Increases LED breathing brightness.
- **FN + Pg Dn (-):** Decreases LED breathing brightness. (The lowest setting is equivalent to turning the backlight off).
- **FN + ESC:** Toggles backlight on/off (for fixed backlight mode).

Bright RGB Backlighting Orange RGB Light Wired Film

FN + PRT SC



Image: The SADES EK-10 keyboard showcasing its bright RGB backlighting. The image also highlights the 'FN + PRT SC' key combination, which may be used for backlight mode adjustments.

3.2 Mouse Functions

The accompanying gaming mouse offers precision control with adjustable DPI settings.

DPI Adjustment:

- The mouse features 4 adjustable DPI settings: 800 / 1200 / 2400 / 3200.
- Use the dedicated DPI switch button (typically located near the scroll wheel) to cycle through the DPI settings.
- A flashing indicator function will confirm the current DPI level.


4. MAINTENANCE

4.1 Cleaning the Keyboard

The SADES EK-10 keyboard is designed with suspended, detachable keycaps for easy cleaning.

1. Unplug the keyboard from your computer before cleaning.
2. Gently pull up on the keycaps to remove them.
3. Use a soft brush, compressed air, or a damp cloth to clean dust and debris from the keyboard base and keycaps.
4. Ensure all parts are completely dry before reattaching the keycaps and plugging the keyboard back in.

| 104-Keys Standard Keyboard |



Ergonomic Arc keycap, comfortable feeling, and anti-fatigue.

Image: A diagram showing the ergonomic arc design of the keycaps, contributing to comfortable typing and reduced fatigue.

5. TROUBLESHOOTING

Common Issues and Solutions:

- **Device not recognized:** Ensure the USB cable is securely plugged into a functional USB 2.0 port. Try a different USB port or restart your computer.
- **Backlight not working:** Check if the backlight is turned off using FN + LED or FN + ESC. Adjust brightness using FN + Pg Up (+) or FN + Pg Dn (-).
- **Keys not responding:** Unplug and replug the keyboard. Ensure no debris is lodged under the keycaps.
- **Mouse cursor erratic or unresponsive:** Ensure the mouse is on a clean, flat surface. Check the USB connection. Adjust DPI settings if sensitivity is an issue.

6. SPECIFICATIONS

Feature	Detail
Brand	SADES
Model	EK-10
Connectivity Technology	USB 2.0 (Wired)
Keyboard Layout	104-Key Standard
Keyboard Backlighting	7 Colors LED, Breathing Effect, Adjustable Brightness
Keyboard Material	Metal Surface
Mouse DPI Settings	800 / 1200 / 2400 / 3200
Compatible Devices	PC, Laptop
Operating System Support	Windows Vista/7/8/10, MAC, Linux, Win XP, Win 2000
Item Weight	1.9 pounds (Keyboard)
Package Dimensions	21 x 8 x 2 inches

7. WARRANTY AND SUPPORT

SADES products are designed for reliability and performance. For specific warranty information and technical support, please refer to the warranty card included with your product or visit the official SADES website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08T17HWLX>

More documents and user manuals: <https://manuals.plus/>