

[Manuals.plus](#) /

› [IKEA](#) /

› IKEA ADDE Chair Instruction Manual

IKEA ADDE

IKEA ADDE Chair Instruction Manual

Model: ADDE

1. INTRODUCTION

Thank you for choosing the IKEA ADDE Chair. This manual provides essential information for the safe assembly, use, and maintenance of your new chair. Please read these instructions carefully before beginning assembly and retain them for future reference.

The IKEA ADDE chair is designed for indoor use, offering a practical and stackable seating solution. It features a durable construction suitable for various settings.



Image: Two black IKEA ADDE chairs, highlighting their simple and functional design.

2. SAFETY INFORMATION

- **Maximum Load Capacity:** The IKEA ADDE chair is designed to support a maximum weight of 150 kg (330 lbs). Do not exceed this weight limit to prevent damage or injury.
- **Indoor Use Only:** This chair is intended for indoor use. Exposure to outdoor elements may compromise its structural integrity and appearance.
- **Regular Maintenance:** For maximum quality and safety, regularly check and re-tighten all screws and fittings. Loose connections can lead to instability.
- **Proper Assembly:** Ensure all components are correctly assembled according to the instructions to guarantee stability and safety.

3. PACKAGE CONTENTS

Before assembly, verify that all parts are present. The package for one IKEA ADDE chair typically includes:

- Chair seat and backrest (integrated unit)
- Leg frame components
- Assembly hardware (screws, washers, nuts if applicable)
- Assembly tool (often an Allen key, but a Phillips screwdriver may also be required)

If any parts are missing or damaged, please contact IKEA customer service.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your IKEA ADDE chair. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

Tools Required:

- Phillips head screwdriver (not always included)
- Allen key (usually included with hardware)

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Check against the package contents list.
2. **Attach Leg Frame:** Connect the leg frame components to the underside of the chair seat using the provided screws and the Allen key. Ensure all connections are aligned before tightening.
3. **Secure All Fasteners:** Once all parts are loosely connected, gradually tighten all screws until they are firm. Do not overtighten.
4. **Final Check:** Gently shake the chair to ensure it is stable. If any wobbling occurs, re-check all connections and tighten as necessary.





Image: An assembled IKEA ADDE chair, illustrating the final product after setup.

5. OPERATING INSTRUCTIONS

The IKEA ADDE chair is designed for straightforward use.

- **Sitting:** Use the chair for seating purposes, ensuring your weight does not exceed the maximum load capacity of 150 kg.
- **Stacking:** To save space, multiple ADDE chairs can be stacked. Lift one chair and carefully place it onto another, aligning the legs and seats. This feature is ideal for storage or when extra space is needed.



Image: An IKEA ADDE chair in a room setting, demonstrating its practical application.

6. MAINTENANCE

Proper care will extend the life and maintain the appearance of your IKEA ADDE chair.

- **Cleaning:** Wipe the chair dry with a clean cloth. For more thorough cleaning, use a mild soapy solution. Avoid abrasive cleaners or harsh chemicals, as these can damage the plastic and metal finishes.
- **Screw Tightening:** Periodically (e.g., every 3-6 months), re-tighten all assembly screws to ensure the chair remains stable and secure.
- **Storage:** When not in use, stack the chairs to save space. Store in a dry, indoor environment.



Image: Detail of the chair's seat and backrest, showing the polypropylene plastic material and perforated design.

7. TROUBLESHOOTING

If you encounter any issues with your IKEA ADDE chair, refer to the following common solutions:

- **Chair is Wobbly:**
 - Ensure all screws are fully tightened.
 - Verify that the chair is on a flat, even surface.
 - Re-assemble if necessary, paying close attention to alignment.
- **Difficulty Stacking:**
 - Ensure chairs are oriented correctly for stacking.
 - Check for any obstructions or damage to the chair legs or seat that might prevent proper stacking.

8. SPECIFICATIONS

Feature	Detail
Model Name	ADDE
Brand	IKEA
Material	Polypropylene plastic, Steel (Epoxy/polyester powder coating)
Color	Black
Maximum Load	150 kg (330 lbs)
Product Care	Wipe dry with a clean cloth; clean with mild soapy solution.
Usage	Indoor
Features	Stackable design



Image: Side view of the IKEA ADDE chair, illustrating its profile and compact form.

9. WARRANTY INFORMATION

For detailed information regarding the warranty for your IKEA ADDE chair, please refer to the official IKEA warranty policy available on the IKEA website or at your local IKEA store. Warranty terms and conditions may vary by region.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact IKEA customer service through their official website or visit your nearest IKEA store.
You can find contact information and support resources on the official IKEA website:[IKEA Customer Service](#)

© 2025 IKEA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question