

[Manuals.plus](#) /

› [Newhai](#) /

› Newhai Commercial Vegetable Slicer Electric Potato Slicing Machine Sweet Potato Slicer Automatic Fruit Slicer 0-10mm (0-0.4") Stainless Steel for Cabbage Onion Tomato (110V US Plug) - Instruction Manual

Newhai WWX2

Newhai Commercial Electric Vegetable Slicer - Instruction Manual

Model: WWX2 | Brand: Newhai

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Newhai Commercial Electric Vegetable Slicer. Designed for commercial and home use, this versatile appliance simplifies the slicing of various fruits and vegetables with adjustable thickness settings.

Key features include:

- **Adjustable Thickness:** Slice from 0 to 10mm (0 to 0.4 inches).
- **Dual Use:** Operates electrically or manually.
- **Large Capacity:** Accommodates multiple items with a 25x13cm (9.8"x5.1") storage slot.
- **Durable Construction:** Made from food-grade stainless steel with a thickened aluminum alloy blade.
- **Easy to Clean:** Removable blade for simple maintenance.

2. SAFETY INSTRUCTIONS

Please read all safety warnings carefully before operating the appliance to prevent injury or damage.

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Keep hands and utensils away from the blade during operation.
- Do not operate the slicer with a damaged cord or plug.
- Ensure the appliance is placed on a stable, flat surface.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Use only original Newhai replacement parts and accessories.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Newhai Commercial Electric Vegetable Slicer.



Figure 3.1: Main components of the Newhai Commercial Electric Vegetable Slicer.

- **Machine Body:** The main unit housing the motor and slicing mechanism.
- **Power Adapter:** Converts AC power for the slicer.
- **Power Line:** Connects the adapter to the power outlet.
- **Handle:** For manual operation.
- **Hexagonal Wrench:** Tool for assembly and maintenance.
- **Spare Wire:** Additional wire for potential replacement.

4. SETUP

Follow these steps to set up your slicer for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Place on Stable Surface:** Position the slicer on a clean, dry, and stable countertop. The suction cup base ensures stability.
3. **Insert Blade:** Insert the slicing blade into the designated slot. Turn it until it clicks into place and does not turn further.
4. **Secure Blade Cover:** Attach the blade cover securely. Ensure the safety lock is engaged to hold it firmly.

5. **Connect Power:** Plug the power adapter into the slicer and then into a 110V US power outlet.

Video 4.1: Demonstration of blade insertion and cover attachment for the Newhai Commercial Electric Vegetable Slicer.




Figure 4.2: Close-up of the stable base and power switch.

5. OPERATING INSTRUCTIONS

Your Newhai slicer is designed for efficient and safe operation.

5.1. Slicing Procedure

1. **Prepare Ingredients:** Ensure fruits and vegetables are clean and appropriately sized to fit the feeding slot (25x13cm / 9.8"x5.1").
2. **Load Ingredients:** Place the ingredients into the large capacity feeding slot. The push rod can be adjusted to suit different lengths.
3. **Power On:** Press the power button to start the slicing process. The machine is designed for quick slicing, often completing tasks in under 10 seconds.
4. **Collect Slices:** Sliced items will exit through the bottom chute. Place a container underneath to collect them.



Figure 5.1: The Newhai slicer in operation, demonstrating its ability to slice various fruits.


5.2. Thickness Adjustment

The slicer allows for precise thickness control from 0 to 10mm (0 to 0.4 inches).

- To adjust the thickness, locate the bolt at the center of the machine.
- Rotate the bolt **counter-clockwise** for a thicker cut.
- Rotate the bolt **clockwise** to close the blade and achieve a thinner cut.
- Adjust gradually until the desired slice thickness is achieved.

DURABLE STAINLESS STEEL BEARING CUTTER

Using food grade 304 stainless steel, Cut the ingredients quickly and neatly



SUPER LARGE CALIBER

Super long food trough, can put 1-8 lemons at a time

CUTTING NEAT AND EVEN

Lemon slices are even and beautiful



Figure 5.2: Illustration of the durable blade and large feeding trough, ensuring neat and even slices.

5.3. Manual Operation

In case of a power outage or for outdoor use, the slicer can be operated manually.

- Detach the machine from the power outlet.
- Use the comfortable handle provided to operate the slicing mechanism manually.

ELECTRIC AND MANUAL DUAL-USE

ADD A PROTECTIVE COVER FOR SAFER USE



Durable blade

Stainless steel
bodyElectric and
manual dual useWashed with
water

Electric slicing



Stable to use

CAN SLICE**150LB** continuously

Figure 5.3: The slicer's design supports both electric and manual operation.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your slicer.

- **Always Unplug:** Disconnect the power before cleaning.
- **Disassemble:** Carefully remove the blade and blade cover.
- **Hand Wash Only:** Wash all removable parts with warm, soapy water. The manufacturer recommends hand washing for all components.
- **Rinse Thoroughly:** Rinse all parts to remove soap residue.
- **Dry Completely:** Ensure all parts are completely dry before reassembling or storing to prevent rust, especially for the stainless steel components.
- **Wipe Main Unit:** Wipe the main machine body with a damp cloth. Do not immerse the main unit in water.

7. TROUBLESHOOTING

If you encounter issues with your Newhai Commercial Electric Vegetable Slicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Slicer does not turn on.	Not plugged in; power switch off; power outage.	Check power connection; ensure switch is ON; check household power.
Slices are uneven.	Blade not properly installed; thickness setting incorrect.	Re-install blade securely; adjust thickness setting as needed.
Machine jams during slicing.	Overloaded; ingredients too hard or large.	Reduce quantity; pre-cut larger items; ensure ingredients are suitable for slicing.

For more detailed troubleshooting, a comprehensive Troubleshooting Guide is available in PDF format. Please refer to the product's official support page or contact customer service for assistance.

8. SPECIFICATIONS

Detailed technical specifications for your Newhai Commercial Electric Vegetable Slicer.




Figure 8.1: Product dimensions and key specifications.

- **Brand:** Newhai
- **Model Number:** WWX2
- **Material:** Food-grade Stainless Steel (Body), Thickened Aluminum Alloy (Blade)

- **Color:** Black, Silver
- **Operation Mode:** Automatic (with manual option)
- **Adjustable Slice Thickness:** 0-10mm (0-0.4 inches)
- **Food Trough Size:** 25cm (9.8") length x 13cm (5.1") width
- **Product Dimensions:** 18.23 x 12.87 x 17.68 inches
- **Item Weight:** 15.4 pounds (7 Kilograms)
- **UPC:** 735279352337

9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact Newhai customer service. Keep your purchase receipt for warranty claims.

Customer Service: Refer to the contact information provided with your product packaging or visit the official Newhai website.