ZdalaMit 28438838-bb4c-46eb-a1a7-0c600ef04440

ZdalaMit Replacement Remote Control Instruction Manual

For Onn Roku Smart TV Models: 100012584, 1000125850, 100012585, 100012589, 100012586, 100012587, 100018971

Brand: ZdalaMit | Model: 28438838-bb4c-46eb-a1a7-0c600ef04440

Introduction

This manual provides essential instructions for setting up and operating your ZdalaMit replacement remote control. Designed for specific Onn Roku Smart TV models, this remote offers a straightforward, ready-to-use solution without the need for complex programming or pairing. Please read this manual thoroughly to ensure proper functionality and to maximize your viewing experience.

Package Contents

- 1x ZdalaMit Replacement Remote Control

Setup

1. Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.




OK
NETFLIX
hulu
RK
VUDU

Image 1: Front view of the ZdalaMit replacement remote control, showing the power button, navigation pad, playback controls, and dedicated app buttons for Netflix, Hulu, and Vudu.

2. Initial Use

No programming or pairing is required for this replacement remote control. Once batteries are correctly installed, the remote is ready for immediate use with compatible Onn Roku Smart TV models.
Important Compatibility Note: This ZdalaMit replacement remote control is specifically designed for Onn Roku Smart TVs. It **DOES NOT WORK** with standalone Roku players, Roku boxes, or Roku sticks.

Operating Instructions

The remote control features standard buttons for navigating your Onn Roku Smart TV. Refer to Image 1 for a visual guide to the button layout.

- **Power Button ( ):** Turns the TV on or off.
- **Back Button (←):** Returns to the previous screen or menu.
- **Home Button (⌂):** Navigates to the Roku home screen.
- **Navigation Pad (Up, Down, Left, Right, OK):** Use the directional arrows to move through menus and select items with the central **OK** button.
- **Volume Buttons (,):** Adjusts the TV volume up or down.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Instant Replay (↺):** Replays the last few seconds of content.
- **Sleep Timer ( ):** Accesses sleep timer settings.
- **Star Button (✱):** Provides quick access to options within certain apps or menus.
- **Playback Controls (, ,):** Control fast rewind, play/pause, and fast forward during media playback.
- **Dedicated App Buttons (Netflix, Hulu, RK, Vudu):** Provides direct access to these streaming applications.





Image 2: Side view of the ZdalaMit replacement remote control, highlighting the volume up, volume down, and mute buttons located on the side.

Maintenance

Battery Replacement

If the remote control becomes unresponsive or its range decreases, it may be time to replace the batteries. Follow the battery installation steps outlined in the 'Setup' section.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote is not responding:**
  Ensure that the batteries are correctly installed with the proper polarity. Replace old batteries with new AAA alkaline batteries. Check for any obstructions between the remote and the TV's infrared receiver.
- **Some functions are not working:**
  Verify that your TV is one of the compatible Onn Roku Smart TV models listed in this manual. This remote is not compatible with standalone Roku players, Roku boxes, or Roku sticks, which may explain missing functionality for those devices.
- **Buttons feel sticky or unresponsive:**
  The remote may require cleaning. Refer to the 'Cleaning' section under Maintenance.

Specifications

Brand	ZdalaMit
Model Number	28438838-bb4c-46eb-a1a7-0c600ef04440
Compatible Devices	Onn Roku Smart Televisions (Specific models listed in Introduction)
Power Supply	2 x 1.5V AAA Alkaline Batteries
Product Dimensions	4 x 1.5 x 0.5 inches
Item Weight	1.13 ounces
Color	Black
Special Feature	Ergonomic Design

Support

For any questions or assistance regarding your ZdalaMit replacement remote control, please contact our customer support. We are here to help ensure your satisfaction.

© 2025 ZdalaMit. All rights reserved.