



[Manuals.plus](#) /

> [SOOPYK](#) /

> SOOPYK Portable Countertop Ice Maker Instruction Manual

SOOPYK B08T6B3TH4

SOOPYK Portable Countertop Ice Maker Instruction Manual

Model: B08T6B3TH4

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your SOOPYK Portable Countertop Ice Maker. Please read these instructions thoroughly before first use and retain for future reference.

The SOOPYK Portable Countertop Ice Maker is designed to produce bullet-shaped ice cubes quickly and efficiently. It features a 1.8 L water reservoir and can produce up to 26 lbs of ice in 24 hours, with 9 ice cubes per 6-minute cycle. The unit includes a self-cleaning function and indicators for 'Ice Full' and 'Add Water'.



Figure 1: SOOPYK Portable Countertop Ice Maker with ice and lemon slices.

2. SAFETY INSTRUCTIONS

- Read all instructions before operating the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Ensure the appliance is placed on a stable, level surface away from direct sunlight and heat sources.
- Allow at least 6 inches of clearance around the appliance for proper ventilation.
- Use only potable water in the water reservoir.
- Unplug the appliance before cleaning or when not in use.
- Keep children away from the appliance during operation.

3. PRODUCT COMPONENTS

The SOOPYK Portable Countertop Ice Maker includes the following main components:

- **Main Unit:** Houses the compressor, water reservoir, and ice-making mechanism.
- **Control Panel:** Located on the top, with indicator lights and buttons for operation.
- **Ice Basket:** Removable basket for collecting produced ice cubes.
- **Ice Scoop:** For convenient removal of ice.
- **Water Reservoir:** Internal tank for holding water for ice production.
- **Drain Plug:** Located at the bottom for draining water.



Figure 2: Ice maker showing the ice basket and scoop.

4. SETUP

Follow these steps for initial setup:

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective film.
2. **Placement:** Place the ice maker on a flat, stable surface. Ensure there is adequate ventilation around the unit (at least 6 inches from walls or other appliances).
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the 'Maintenance and Cleaning' section for detailed instructions.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Fill Water Reservoir:** Open the lid and fill the water reservoir with potable water up to the 'MAX' fill line. Do not overfill.

EASY TO USE

STEP 1

Fill the tank to the fill line with water



STEP 2

Press the ON/OFF button



STEP 3

Ice will be deposited into ice basket in 5 minutes

Figure 3: Step-by-step guide for filling the water tank and starting the ice maker.

5. OPERATING INSTRUCTIONS

Operating your SOOPYK ice maker is straightforward:

1. **Power On:** After filling the water reservoir, press the **POWER** button on the control panel to turn on the ice maker. The 'POWER' indicator light will illuminate.
2. **Select Ice Size:** Use the 'SMALL' or 'LARGE' buttons to select your desired ice cube size. The corresponding indicator light will illuminate.
3. **Ice Production:** The ice maker will begin its ice-making cycle. Each cycle produces 9 ice cubes in approximately 6 minutes.
4. **Ice Full Indicator:** When the ice basket is full, the 'ICE FULL' indicator light will turn on, and the ice maker will automatically pause operation. Remove ice to resume production.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the 'ADD WATER' indicator light will turn on, and the ice maker will pause. Add more water to resume operation.
6. **Power Off:** To stop ice production, press the **POWER** button again.

Make Ice In 6Mins



6Mins  = **9**Pcs 

Figure 4: The ice-making process, showing 9 ice cubes produced in 6 minutes.

Two Ice Cube Sizes

Small & Large




Figure 5: The ice maker offers two ice cube sizes: small and large.



Figure 6: Detailed view of the control panel with 'Small', 'Large', 'Power', 'Ice Full', and 'Add Water' indicators.

Operating Video

Your browser does not support the video tag.

Video 1: Demonstrates the SOOPYK Countertop Ice Maker in operation, including the ice production process.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your ice maker.

Self-Cleaning Function

1. Ensure the ice maker is empty of ice and the water reservoir is filled with clean water.
2. Plug in the power cord.
3. Press and hold the **POWER** button for 3 seconds. The unit will enter self-cleaning mode.
4. The pump will circulate water through the ice-making box for approximately 10 minutes.
5. After the cycle, the unit will return to standby mode.
6. Drain the water from the reservoir using the drain plug at the bottom of the unit.
7. Refill with fresh water before resuming ice production.



Figure 7: Visual representation of the self-cleaning function.

Manual Cleaning

- Unplug the ice maker from the power outlet.
- Remove the ice basket.
- Drain all water from the reservoir using the drain plug.
- Wipe the interior with a soft cloth dampened with a mild detergent solution. Rinse thoroughly with clean water.
- Clean the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are dry before reassembling and storing or using the appliance.




Figure 8: Interior view of the ice maker, showing the area to be cleaned after removing the ice basket.

7. TROUBLESHOOTING

If you encounter issues with your ice maker, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; 'ADD WATER' indicator on.	Fill the water reservoir with potable water.
Ice maker not producing ice.	Ice basket is full; 'ICE FULL' indicator on.	Remove ice from the basket.
Ice cubes are too small or cloudy.	Water temperature is too high.	Use colder water. Ensure the unit is in a cool environment.
Unit is leaking water.	Drain plug not properly sealed or unit is overfilled.	Check the drain plug for a secure fit. Do not overfill the water reservoir.
Unusual noise during operation.	Normal operation sounds (compressor, water pump) or unit not level.	Ensure the unit is on a level surface. If noise is excessive or unusual, contact support.

8. SPECIFICATIONS

Key technical specifications for the SOOPYK Portable Countertop Ice Maker:

Feature	Specification
Brand	SOOPYK
Model Name	Ice Makers Countertop
Product Dimensions (D x W x H)	10.2" x 14.3" x 13.98"

Feature	Specification
Ice Production Capacity	Up to 26 lbs per 24 hours
Water Reservoir Capacity	1.8 Liters
Ice Cube Cycle Time	Approximately 6 minutes for 9 cubes
Voltage	115 Volts
Refrigerant	R600a
Noise Level	<40db
UPC	642457711957



Figure 9: Dimensions and key features of the ice maker.



Figure 10: Rear view of the ice maker, highlighting the ventilation fan.

9. WARRANTY AND SUPPORT

SOOPYK is committed to providing quality products and customer service. For warranty information or technical support, please contact our customer service team.

Customer Service Contact:

Email: lynn@aquart.cn

Please have your model number (B08T6B3TH4) and purchase date available when contacting support.