Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Amazon 4K55M600A

Amazon Fire TV 55" Omni Series 4K UHD Smart TV User Manual

Model: 4K55M600A

1. Introduction

Welcome to your new Amazon Fire TV 55" Omni Series 4K UHD Smart TV. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your television. The Fire TV Omni Series offers brilliant 4K entertainment with hands-free Alexa control, vibrant 4K Ultra HD, HDR 10, HLG, and Dolby Digital Plus support.

Enjoy a vast selection of streaming content, live TV, games, and music, all controlled conveniently with your voice.



Image: Front view of the Amazon Fire TV 55" Omni Series 4K UHD Smart TV.

2. What's in the Box

Before you begin, ensure all items are present:

- Fire TV Omni Series 55”
- Fire TV Alexa Voice Remote
- Power cord
- 2 AAA batteries
- IR emitter cable
- 4 screws
- TV stand (2 legs)
- Quick Start Guide



Image: Diagram showing the TV dimensions and the items included in the box, along with the Alexa Voice Remote.

3. Setup Guide

3.1 Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align the two TV stand legs with the screw holes on the bottom of the TV.
3. Secure each leg with the provided screws.



Image: Front view of the Fire TV Omni Series, illustrating its design.




Image: Rear view of the Fire TV Omni Series, highlighting the VESA mounting points and central access panel.

3.2 Connecting Cables

Connect your devices to the appropriate ports on the back or side of the TV.

- **Power Cord:** Connect to the TV's power input and then to a wall outlet.
- **HDMI Devices:** Use the 3 HDMI 2.0 ports for most devices (cable box, gaming console) and the 1 HDMI 2.1 port with eARC for enhanced audio equipment.
- **Ethernet:** For a wired internet connection, connect an Ethernet cable.
- **USB:** For external storage or accessories.

- **Digital Optical Audio Output:** For connecting to soundbars or audio receivers.
- **IR Emitter Cable:** Connect for controlling external IR-enabled devices.



Image: Side profile of the Fire TV Omni Series, highlighting the accessible input ports.



Image: Detailed view of the TV's connectivity panel with labels for Ethernet, HDMI, HDMI eARC/ARC, Cable/Ant, USB, IR Emitter, Headphone, and Optical ports.

3.3 Initial Power-On and Network Connection

1. Plug in the TV.
2. Press the power button on the remote or TV.
3. Follow the on-screen instructions to select your language, connect to your Wi-Fi network (or use Ethernet), and sign in with your Amazon account.
4. The TV will guide you through setting up Alexa and performing initial channel scans if applicable.

4. Operating Your Fire TV

4.1 Hands-Free Alexa Control

Your Fire TV Omni Series features built-in microphones for hands-free Alexa control. Simply say "Alexa" followed by your command.

- "Alexa, turn on the TV."
- "Alexa, find action movies."
- "Alexa, open Netflix."
- "Alexa, switch to HDMI 1."
- To disable microphones, use the physical switch on the TV.

4.2 Streaming Content

Access a wide range of streaming services directly from your Fire TV home screen. Subscription fees may apply for certain services.

- Navigate the home screen using your Alexa Voice Remote.
- Select apps like Prime Video, Netflix, Disney+, YouTube, and more.
- Use Alexa voice commands to search for specific titles or genres.



Image: The Fire TV interface displaying popular streaming applications.

4.3 Gaming on Fire TV

Your Fire TV supports gaming, offering various options for entertainment.

- Play free games with Prime.
- Stream games via the cloud.
- Connect Bluetooth controllers for an enhanced experience.
- Explore hundreds of games available through the Fire TV interface.



Image: The Fire TV interface showcasing available games and a connected game controller.

4.4 Accessibility Features

Fire TV includes features to assist users with various needs:

- **VoiceView screen reader:** Provides audio feedback for on-screen elements.
- **Screen magnifier:** Allows zooming and panning of the display.
- **Text Banner:** Consolidates on-screen text into a customizable banner.
- **Closed Captioning:** Displays captions for compatible content.
- **Audio Description:** Provides verbal descriptions of on-screen actions for compatible content.
- **Bluetooth Hearing Aids:** Supports audio streaming to select compatible Bluetooth hearing aids and devices.

5. Maintenance

5.1 Cleaning Your TV

- Always unplug the TV before cleaning.
- Use a soft, dry, lint-free cloth to wipe the screen and exterior.
- For stubborn marks, lightly dampen the cloth with water. Avoid harsh chemicals or abrasive cleaners.

5.2 Software Updates

Your Fire TV receives automatic software security updates. Ensure your TV is connected to the internet to receive these updates, which improve performance and add new features.

6. Troubleshooting

If you encounter issues with your Fire TV, try the following steps:

- **No Power:** Ensure the power cord is securely plugged into both the TV and a working wall outlet.
- **No Picture/Sound:**
  - Check that the correct input source is selected.
  - Verify all HDMI or audio cables are securely connected.
  - Restart the TV by unplugging it for 30 seconds and plugging it back in.
- **Remote Not Responding:**
  - Replace the AAA batteries in the remote.
  - Pair the remote again by holding the Home button for 10 seconds near the TV.

- **Wi-Fi Connection Issues:**
  - Restart your Wi-Fi router and modem.
  - Go to TV Settings > Network and try reconnecting.
  - Ensure the TV is within range of your Wi-Fi router.
- **Alexa Not Responding:**
  - Check if the microphone switch on the TV is enabled.
  - Ensure the TV is connected to the internet.

For further assistance, refer to the Warranty and Support section.

7. Specifications

Feature	Detail
Model Number	4K55M600A
Resolution	3840 x 2160 (4K UHD)
Screen Size	55” (Viewable display size: 54.6”)
HDR Format	HDR 10, HLG
Backlight Type	Direct LED
Refresh Rate	60 Hz
HDMI Ports	3 HDMI 2.0 + 1 HDMI 2.1 with eARC
Ethernet	1 Ethernet port
USB	1 USB port
Digital Optical Audio Output	1 Digital Optical Audio Port
Voice Support	Hands-free with Alexa, Fire TV Voice Remote, Fire TV app
Audio Support	Dolby Digital Plus
Operating System	Fire TV OS
Product Size (without stand)	48.6” x 28.5” x 3.6”
Weight (without stand)	25 lb
VESA Wall Mount Standard	300 mm x 300 mm
Connectivity	Wifi or Ethernet

8. Warranty and Support

8.1 Warranty Information

Your Amazon Fire TV Omni Series includes a **1-year limited warranty and service**. Optional 3-Year and 4-Year

Extended Warranties are available for U.S. customers and sold separately. Use of Fire TV is subject to the terms found here.

8.2 Software Security Updates

This device receives guaranteed software security updates for at least four years after its last availability for purchase as a new unit on Amazon websites. For more information, visit the Amazon website. If you already own a Fire TV, you can find device-specific information on Manage Your Content and Devices.

8.3 Customer Support

For additional support or to explore more information about your Fire TV Omni Series, you can visit the official Amazon support pages or contact customer service. The User Manual can be explored further online for detailed information.
You can also find support resources via theAmazon Customer Support page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question