

MISSCHEERING LAMP

MISSCHEERING SUN Mini UV/LED Nail Dryer Instruction Manual

Model: LAMP

1. INTRODUCTION AND OVERVIEW

The MISSCHEERING SUN Mini UV/LED Nail Dryer is a compact and portable device designed for curing various types of UV and LED gel polishes. Featuring 6 durable LED light beads and a 6W power output, this lamp offers efficient and safe nail curing for both fingernails and toenails. Its mini size and USB power option make it ideal for travel, home use, or professional settings.



Image 1.1: The SUN Mini UV/LED Nail Dryer in operation, curing gel polish on a hand.

The device is equipped with a closer white light to protect your hands and eyes from potential harm associated with older nail dryer technologies. It offers two convenient timer settings: 60 seconds and 120 seconds, allowing for flexible curing based on your gel polish requirements.

60s/120s

Can Be Used With Laptop Or Charger Plug



Sunlight



Not glaring



Not black hand



UV/LED



6W power



Image 1.2: Key features of the nail dryer, including UV/LED technology and 6W power.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x MISSSCHEERING SUN Mini UV/LED Nail Dryer
- 1 x USB Power Cable
- 1 x User Manual Guide (this document)

3. SETUP

The SUN Mini UV/LED Nail Dryer is designed for easy setup and portability.

1. **Unpack the Device:** Carefully remove the nail dryer and USB cable from its packaging.
2. **Connect Power:** Insert the small end of the provided USB cable into the USB port on the back of the nail dryer.

3. **Power Source:** Connect the larger end of the USB cable to a suitable power source. This can be a computer, laptop, power bank, or a mobile phone charger (USB wall adapter). Ensure the power source provides sufficient power (e.g., a standard 5V/1A USB adapter).



Image 3.1: The USB port for power connection and timer buttons on the device.

4. OPERATING INSTRUCTIONS

Follow these steps for effective curing of your gel polish:

1. **Prepare Nails:** Ensure your nails are clean and dry. Apply a thin, even layer of your chosen gel polish according to its specific instructions. Avoid touching the cuticle or skin around the nails.
2. **Position Hand/Foot:** Place your hand or foot under the nail dryer. Due to its mini size, you may need to cure fingers and thumb separately for optimal results.
3. **Select Timer Setting:**
 - **60-second Timer:** Press the power button once. The lamp will activate for 60 seconds.

- **120-second Timer:** Press and hold the power button for 2 seconds. The lamp will activate for 120 seconds.

Refer to your gel polish brand's instructions for recommended curing times. Curing times can vary significantly between different brands and types of gel polish.

4. **Curing Process:** Keep your hand or foot still under the lamp until the selected timer cycle is complete.
5. **Repeat Layers:** If applying multiple layers of gel polish, repeat steps 1-4 for each layer.
6. **Post-Curing Clean-up:** After curing, if the gel polish feels slightly sticky, gently wipe your nails with a gel cleanser or rubbing alcohol to remove any sticky residue.

Important Note: This SUN Mini nail dryer is designed exclusively for UV and LED gel polishes. It is not compatible with regular nail polish. Always ensure your polish is compatible before use.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your nail dryer.

- **Cleaning:** Disconnect the device from the power source before cleaning. Use a soft, dry cloth to wipe the exterior of the lamp. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the device.
- **Storage:** Store the nail dryer in a cool, dry place away from direct sunlight and extreme temperatures. Keep it in its original packaging or a protective case when not in use, especially during travel, to prevent damage.
- **LED Bulbs:** The 6 LED light beads are designed for durability and typically do not require replacement. If you experience issues with the lights, refer to the troubleshooting section.

6. TROUBLESHOOTING

If you encounter any issues with your SUN Mini UV/LED Nail Dryer, please refer to the following common problems and solutions:

- **Lamp Does Not Turn On:**
 - Ensure the USB cable is securely connected to both the lamp and the power source.
 - Try using a different USB cable or a different power source (e.g., a different USB wall adapter, computer port, or power bank) to rule out a faulty cable or power supply.
 - Confirm the power source is active and providing power.
- **Gel Polish Remains Sticky After Curing:**
 - This is often normal for gel polishes. Wipe the sticky residue (inhibition layer) with a gel cleanser or rubbing alcohol on a lint-free wipe.
 - Ensure you are using the correct curing time as recommended by your gel polish brand. Some polishes require longer curing.
 - Verify that your gel polish is compatible with UV/LED lamps.
 - Apply gel polish in thin, even layers. Thick layers may not cure properly.
- **Incomplete Curing / Polish Peeling:**
 - Ensure your entire nail surface, especially the edges, is exposed to the light during curing. You may need to cure your thumb separately.
 - Confirm the correct timer setting is being used for your specific gel polish.
 - Check the expiration date of your gel polish. Old or improperly stored polish may not cure effectively.
- **Device Feels Flimsy or Slips:**

- Ensure the foldable legs are fully extended and stable on a flat, dry surface.
- Handle the device carefully during use and avoid placing it on uneven or slippery surfaces.

7. SPECIFICATIONS

Below are the technical specifications for the MISSCHEERING SUN Mini UV/LED Nail Dryer:

Brand	MISSCHEERING
Model Number	LAMP
Power	6 Watts
Light Source Type	LED (6 beads)
Timer Settings	60s, 120s
Power Source	Corded Electric (USB)
Product Dimensions	1.97"D x 5.12"W x 0.94"H (approx. 5 x 13 x 2.4 cm)
Item Weight	1.76 ounces (approx. 50 grams)
Material	Plastic
Color	Pink
Special Feature	Portable, Rechargeable (via USB)
Control Method	Touch



Image 7.1: View of the LED light arrangement inside the dryer.



Image 7.2: The compact size of the nail dryer, easily held in one hand.

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support for your MISSCHEERING SUN Mini UV/LED Nail Dryer, please contact the seller or refer to the purchase documentation. Specific warranty terms may vary depending on your region and retailer.

For further assistance, you may visit the official MISSCHEERING store on Amazon:[MISSCHEERING Store](#)

