

[Manuals.plus](#) /

› [Asuwish](#) /

› Asuwish Phone Case for Coolpad Legacy with Tempered Glass Screen Protector - Instruction Manual

Asuwish CP3705AS

Asuwish Phone Case for Coolpad Legacy - Instruction Manual

Model: CP3705AS

INTRODUCTION

This manual provides instructions for the installation, use, and maintenance of your Asuwish Phone Case for Coolpad Legacy. This product is designed to protect your device and offer convenient features such as card storage and a kickstand.



Image: Front and back view of the Asuwish Phone Case, showcasing the embossed sunflower design and magnetic flap closure.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Asuwish Phone Case for Coolpad Legacy
- 1 x Tempered Glass Screen Protector
- 1 x Detachable Wrist Strap

COMPATIBILITY

This phone case is specifically designed for the **Coolpad Legacy** (models 3705A, 3705AS, CP3705AS, CP3705A). It is not compatible with other devices, including Coolpad Legacy Go or Coolpad Illumina. Ensure your device matches the compatible model before installation.



Fit Full



Coolpad Legacy



Not Fit Full



Coolpad Legacy Go
Coolpad illumina

Image: Visual guide illustrating the correct fit for Coolpad Legacy (6.4 inches) and incorrect fit for Coolpad Legacy Go (5.0 inches).

SETUP AND INSTALLATION

1. Installing the Phone Case

1. Ensure your Coolpad Legacy phone is clean and free of dust or debris.
2. Gently align your phone with the soft TPU inner shell of the case.
3. Press the phone firmly into the case, ensuring all edges are securely seated within the TPU bumper. The flexible TPU material provides full body protection and allows for easy installation.




Image: Detail of the soft TPU bumper, highlighting its role in providing protection and ease of phone insertion.

2. Installing the Tempered Glass Screen Protector

1. Clean your phone screen thoroughly with the provided cleaning wipes (if included) to remove any dust or fingerprints.
2. Carefully peel off the protective film from the adhesive side of the tempered glass.
3. Align the screen protector precisely with your phone's screen, ensuring cutouts for the camera and sensors match.
4. Gently lower the screen protector onto the screen. It will adhere automatically. Smooth out any air bubbles by pushing them towards the edges with a soft cloth.

OPERATING INSTRUCTIONS

1. Using the Wallet Features

The case features multiple card slots and a larger pocket for cash or additional cards. Insert your ID, credit cards, or

money into the designated slots for convenient access.



Image: The phone case opened, displaying the integrated card slots and a phone securely held within.

2. Using the Kickstand Function

The flip cover can be folded to create a kickstand. This allows you to prop your phone horizontally for hands-free viewing of videos or video calls.

Built-in magnet

Built-in magnet can be sucked back to avoid affecting the line of sight



Image: The phone case configured as a kickstand, supporting the phone in a horizontal viewing orientation.

3. Magnetic Flap Closure

The case features a strong magnetic flap closure to keep the cover securely closed, protecting your phone screen and contents of the wallet section.



Image: The phone case closed, demonstrating the magnetic flap and overall protective design.

MAINTENANCE

Cleaning the Case

To clean your phone case, gently wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material or finish.

General Care

Avoid exposing the case to extreme temperatures or direct sunlight for prolonged periods to prevent material degradation. While the case offers protection, avoid dropping your phone from significant heights.

TROUBLESHOOTING

Case Does Not Fit

Ensure your phone is a Coolpad Legacy model (3705A, 3705AS, CP3705AS, CP3705A). This case is not

universally compatible with all Coolpad models. Refer to the Compatibility section for details.

Screen Protector Bubbles

If air bubbles appear after screen protector installation, gently press them towards the nearest edge using a soft cloth. For persistent bubbles, lift the nearest edge slightly and reapply, ensuring no dust is trapped underneath.

SPECIFICATIONS

- **Compatible Phone Models:** Coolpad Legacy (3705A, 3705AS, CP3705AS, CP3705A)
- **Material:** High-Quality Leather (exterior), Thermoplastic Polyurethane (TPU) (inner bumper)
- **Special Features:** Card Slot, Kickstand, Magnetic Flap Closure
- **Color:** Gray
- **Form Factor:** Flip Case
- **Item Weight:** Approximately 4.2 ounces
- **Package Dimensions:** Approximately 8.11 x 4.02 x 0.75 inches

WARRANTY AND SUPPORT

Asuwish provides professional customer service. For any questions or concerns regarding your product, please contact us. We offer a free replacement for defective products. We aim to provide a satisfactory solution within 24 hours of your inquiry.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08T6W4V7J>

More documents and user manuals: **<https://manuals.plus/>**