

## Costzon 0756598

# Costzon Baby Playpen Instruction Manual

Model: 0756598

## IMPORTANT SAFETY WARNINGS

Please read and understand all instructions before assembly and use of the Costzon Baby Playpen. Failure to follow these warnings and instructions could result in serious injury or death.

- **Adult Supervision Required:** Never leave a child unattended in the playpen.
- **Proper Assembly:** Ensure all parts are correctly assembled and securely locked before placing a child inside.
- **Hazard Prevention:** Keep the playpen away from open flames, heaters, electrical outlets, windows with cords, and other potential hazards.
- **Weight Limit:** Do not exceed the maximum weight recommendation of 50 pounds.
- **Age Appropriateness:** This playpen is designed for infants and toddlers who cannot climb out. Discontinue use if a child can climb out or reaches 35 inches in height.
- **No Additional Padding:** Do not add extra padding, pillows, or mattresses inside the playpen, as this can create a suffocation hazard.
- **Inspect Regularly:** Periodically check the playpen for damaged hardware, loose joints, missing parts, or sharp edges. Do not use if any part is damaged.
- **Choking Hazards:** Remove any toys with small parts or other choking hazards from the playpen area.

The playpen features breathable mesh walls for visibility and an external zipper opening to prevent accidental exits. Always ensure the zipper is securely closed when a child is inside.



Image: The playpen provides a secure and spacious area for a child to play, featuring breathable mesh walls for visibility and safety.

## ASSEMBLY INSTRUCTIONS


The Costzon Baby Playpen is designed for easy setup. Follow these steps for assembly:

- 1. Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the parts list are present.
- 2. Assemble Frame:** Connect the steel frame tubes according to the diagrams. Ensure all connections click into place securely. The thickened metal tubes provide a sturdy structure.
- 3. Attach Fabric Cover:** Slide the Oxford cloth cover over the assembled frame. Ensure the corner protective covers are properly positioned to reduce impact.
- 4. Secure Base:** Press down firmly on the frame to ensure the non-slip suction cups on the bottom of the panel adhere to a smooth, clean surface. This prevents the playpen from tipping or moving.
- 5. Final Check:** Before use, double-check all connections and ensure the playpen is stable and secure.

# Reliable & Stable Design



Visible Mesh Wall



Skin-friendly Oxford Cloth



Corner Protective Cover



Thickened Metal Tubes



Strong Suction Cups

Image: This diagram illustrates the playpen's dimensions (47"L x 47"W x 27"H) and highlights structural components such as visible mesh walls, skin-friendly Oxford cloth, corner protective covers, thickened metal tubes, and strong suction cups for stability.

## OPERATING INSTRUCTIONS

Using your Costzon Baby Playpen is straightforward:

- **Placing Child Inside:** Gently place your child into the playpen. Ensure they are comfortable and have enough space to move.
- **Zippered Door:** The playpen features an enlarged zippered mesh door for easy access. To allow your child to enter or exit, unzip the door. Always ensure the zipper is fully closed and secured when your child is inside to prevent them from crawling out.
- **Pull Rings:** Four pull rings are included to aid your baby in standing up independently. Attach these rings to the top rail of the playpen at appropriate intervals.
- **Ocean Balls:** The included 50 ocean balls can be placed inside the playpen for additional fun and to help develop your baby's grasping ability.

## Enlarged Zippered Mesh Door

Offer an easy entrance for baby to climb in and out



Image: The playpen features an enlarged zippered mesh door, offering an easy entrance and exit for the baby, facilitating interaction and independent movement.



**50 Ocean Balls**  
Exercise  
baby's grasping ability

## Bonus Accessories



**4 Pull Rings**  
Aid baby to stand up  
independently



Image: The playpen includes 50 ocean balls for play and 4 pull rings to assist babies in standing independently, promoting motor skill development.

### MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and hygiene of your Costzon Baby Playpen:

- **Cleaning Fabric:** The entire fabric cover is removable. It can be wiped down with a damp cloth and mild soap. Rinse thoroughly and air dry completely before reassembling. Do not use harsh chemicals or abrasive cleaners.
- **Cleaning Frame:** Wipe the steel frame with a damp cloth as needed.
- **Inspect Components:** Periodically check all parts for wear and tear, especially the mesh, fabric, and frame connections. Ensure the non-slip suction cups are clean and functioning effectively.
- **Storage:** When not in use, the playpen can be disassembled and stored in a dry, cool place away from direct sunlight.

## TROUBLESHOOTING

If you encounter any issues with your Costzon Baby Playpen, refer to the following common solutions:

- **Playpen is Unstable:** Ensure all frame tubes are fully connected and locked. Check that the non-slip suction cups are clean and firmly pressed onto a smooth, flat surface.
- **Zipper Not Functioning Smoothly:** Check for any fabric caught in the zipper teeth. Apply a small amount of zipper lubricant if necessary.
- **Missing Parts:** If any parts are missing upon unpacking, please contact Costzon customer support immediately.
- **Difficulty Disassembling:** Refer to the assembly instructions in reverse. Ensure all locking mechanisms are disengaged before attempting to separate components.

## SPECIFICATIONS

Feature	Detail
Model Number	0756598
Overall Dimensions (L x W x H)	47 inches x 47 inches x 27 inches
Floor Area	Approximately 15.34 Square Feet
Item Weight	8 Pounds
Maximum Weight Recommendation	50 Pounds
Material Type	Steel, Waterproof Oxford cloth, Sponge, Mesh
Color	Blue
Included Accessories	50 Ocean Balls, 4 Pull Rings



Image: The Costzon Baby Playpen offers a spacious and secure environment for babies, allowing them to play safely while parents can attend to other tasks.

## WARRANTY INFORMATION

For specific warranty details regarding your Costzon Baby Playpen, please refer to the warranty card included with your purchase or visit the official Costzon website. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

## CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a defective part, please contact Costzon customer support. Contact information can typically be found on the product packaging, the warranty card, or the official Costzon website.

**Online Support:** Visit the Costzon official website for FAQs and support resources.

**Email Support:** Refer to your product documentation for the customer service email address.



© 2026 Costzon. All rights reserved.