

Logitech 952-000038

Logitech Rally Mic Pod User Manual

Model: 952-000038

INTRODUCTION

The Logitech Rally Mic Pod is designed to enhance audio clarity in conference rooms by providing focused voice pickup. This manual provides essential information for the proper installation, operation, and maintenance of your Rally Mic Pod.

PACKAGE CONTENTS

Before proceeding with the setup, please verify that all components are present in your package:

- Logitech Rally Mic Pod (Model 952-000038)
- Integrated Cable

SETUP

Follow these steps to properly set up your Rally Mic Pod:

1. **Placement:** Position the Rally Mic Pod on a flat surface in your conference room, ensuring it is centrally located to capture all participants' voices effectively. For optimal performance, avoid placing it too close to noise sources or reflective surfaces.
2. **Connection:** Connect the integrated cable from the Rally Mic Pod to a Logitech Rally Table Hub or Rally Display Hub. The Mic Pod is designed to work exclusively with Logitech Rally systems and is not a standalone USB microphone for direct PC connection.
3. **Daisy-Chaining (Optional):** Multiple Rally Mic Pods can be daisy-chained together to extend audio coverage in larger rooms. Connect the cable from the first Mic Pod to the Rally Hub, and then connect subsequent Mic Pods to each other using additional Rally Mic Pod cables (sold separately).



Image: Top view of the Logitech Rally Mic Pod, showing its circular design and mute button.



Image: Bottom view of the Logitech Rally Mic Pod, illustrating the cable management and connection port.

OPERATING INSTRUCTIONS

Once connected to a Logitech Rally system, the Mic Pod operates automatically. Here are key operational features:

- **Mute Button:** The Mic Pod features a touch-sensitive mute button located on its top surface. Pressing this button will mute or unmute the microphone. An LED indicator on the Mic Pod will change color to show its current status (e.g., red for muted, green for active).
- **Automatic Beamforming:** The Rally Mic Pod utilizes RightSound™ technology with automatic beamforming to focus on active speakers and suppress background noise, ensuring clear audio pickup.
- **System Integration:** The Mic Pod's functionality is managed through the connected Logitech Rally system. Audio settings and firmware updates are typically handled via the Rally system's management software.



Image: A hand interacting with the mute button on a Logitech Rally Mic Pod placed on a conference table.

MAINTENANCE

To ensure the longevity and optimal performance of your Rally Mic Pod, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the Mic Pod. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by a dry cloth. Avoid abrasive cleaners, solvents, or aerosol sprays.
- **Storage:** When not in use for extended periods, store the Mic Pod in a clean, dry environment away from extreme temperatures and direct sunlight.
- **Cable Care:** Avoid bending or crimping the integrated cable excessively. Ensure cables are routed safely to prevent tripping hazards and damage.

TROUBLESHOOTING

If you encounter issues with your Rally Mic Pod, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No audio pickup from Mic Pod	Mic Pod is muted; incorrect connection; Rally system issue.	Press the mute button to unmute. Ensure the cable is securely connected to the Rally Hub. Verify the Rally system is powered on and functioning correctly.

Problem	Possible Cause	Solution
Mute button LED not responding	No power; faulty connection.	Check all cable connections to the Rally Hub. Ensure the Rally system is receiving power.
Mic Pod not recognized by PC	Attempting to connect directly to PC via USB.	The Rally Mic Pod is designed for use with Logitech Rally systems only and does not function as a standalone USB microphone for direct PC connection. It must be connected to a Rally Table Hub or Display Hub.
Poor audio quality	Improper placement; environmental noise; faulty unit.	Relocate the Mic Pod to a more central position. Minimize background noise. If issues persist, contact Logitech support.

SPECIFICATIONS

Key technical specifications for the Logitech Rally Mic Pod (Model 952-000038):

- **Model Number:** 952-000038
- **Brand:** Logitech
- **Color:** Graphite
- **Material:** Acrylic (Body), Graphite (General)
- **Item Weight:** 357 Grams
- **Item Dimensions (L x W x H):** 17.45 x 12.08 x 8.22 inches
- **Maximum Height:** 20.89 Centimeters
- **Included Components:** Microphone
- **Connectivity:** Proprietary connection to Logitech Rally Hubs
- **Features:** Mute button with LED indicator, RightSound™ technology with automatic beamforming.

WARRANTY INFORMATION

The Logitech Rally Mic Pod (Model 952-000038) comes with a **1-year limited hardware warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For full terms and conditions, please refer to the official Logitech warranty documentation or visit the Logitech support website.

SUPPORT

For further assistance, technical support, or to access additional resources, please visit the official Logitech support website:

[Logitech Support](#)

You can also find frequently asked questions and community forums on the support portal.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question