

[Manuals.plus](#) /

› [Miady](#) /

› Miady 5000mAh Mini Portable Charger User Manual

Miady HYD009

Miady 5000mAh Mini Portable Charger User Manual

Model: HYD009

1. INTRODUCTION

The Miady 5000mAh Mini Portable Charger is a compact and efficient power bank designed to provide on-the-go charging for your mobile devices. Its small size and dual output ports make it an ideal companion for travel and daily use, ensuring your smartphones, tablets, and other compatible devices remain powered throughout the day.



Image 1.1: Miady 5000mAh Mini Portable Chargers (White and Black)

2. KEY FEATURES

- **Super-mini Design:** Compact dimensions (3.6 x 2.5 x 0.4 inches) and lightweight (4.2 Oz) for easy portability.
- **12W Rapid Charging:** Provides 5V/2.4A high-speed charging via USB-A and USB-C ports.
- **Dual Output Ports:** Capable of charging two devices simultaneously.
- **Airline Approved Capacity:** 5000mAh / 18.5 watt-hours, safe for air travel.

- **Wide Compatibility:** Compatible with various devices including iPhone 16/15/14/13/12/11 Series, Galaxy S24/S22/S21/S20, Pixel series, iPads, and other Android smartphones and tablets.
- **Safety Features:** Includes Auto Shut-Off, LED Indicator Lights, Pocket Size, Short Circuit Protection, and Slim design.

Ultra Small, Slim, Lightweight

Size:3.6*2.5*0.4 in | weight: 4.2 Oz



Slim



Image 2.1: Compact and Lightweight Design

PD Fast Charging



Image 2.2: 12W Rapid Charging Capability

3. PACKAGE CONTENTS

The Miady 5000mAh Mini Portable Charger package includes the following items:

- 5000mAh Portable Phone Charger (Black) x 1
- 5000mAh Portable Phone Charger (White) x 1
- USB-C Cable x 2
- User Manual x 1

Black & White portable chargers



4. SETUP AND CHARGING THE POWER BANK

Before first use, it is recommended to fully charge your Miady portable charger. The power bank features a USB-C port that functions for both input (charging the power bank) and output (charging devices).

4.1 Charging the Power Bank

1. Connect one end of the provided USB-C cable to the USB-C port on the Miady power bank.
2. Connect the other end of the USB-C cable to a compatible USB wall adapter (not included) or a computer's USB port.
3. The LED indicator lights on the power bank will illuminate to show the charging progress. All four lights will be solid when fully charged.

USB-C IN&OUT



✓ **Miady USBC**

IN/OUT



✓ **Charge All**
✓ **Fail to Charge**

✓ **Recharge Power bank Itself**

✗ **Other USB C**

INPUT



Fail to Charge
Devices

✓ **Recharge Power bank Itself**

Image 4.1: Charging the Power Bank via USB-C

5. OPERATING INSTRUCTIONS

5.1 Charging Your Devices

The Miady portable charger is equipped with both a USB-A output port and a USB-C input/output port, allowing for versatile charging options.

1. Connect your device's charging cable to either the USB-A port or the USB-C port on the power bank.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The LED indicators will show the remaining battery level.
4. To charge two devices simultaneously, connect one device to the USB-A port and another to the USB-C port.

Dual output ports



iPhone 11
1.3 Charges



Galaxy S20
1.0 Charges



Pixel
1.4 Charges

Image 5.1: Dual Output Ports for Device Charging

Charge 2 Devoces at Once



Image 5.2: Charging Two Devices at Once

5.2 Checking Battery Level

Press the power button once to check the remaining battery level indicated by the LED lights. Each light typically represents approximately 25% of the battery capacity.

6. MAINTENANCE AND CARE

- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- Do not expose the power bank to water or other liquids.
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- For optimal battery life, fully charge the power bank at least once every three months if not in regular use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging	Cable is faulty; wall adapter is not working; power bank is fully charged.	Try a different USB-C cable and wall adapter. Check LED indicators to confirm if it's already fully charged.
Device not charging from power bank	Power bank battery is low; device cable is faulty; device is incompatible; power bank is in auto shut-off mode.	Recharge the power bank. Try a different charging cable. Ensure your device is compatible. Press the power button to reactivate the power bank.
Slow charging speed	Using a non-fast charging cable/adaptor; charging multiple devices simultaneously.	Use the provided USB-C cable or another high-quality fast-charging cable. Disconnect one device if charging two at once.
Power bank overheats	Overloading; poor ventilation; internal fault.	Disconnect devices and allow the power bank to cool down. Ensure it's used in a well-ventilated area. If overheating persists, discontinue use and contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	HYD009
Battery Capacity	5000 Milliamp Hours (18.5 Wh)
Product Dimensions	3.6 x 2.4 x 0.5 inches
Item Weight	3.45 ounces
Input (USB-C)	5V/2.4A (Max)
Output (USB-A)	5V/2.4A (Max)
Output (USB-C)	5V/2.4A (Max)
Batteries	2 Lithium Ion batteries (included)
Color	White+Black
Special Features	Auto Shut-Off, LED Indicator Lights, Pocket Size, Short Circuit Protection, Slim




Image 8.1: Airline Approved Capacity

Right for All Your Devices

USB A & USB C



Image 8.2: Wide Device Compatibility

9. WARRANTY AND CUSTOMER SUPPORT

Miady provides a 180-day after-sales service for this product. For any questions or concerns, please contact Miady's customer service. They offer 24/7 support to ensure a satisfying solution for your needs.

Your satisfaction is our greatest recognition and support.

For support, please refer to the contact information provided with your purchase or visit the official Miady store on Amazon:[Miady Store](#)

© 2024 Miady. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why is my Miady HQW021 power bank not charging via the wireless pad or the provided USB-C cable?

It is common for lithium-ion batteries to enter a "deep discharge" state if they are left unused for an extended period without an initial charge. Since your Miady HQW021 is not responding, please try...

[Read full answer](#)