Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

waxkiss B08T982VVD

waxkiss Digital Hair Removal Wax Warmer Instruction Manual

Model: B08T982VVD

1. Introduction

Thank you for choosing the waxkiss Digital Hair Removal Wax Warmer. This device is designed for efficient and convenient hair removal, suitable for various wax types. Please read this manual thoroughly before use to ensure safe and optimal operation.



Figure 1: The waxkiss Digital Hair Removal Wax Warmer with its clear lid and digital display.

2. Safety Information

For external use only. Always follow these safety guidelines to prevent injury or damage to the device:

- Do not immerse the device in water or any other liquid.
- Keep out of reach of children.
- Always unplug the device when not in use and before cleaning.
- Do not operate the device if the cord or plug is damaged.
- Ensure the device is placed on a stable, heat-resistant surface.
- Avoid direct contact with hot wax or the inner pot to prevent burns. Use appropriate tools for handling.
- Do not use the device near flammable materials.
- Always monitor the wax melting process.

3. Product Components

The waxkiss Digital Hair Removal Wax Warmer includes the following main components:

- **Main Warmer Unit:** Houses the heating element and control panel.
- **Removable Aluminum Wax Pot (14oz):** For holding wax, designed for easy cleaning.
- **See-Through Lid:** Allows monitoring of wax meltdown while keeping it clean.
- **Digital Display:** Shows the current temperature.
- **Temperature Control Knob:** Adjusts the desired heating temperature.
- **Power Cable:** 4.6-inch grounded power cable for safety.



Figure 2: Diagram illustrating the main components of the wax warmer kit.

4. Setup Instructions

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the wax warmer on a flat, stable, and heat-resistant surface. Ensure it is away from water sources and flammable materials.
3. **Insert Pot:** Place the removable aluminum wax pot into the main warmer unit.

4. **Connect Power:** Plug the 3-pin grounded power cable into a suitable electrical outlet.

5. Operating Instructions

This wax warmer is compatible with various wax types, including standard 14-ounce wax cans, loose wax, and wax beans.



Figure 3: Examples of wax types suitable for use with the waxkiss warmer, including wax beans, round wax blocks, square wax blocks, and wax cans.

1. **Add Wax:** Place your desired wax (beans, blocks, or a 14oz can) into the removable aluminum wax pot.
2. **Cover:** Place the see-through lid onto the warmer unit. This helps maintain temperature and keeps the wax clean.
3. **Power On & Set Temperature:** Turn the temperature control knob from "OFF" to your desired temperature setting. The digital display will show the set temperature. The adjustable temperature range is 86°F to 257°F (30°C to 125°C).
4. **Heat Wax:** The warmer will begin heating. The digital display will show the current temperature. As the temperature increases, the heating speed will accelerate.

5. **Monitor Meltdown:** Observe the wax through the see-through lid. Once the wax has melted to the desired consistency, it is ready for use.
6. **Application:** Carefully remove the lid. Using appropriate applicators, apply the wax according to the specific wax product's instructions for hair removal.
7. **Power Off:** After use, turn the temperature control knob to the "OFF" position and unplug the device from the power outlet.



Figure 4: The waxkiss warmer in use, demonstrating its application in a hair removal routine.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your wax warmer.

1. **Unplug and Cool:** Always ensure the device is unplugged and completely cooled down before cleaning.
2. **Remove Wax Pot:** Carefully lift out the removable aluminum wax pot using its handle.
3. **Clean Wax Pot:** The non-stick aluminum wax pot is easy to clean. Allow any residual wax to solidify, then gently scrape it out. You can use a wax cleaner or a small amount of oil to remove stubborn wax residue, then wash with warm soapy water. Rinse thoroughly and dry completely.

4. **Clean Exterior:** Wipe the exterior of the warmer unit and the lid with a soft, damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
5. **Storage:** Store the cleaned and dried wax warmer in a cool, dry place.

7. Troubleshooting

- **Warmer not turning on:**
  - Ensure the power cable is securely plugged into both the warmer and a working electrical outlet.
  - Check if the temperature control knob is turned past the "OFF" position.
- **Wax heating slowly:**
  - Ensure the lid is properly placed on the warmer to retain heat.
  - Verify the temperature setting on the digital display. Higher temperatures will melt wax faster.
  - The initial heating of a full pot of cold wax may take some time.
- **Digital display not working:**
  - Check power connection. If the unit is on but the display is blank, contact customer support.
- **Warmer automatically turns off:**
  - Some units may have an auto-off safety feature. If the warmer turns off during extended use, manually restart it by turning the knob to "OFF" and then back to the desired temperature.

8. Specifications

Feature	Detail
Model	B08T982VVD
Brand	waxkiss
UPC / GTIN	609792484762
Package Dimensions	7.2 x 7.17 x 5.87 inches
Item Weight	1.41 Pounds
Wax Pot Capacity	14 ounces
Temperature Range	86°F to 257°F (30°C to 125°C)
Material Feature	Dermatologist Tested (for compatible waxes)
Skin Type Compatibility	All (with appropriate wax)



Figure 5: Product dimensions for the waxkiss Digital Hair Removal Wax Warmer.

9. Warranty and Support

waxkiss is committed to providing excellent service. If you encounter any issues or have questions regarding your wax warmer, please contact us within 30 days of purchase. We will provide services to satisfy you or arrange a replacement if any questions remain unsatisfied.

For further assistance, please refer to the contact information provided with your purchase or visit the official waxkiss store online.

Note: This manual provides general instructions. Always refer to the specific instructions provided with your chosen wax product for detailed application guidelines.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08T982VVD

More documents and user manuals: **https://manuals.plus/**