



[Manuals.plus](#) /

› [Furologee](#) /

› Furologee Vertical 4 Drawer Dresser Organizer with 3-Tiers Wood Shelf Instruction Manual

Furologee 4D-001

Furologee Vertical 4 Drawer Dresser Organizer Instruction Manual

Model: 4D-001 | Brand: Furologee

1. INTRODUCTION

Thank you for choosing the Furologee Vertical 4 Drawer Dresser Organizer. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new storage unit. Please read this manual thoroughly before beginning assembly.

2. SAFETY INSTRUCTIONS

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload shelves or drawers. Each wood shelf can hold up to 50 lbs, and each fabric drawer can hold up to 10 lbs.
- Install the anti-tip kit provided to prevent accidental tipping, especially in households with children or pets.
- Keep small parts and packaging materials away from children.
- Do not stand or climb on the unit.

3. PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Metal Frame Components (various labeled parts)
- Wood Shelves (3 tiers)
- Fabric Drawers (4 units)
- Adjustable Feet (4 units)
- Anti-tip Kit

- Assembly Hardware (screws, connectors, wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly:

1. **Assemble the Metal Frame:** Connect the vertical metal frame pieces using the provided screws and connectors. Ensure all connections are secure.



Figure 4.1: Initial assembly of the metal frame.

2. **Attach the Wood Shelves:** Secure the three wood shelves to the designated positions on the metal frame using the appropriate hardware.



Figure 4.2: Attaching the wood shelves.

3. **Prepare and Insert Fabric Drawers:** Unfold each fabric drawer and insert the bottom panel to create a sturdy box. Attach the handles to the front of each drawer. Slide the assembled drawers into their respective compartments in the frame.



Figure 4.3: Assembling and inserting the fabric drawers.

4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the metal frame. Adjust them to level the unit on uneven surfaces.
5. **Install Anti-Tip Kit:** For safety, secure the unit to the wall using the provided anti-tip kit. Follow the specific instructions included with the kit for proper installation.



Figure 4.4: Installing the anti-tip kit for stability.

5. OPERATING INSTRUCTIONS

Your Furologee dresser is designed for versatile storage:

- **Drawer Usage:** The four fabric drawers are ideal for organizing clothes, linens, toys, or office supplies. Pull the handles gently to open and push to close.



Figure 5.1: Fabric drawers provide ample storage space.

- **Shelf Usage:** The three wood shelves provide open storage for books, decorative items, plants, or frequently accessed essentials.





Figure 5.2: The top shelves are perfect for display or easy access items.

- **Weight Capacity:** Adhere to the maximum weight limits: 50 lbs per wood shelf and 10 lbs per fabric drawer to ensure stability and longevity of the unit.

6. MAINTENANCE

To keep your dresser in optimal condition:

- **Cleaning:** Wipe the wood shelves and metal frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners.

- **Fabric Drawers:** The fabric drawers can be spot cleaned with a mild detergent and air-dried. Do not machine wash.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Leveling:** Re-adjust the adjustable feet if the unit becomes wobbly due to floor unevenness.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Unit is wobbly	Uneven floor; loose connections; anti-tip kit not installed.	Adjust adjustable feet; tighten all screws; install anti-tip kit.
Drawers do not slide smoothly	Drawer is overloaded; fabric is caught; drawer not properly assembled.	Reduce load in drawer; check for obstructions; ensure bottom panel is fully inserted.
Missing parts or damaged components	Manufacturing defect; shipping damage.	Contact customer support for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	Furologee
Product Dimensions	11.4"D x 22.8"W x 42.7"H
Mounting Type	Freestanding
Room Type	Bedroom, Living Room, Office
Special Feature	Lightweight, Removable, Sturdy
Furniture Finish	Brown
Product Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes
Item Weight	10 Pounds
Size	4 drawer
Number of Pieces	1
Model Number	4D-001
ASIN	B08TBM7MBB
UPC	779172185920

9. WARRANTY AND SUPPORT

For any questions, concerns, or to inquire about warranty information and replacement parts, please contact Furologee customer support. Refer to the product packaging or the retailer's website for specific contact details.

