Kohler 98804-0

Kohler PureWash M300 Manual Elongated Bidet Toilet Seat Instruction Manual

Model: **98804-0** | Brand: **Kohler**

INTRODUCTION

The Kohler PureWash M300 Manual Elongated Bidet Toilet Seat is designed to provide personal cleansing without requiring electricity or batteries. This manual bidet seat features a dual-spray wand for front and rear cleansing, adjustable water pressure, and a Quiet-Close lid to prevent slamming. Its quick-release hinges facilitate easy installation and cleaning.

SETUP AND INSTALLATION

This bidet toilet seat is designed for straightforward installation, connecting directly to your toilet's existing water supply line. No electrical outlet is required.

Installation Steps:

1. **Prepare the Toilet:** Turn off the water supply to your toilet and flush to empty the tank. Disconnect the existing water supply line from the toilet tank.

2. **Install T-Valve:** Connect the supplied T-valve to the toilet tank's fill valve. Ensure the T-valve's stem is oriented to easily connect with the bidet seat's hose.

3. **Connect Bidet Hose to Seat:** It is crucial to connect the L-shaped end of the white plastic bidet hose to the bidet seat first. Carefully thread the metal female connector onto the plastic male screw on the seat. Applying a small amount of silicone lubricant to the threads can aid in preventing stripping. Tighten firmly with a wrench once properly threaded.

4. **Mount the Seat:** Attach the mounting bracket to your toilet bowl using the provided hardware. Place the bidet seat onto the mounting bracket, ensuring it clicks securely into place.

5. **Connect Bidet Hose to T-Valve:** Connect the straight end of the bidet hose to the T-valve. Create a loop with any excess hose to manage its length neatly under the water tank.

6. **Restore Water Supply:** Turn the toilet's water supply back on slowly and check all connections for

leaks.

Figure 1: Side view of the bidet seat with water connection.

Figure 2: The bidet seat detached, revealing the mounting hardware.

OPERATING INSTRUCTIONS

The PureWash M300 bidet seat offers simple, manual operation for personal cleansing.

Cleansing Functions:

- **Dual-Spray Wand:** The bidet features a wand that provides water for both front and rear cleansing.

- **Adjustable Water Pressure:** A convenient side lever allows you to adjust the water pressure to your preference. Rotate the lever for desired intensity.

- **Self-Cleaning Wand:** The wand automatically rinses itself with water after each use, maintaining hygiene.

Figure 3: Manual control lever for water pressure and spray selection.

Figure 4: The self-cleaning bidet wand.

Figure 5: Adjustable spray in operation.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your bidet toilet seat.

Cleaning the Seat:

- **Quick-Release Functionality:** The seat features Quick-Release hinges, allowing it to be easily removed from the toilet for thorough cleaning of both the seat and the toilet bowl. Press the release buttons located near the hinges to lift the seat off.

- **Cleaning Materials:** Use mild soap and water with a soft cloth. Avoid abrasive cleaners, scrubbers, or chemical solvents, as these can damage the finish.

- **Wand Cleaning:** The bidet wand is self-cleaning. For additional cleaning, gently wipe the wand with a soft, damp cloth when it is extended.

- **Hygiene:** The seat material inhibits the growth of odor-causing bacteria, mold, and mildew. Note that this does not protect against bacteria, viruses, or disease organisms.

Your browser does not support the video tag.

TROUBLESHOOTING

If you encounter issues with your Kohler PureWash M300 bidet seat, refer to the following common solutions:

Common Issues:

- **No Water Spray or Low Pressure:**

  - Ensure the toilet's water supply valve is fully open.
  - Verify that the bidet's side lever is correctly positioned for the desired spray.
  - Check for kinks or obstructions in the bidet's water supply hose.
  - Confirm adequate household water pressure.

- **Leaks at Connections:**

  - Turn off the water supply.
  - Inspect all connections (T-valve to tank, bidet hose to seat, bidet hose to T-valve) for proper alignment and tightness.
  - Ensure no threads are stripped, especially where the bidet hose connects to the seat. If necessary, re-thread carefully or replace the hose.
  - Consider using plumber's tape on threaded connections to ensure a watertight seal.

- **Seat Does Not Close Quietly:**

  - Check for any obstructions preventing the lid from closing smoothly.
  - Ensure the quick-release hinges are fully engaged and the seat is properly seated on the mounting posts.

SPECIFICATIONS

Feature	Detail
Model Number	98804-0
Brand	Kohler
Color	White
Material	Plastic
Style	White Handle
Shape	Elongated (Oval)
Product Dimensions	19.94"L x 16.19"W
Item Weight	6.74 pounds
Power Source	Manual (No batteries or electricity required)

Feature	Detail
UPC	885612886927

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Kohler website or contact Kohler customer service directly. It is important to note that toilet seats are generally not returnable to Kohler Co. if opened or removed from their original packaging, as per standard policy.

For further assistance, please visit the KOHLER Store on Amazon or consult your purchase documentation.