

[Manuals.plus](#) /

› [Lynnoland](#) /

› Lynnoland Clear Glass Shade Cylinder N19016SG01 Instruction Manual

Lynnoland N19016SG01

Lynnoland Clear Glass Shade Cylinder N19016SG01 Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and proper installation, use, and maintenance of your Lynnoland Clear Glass Shade Cylinder. Please read these instructions carefully before proceeding with installation or use, and retain them for future reference.

SAFETY INFORMATION

- Always disconnect power to the lighting fixture at the circuit breaker before installing or replacing the glass shade.
- Handle glass shades with care to prevent breakage and injury.
- Ensure the shade is securely fastened to the fixture before restoring power.
- Do not use abrasive cleaners or materials that could scratch or damage the glass surface.
- Verify that the shade dimensions are compatible with your existing fixture.

PRODUCT OVERVIEW

The Lynnoland Clear Glass Shade Cylinder is designed as a replacement or upgrade for various lighting fixtures, including pendant lights, floor lamps, desk lamps, wall sconces, and bathroom light fixtures. It features a modern, cylindrical design with high-transmittance, explosion-proof glass for durability and clear light diffusion.

**Medium 1.77in /
45mm fitter**



Thick clear glass

Image: The clear glass shade highlighting the 1.77 inch (45mm) fitter opening and the thick glass construction.



Image: A close-up view of the glass shade demonstrating its 4mm thickness and solid, explosion-proof design.

SPECIFICATIONS

Brand	Lynnoland
Model Number	N19016SG01
Material	Glass
Color	Clear
Shape	Cylindrical
Product Dimensions	4.72 inches (120mm) diameter x 5 inches (127mm) height

Fitter Opening Diameter	1.65 inches (42mm) to 1.77 inches (45mm)
Special Feature	Explosion-proof glass, Smooth edges
Recommended Uses	Chandelier, Wall Lamp, Sconces, Pendant Light, Floor Lamp, Desk Lamp, Bathroom Light Fixtures
Assembly Required	No
Item Weight	0.25 Pounds (4 ounces)




Image: Dimensional diagram of the glass shade, indicating a 4.72 inch diameter, 5 inch height, and a 1.65 inch opening for an E26 socket ring (socket ring not included).

INSTALLATION INSTRUCTIONS

This glass shade is designed for easy replacement on compatible lighting fixtures. Follow these steps for safe installation:

1. **Prepare the Fixture:** Before beginning, ensure the power supply to the lighting fixture is completely turned off at the circuit breaker to prevent electrical shock. Allow any existing bulbs to cool down if they have been recently in use.
2. **Remove Existing Shade (if applicable):** Carefully remove the old glass shade or diffuser from your lighting fixture. This usually involves unscrewing a retaining ring, clips, or other fasteners. Place the old shade aside safely.
3. **Inspect the Fitter:** Check the fitter on your lighting fixture. The Lynnloland Clear Glass Shade Cylinder requires a fitter with an opening diameter of approximately 1.65 inches (42mm) to 1.77 inches (45mm) to accommodate the socket ring. Ensure your fixture's socket ring is compatible and in good condition.
4. **Install the New Shade:**
 - Carefully slide the Lynnloland Clear Glass Shade Cylinder over the bulb socket.
 - Secure the shade in place using the existing socket ring or retaining mechanism of your fixture. Twist the socket ring clockwise until the shade is firmly held, but do not overtighten, as this may crack the glass.
5. **Verify Stability:** Gently tug on the installed shade to ensure it is stable and securely attached to the fixture.
6. **Restore Power:** Once the shade is securely installed, restore power to the lighting fixture at the circuit breaker.

If you encounter any difficulties or if the shade does not fit properly, do not force it. Consult a qualified electrician or contact Lynnloland customer support.

OPERATION

The Lynnloland Clear Glass Shade Cylinder functions passively as a component of your lighting fixture. Once installed, its primary role is to diffuse light and contribute to the aesthetic of the fixture. Operate your lighting fixture as usual according to its own instructions.

MAINTENANCE AND CARE

To maintain the clarity and appearance of your glass shade, follow these cleaning guidelines:

- **Regular Cleaning:** Dust the shade regularly with a soft, dry, lint-free cloth.
- **Deep Cleaning:** For more thorough cleaning, turn off the power to the fixture and allow the shade to cool. Carefully remove the shade from the fixture. Wash it gently with warm water and a mild, non-abrasive soap. Rinse thoroughly with clean water.
- **Drying:** Dry the shade completely with a soft, lint-free cloth before re-installing it. Ensure no moisture remains, especially around metal components of the fixture.
- **Avoid Harsh Chemicals:** Do not use harsh chemical cleaners, abrasive pads, or scouring powders, as these can scratch the glass or leave residues.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shade does not fit the fixture.	Incompatible fitter size.	Verify the fitter opening diameter of the shade (1.65-1.77 inches) against your fixture's requirements. This shade is designed for specific fitter sizes.
Shade appears loose after installation.	Socket ring not tightened sufficiently.	Ensure power is off, then carefully tighten the socket ring until the shade is secure. Do not overtighten.

Problem	Possible Cause	Solution
Glass appears cloudy or stained after cleaning.	Residue from cleaning agents or improper drying.	Re-clean with mild soap and water, rinse thoroughly, and dry immediately with a clean, lint-free cloth. Avoid harsh chemicals.

WARRANTY AND SUPPORT

Lynnoland is committed to providing quality products. While specific warranty details are not provided in this manual, we strive for customer satisfaction. If you experience any issues with your Lynnoland Clear Glass Shade Cylinder, please contact Lynnoland customer service through the retailer where you purchased the product or visit the official Lynnoland website for support information.

For assistance, please have your model number (N19016SG01) and purchase details ready.

