

[Manuals.plus](#) /

> [HOMCOM](#) /

> HOMCOM Kitchen Hutch Model 835-330GY Instruction Manual

HOMCOM 835-330GY

HOMCOM Kitchen Hutch Model 835-330GY Instruction Manual

Date: 2024-05-07

PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, setup, operation, and maintenance of your HOMCOM Kitchen Hutch, Model 835-330GY. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.





Image: The HOMCOM Kitchen Hutch, a tall grey cabinet with glass-framed upper doors, an open middle section for a microwave, and solid lower doors, situated in a modern dining room.

SAFETY INFORMATION

- Always assemble the unit on a soft, clean surface to prevent scratches and damage to components.
- Ensure all screws and fasteners are securely tightened before and during use. Periodically check for loose connections.
- Do not overload shelves. Refer to the 'Specifications' section for the overall weight capacity.
- Use the provided anti-tipping device to securely anchor the cabinet to a wall. This is crucial for stability and preventing accidents, especially in households with children or pets.



Image: A detailed view showing the anti-tipping device attached to the top rear of the hutch and secured to the wall, emphasizing safety.

PACKAGE CONTENTS

Verify all components are present and undamaged before beginning assembly. Refer to the separate assembly guide for a complete list of parts and hardware with corresponding labels.

- Cabinet panels (numbered)
- Hardware (screws, dowels, hinges, handles - lettered)
- Adjustable shelves
- Glass-framed doors
- Solid doors
- Anti-tipping device
- Assembly instructions (separate document)

ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have two people for assembly due to the size

and weight of the components. A screwdriver and hammer may be required (not included).

1. Unpack all components and lay them out on a clean, soft surface. Identify each part using the provided labels (numbers for panels, letters for hardware).
2. Follow the step-by-step diagrams in the separate assembly guide. Pay close attention to the orientation of each panel and the correct hardware for each step.
3. Securely fasten all connections. Do not overtighten screws, as this can damage the engineered wood.
4. Install the adjustable shelves into the desired positions within the lower cabinet.
5. Attach the doors and adjust hinges for proper alignment, ensuring they close flush.



Image: An illustration demonstrating how to adjust cabinet hinges for vertical, horizontal, and depth alignment, ensuring doors close flush.

Note: If assembly instructions were not included in your package, please contact customer support for a digital copy.

SETUP

Choosing the correct location and securing the hutch are important steps for long-term use.

Placement

- Position the hutch against a sturdy wall where the anti-tipping device can be securely installed.
- Ensure the floor surface is level to prevent wobbling. Use shims if necessary.
- Allow adequate space around the unit for doors to open fully and for comfortable access to contents.

Anti-Tipping Device Installation

For safety, it is mandatory to install the anti-tipping device.

1. Locate the anti-tipping strap and associated hardware (screws, wall anchor).
2. Attach one end of the strap to the pre-drilled hole on the top rear of the hutch using the provided screw.
3. Move the hutch to its final position. Mark the wall at the appropriate height, ensuring the strap is taut but not overly stretched.
4. Drill a pilot hole in the wall at the marked spot. Insert the wall anchor if your wall material requires it (e.g., drywall).
5. Secure the other end of the strap to the wall using the remaining screw.
6. Gently pull the hutch forward to verify that the anti-tipping device is securely installed and prevents the unit from tipping.

OPERATING INSTRUCTIONS

Your HOMCOM Kitchen Hutch is designed for versatile storage and organization.

Storage Compartments

The hutch features various storage areas designed for kitchen essentials:

- **Upper Glass-Framed Cabinets:** Ideal for displaying glassware, dishes, or frequently used items. The glass doors protect contents from dust while keeping them visible.
- **Open Microwave Space:** This central compartment is designed to accommodate most standard microwaves or other small kitchen appliances like coffee makers or toasters.
- **Lower Solid Cabinets:** Suitable for storing larger items, pots, pans, bulk supplies, or items you prefer to keep out of sight.





Image: The hutch with its doors open, showcasing ample storage space for various kitchen items, including a microwave, coffee maker, and other appliances.

Adjustable Shelves

The shelves within the lower cabinet are adjustable to customize your storage space according to the height of your items.

1. Empty the shelf you wish to adjust.
2. Carefully lift the shelf and remove the support pegs from their current holes.
3. Reinsert the support pegs into the desired new holes, ensuring they are level and fully seated.
4. Place the shelf back onto the pegs.

CABLE MANAGEMENT SYSTEM

Prevent your wires from being tangled efficiently



Image: A close-up of the lower cabinet illustrating the adjustable and removable shelves, with numbered holes indicating various height options for customized storage.

Cable Management System

A dedicated circular cutout for cable management is located in the back panel of the microwave space. This feature helps to keep appliance cords organized, tidy, and out of sight, contributing to a cleaner aesthetic and safer environment.



AMPLE STORAGE SPACE

Ideal storage space for your coffee maker, microwave oven, and utensils.

Image: A detailed view of the cable management system, showing a circular opening in the back panel of the microwave compartment to prevent tangled wires.

MAINTENANCE

Proper care and maintenance will extend the life and appearance of your kitchen hutch.

Cleaning

- Wipe all surfaces with a dry, soft cloth regularly to remove dust and light smudges.
- For stubborn marks or spills, use a slightly damp cloth with a small amount of mild, non-abrasive soap. Immediately dry the surface with a clean, dry cloth.
- Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish and material.

Hinge Adjustment

If doors become misaligned or do not close properly over time, use a Phillips head screwdriver to adjust the hinges. Refer to the hinge adjustment diagram in the 'Assembly Instructions' section for guidance on making vertical, horizontal, and depth adjustments to ensure doors are flush and operate smoothly.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Loose Connections

- **Issue:** The hutch feels wobbly or parts seem loose.
- **Solution:** Periodically check all screws and fasteners throughout the unit and tighten them as needed to maintain structural integrity and stability.

Door Misalignment

- **Issue:** Doors do not close flush, are uneven, or rub against the frame.
- **Solution:** Adjust the door hinges using a screwdriver as detailed in the 'Maintenance' section. Small adjustments can significantly improve door alignment.

Stability Issues

- **Issue:** The hutch rocks or feels unstable.
- **Solution:** Ensure the hutch is placed on a level surface. If the floor is uneven, use furniture shims under the base. Confirm the anti-tipping device is correctly installed and securely anchored to the wall.

SPECIFICATIONS

Feature	Detail
Model Number	835-330GY
Overall Dimensions	28.75" W x 16.25" D x 70" H
Material	Engineered Wood
Color	Grey
Overall Weight Capacity	66 lbs
Number of Doors	4 (2 glass-framed, 2 solid)
Adjustable Shelves	Yes (in lower cabinet)
Special Features	Cable Management System, Anti-Tipping Device
Assembly Required	Yes



Image: A diagram illustrating the key dimensions of the kitchen hutch, including its overall height, width, and depth.

OFFICIAL PRODUCT VIDEO

Watch the official product video for a visual overview of the HOMCOM Kitchen Hutch features and design.

Your browser does not support the video tag.

Video Description: An official HOMCOM video showcasing the kitchen hutch in various settings, highlighting its storage capabilities, design, and features like adjustable shelves and cable management.

WARRANTY AND SUPPORT

Warranty Information

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the HOMCOM official website for detailed terms and conditions regarding coverage and duration.

Customer Support

For any questions, missing parts, or assistance with assembly or product issues, please contact HOMCOM customer support. Have your model number (835-330GY) and purchase date ready when contacting

support.

- **Website:** www.aosom.com (Aosom is the parent company of HOMCOM)
- **Email:** Refer to the product packaging or official website for contact email.
- **Phone:** Refer to the product packaging or official website for contact phone number.