

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Automatic Mechanical Watch Model 2020 User Manual

OLEVS 2020

OLEVS Automatic Mechanical Watch Model 2020 User Manual

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your OLEVS Automatic Mechanical Watch, Model 2020.

INTRODUCTION

Thank you for choosing the OLEVS Automatic Mechanical Watch. This timepiece combines classic design with precise automatic movement. Please read this manual carefully to ensure proper use and care of your watch.



Image: Front view of the OLEVS Automatic Mechanical Watch with a black steel band and black face, showcasing the intricate dial details.

SETUP: INITIAL WINDING AND TIME/DATE SETTING

Before wearing your watch for the first time, or if it has stopped, it must be manually wound to ensure correct and precise function. The watch is powered by an automatic mechanical movement and does not require a battery.



Initial Winding

1. Ensure the crown is in its normal position (Position 1).
2. Turn the crown clockwise 30-40 times. This will manually wind the mainspring.

3. For continuous operation, the watch should be worn for at least 8 hours per day. If not worn regularly, manual winding may be required periodically.

WEARING THE AUTOMATIC WATCH FOR THE FIRST TIME

Before being worn for the first time, or if it has stopped, an automatic watch must be wound manually in order to function correctly and precisely. To wind the watch manually, turn the crown clockwise **30 - 40 times** while it is in its normal position (position 1). A minimum of 30 turns is required for adequate partial winding. The automatic watch should be worn **at least 8 hours** daily. If the watch stops completely, loses time or ticks erratically, you must wind it manually.



SETTING THE TIME

1. Pull the crown out one click (position 2).
2. Slowly rotate the crown until the hour and minute hands are in the correct position for the current time.
NOTE: AM / PM can be determined from the position of the 24 hour time and the Sun / Moon indicator on the sub-dial at the 6 o'clock position.
3. Push the crown in one click, to the normal position (position 1).

SETTING THE DATE AND DAY

NOTE: DO NOT set the Date and Day between 9 PM and 3 AM. Setting the Date and Day during this time period will damage the watch movement.

1. Push button B to advance the date hand to the correct day of the month.
2. Click button D to advance the date hand to the correct day of the week.

SETTING THE MONTH AND YEAR

1. Push button A to advance the Month display to the correct Month.
2. Click button C to advance the Year display to the correct Year.

Image: Diagram illustrating the watch crown positions (1 and 2) and the functions of the push buttons (A, B, C, D) for adjusting the month, date, day, and moon phase.

Setting the Time

1. Pull the crown out one click to Position 2.
2. Rotate the crown slowly until the hour and minute hands are in the correct position for the current time.
3. Note: AM/PM can be determined by observing the 24-hour time and the Sun/Moon indicator on the sub-dial at the 6 o'clock position.
4. Push the crown back into its normal position (Position 1).

Setting the Date and Day

IMPORTANT: Do not set the Date and Day between 9 PM and 3 AM. Setting during this period may damage the watch movement.

1. Push button B to advance the date hand to the correct day of the month.
2. Push button D to advance the day hand to the correct day of the week.

Setting the Month and Year

1. Push button A to advance the Month display to the correct Month.
2. Push button C to advance the Year display to the correct Year.

OPERATING YOUR WATCH

Your OLEVS Automatic Mechanical Watch features several sub-dials and indicators for comprehensive timekeeping.



Image: Detailed diagram of the watch face highlighting the functions of the sub-dials: 24-hour Sun/Moon/Stars indicator (at 12 o'clock), Calendar pointer (at 3 o'clock), Week pointer (at 9 o'clock), and the visible Hollow Flywheel (at 6 o'clock).

- **24-hour Sun, Moon and Stars Indicator:** Located at the 12 o'clock position, this sub-dial displays the 24-hour cycle, indicating day (sun) and night (moon and stars).
- **Calendar Pointer:** Positioned at 3 o'clock, this sub-dial indicates the date of the month.
- **Week Pointer:** Found at the 9 o'clock position, this sub-dial displays the day of the week.
- **Hollow Flywheel:** Visible at the 6 o'clock position, this feature showcases the intricate mechanical movement of the watch.

Your browser does not support the video tag.

Video: A demonstration of the OLEVS Automatic Mechanical Watch, showcasing its design, movement, water resistance, and luminous features from various angles.

MAINTENANCE AND CARE

Proper care will ensure the longevity and performance of your OLEVS watch.

- **Water Resistance:** This watch is 3ATM (30 meters) water-resistant. This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in water (e.g., hand washing). It is not suitable for swimming, diving, or showering with hot water. Avoid operating the crown or push buttons when the watch is wet.
- **Cleaning:** Clean the watch case and stainless steel strap with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Extreme Conditions:** Protect your watch from extreme temperatures, strong magnetic fields, and harsh chemicals.
- **Storage:** When not wearing the watch, store it in a cool, dry place away from direct sunlight.
- **Luminous Function:** The watch features luminous hands and markers for readability in low-light conditions. Exposure to light will charge the luminous material.



Image: A composite image highlighting key features: water resistance, high-hardness coated glass, durable stainless steel strap, and luminous dial for visibility in the dark.

TROUBLESHOOTING

If you encounter issues with your OLEVS Automatic Mechanical Watch, please refer to the following common solutions:

- **Watch Stops or Loses Time:**

- As an automatic watch, it relies on wrist movement for power. Ensure you wear the watch for at least 8 hours daily.
- If the watch has stopped completely or is losing time, manually wind it by turning the crown clockwise 30-40 times (as described in the "Initial Winding" section).

- **Date/Day Not Changing Correctly:**

- Ensure the time is set correctly, especially the AM/PM cycle, as the date/day change typically occurs around midnight.
- Avoid adjusting the date/day between 9 PM and 3 AM to prevent damage to the movement.

- **Bracelet Adjustment:** The watch comes with a strap adjustment tool. If you need to adjust the bracelet size, use the provided tool to remove or add links. If you do not have the tool, a small push pin can often be used to depress the pins in the links.

SPECIFICATIONS

Key specifications for the OLEVS Automatic Mechanical Watch Model 2020:

PRODUCT PARAMETERS

Case material	Alloy
Strap material	Stainless Steel
Mirror material	Hardness Coated Glass
Bottom cover material	304 Steel
Case diameter	42mm
Case thickness	12.5mm (Including Glass)
Strap width	20MM
Watch length	220MM
Waterproof	30m
weight	152g



Dial width: 42MM



Dial thickness: 12.5MM



Band Width: 20MM



Watch length: 220MM

Image: A table detailing the product specifications of the OLEVS watch, including dimensions, materials, and water resistance.

Product Parameters

Feature	Detail
Product Dimensions	8.66 x 1.65 x 0.31 inches
Weight	5.36 ounces (152g)
Item Model Number	2020

Feature	Detail
Case Material	Alloy
Strap Material	Stainless Steel
Mirror Material	Hardness Coated Glass
Bottom Cover Material	304 Steel
Case Diameter	42mm
Case Thickness	12.5mm (Including Glass)
Strap Width	20mm
Watch Length	220mm
Waterproof Rating	30m (3ATM)
Movement	Automatic Mechanical, 21 Rubies, 21,600 beats/hour, >45 hours power reserve

WARRANTY AND PROTECTION PLANS

Your OLEVS watch is designed for durability and precision. For information regarding manufacturer warranty, please refer to the documentation included with your purchase or contact the seller directly.

Extended protection plans may be available for purchase separately to cover your watch beyond any standard manufacturer's warranty. These plans typically offer additional coverage for accidental damage or mechanical failures. Please check the product listing or your purchase details for available options:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect: Monthly plan covering eligible purchases.

SUPPORT AND CONTACT INFORMATION

For further assistance, questions, or concerns regarding your OLEVS Automatic Mechanical Watch, please contact the seller or refer to the official OLEVS brand store.

Seller: XIN LINGYU

OLEVS Brand Store: [Visit the OLEVS Store on Amazon](#)

