

Manuals.plus /

- › Lysee /
- › Lysee Mobile Phone Touch Panel Instruction Manual

Lysee L36H C6603 C6602 C6606

Lysee Mobile Phone Touch Panel Instruction Manual

Model: SONY Xperia Z L36H C6603 C6602 C6606 | Brand: Lysee

PRODUCT OVERVIEW

This manual provides detailed instructions for the installation, operation, and maintenance of your Lysee 5-inch Original Display Touch Panel for SONY Xperia Z series mobile phones. This product is designed as a replacement part for damaged or non-functional screens, ensuring your device returns to optimal performance.




Image: The Lysee 5-inch Original Display Touch Panel for SONY Xperia Z, shown alongside the various tools provided for installation, including screwdrivers, prying tools, and a suction cup.

SETUP AND INSTALLATION

Replacing a mobile phone display requires careful handling and appropriate tools. It is recommended that this procedure be performed by individuals with experience in electronics repair. Ensure your phone is powered off and disconnected from any power source before beginning.

Required Tools (Included):

- Precision Screwdrivers
- Plastic Pry Tools
- Suction Cup
- SIM Ejector Pin



Image: The Lysee 5-inch Original Display Touch Panel (left) shown detached from its frame (right), illustrating the two main components of the replacement part.

Installation Steps:

1. **Power Off Device:** Completely power down your SONY Xperia Z phone.
2. **Remove SIM Tray:** Use the SIM ejector pin to remove the SIM card tray.
3. **Open Phone Casing:** Carefully use the suction cup and plastic pry tools to open the phone's back casing. Proceed with caution to avoid damaging internal components or cables.
4. **Disconnect Battery:** Locate and disconnect the battery connector to prevent short circuits during the repair.
5. **Remove Old Display:** Disconnect the flex cables connecting the old display to the motherboard. Carefully remove the old display assembly from the phone frame.
6. **Clean Frame:** Ensure the phone's frame is clean and free of any adhesive residue from the old display.
7. **Connect New Display:** Carefully connect the flex cables of the new Lysee display to the corresponding connectors on the motherboard.
8. **Test Display:** Before fully securing the new display, temporarily reconnect the battery and power on the phone to test the display and touch functionality. Ensure there are no dead pixels, lines, or touch response issues.
9. **Secure New Display:** If the test is successful, disconnect the battery again. Apply appropriate adhesive (not included) around the frame and carefully seat the new display.
10. **Reassemble Phone:** Reconnect the battery, reattach the back casing, and reinsert the SIM tray.

Note: Professional installation is highly recommended. Improper installation can lead to damage to the product or your device, which may not be covered under warranty.

OPERATING THE DISPLAY

Once the Lysee display is successfully installed, your SONY Xperia Z phone will operate as normal. The display provides the visual interface and touch input for your device.

- **Touch Sensitivity:** The display is designed to provide accurate and responsive touch input.
- **Display Quality:** Expect clear visuals and vibrant colors, consistent with the original display specifications.
- **Testing:** After installation, navigate through menus, open applications, and test multi-touch gestures to ensure full functionality.



Image: A SONY Xperia Z phone with the Lysee display installed, powered on and showing the device's home screen with various application icons, demonstrating full operational capability.

MAINTENANCE

Proper care of your new display will extend its lifespan and maintain its visual quality.

- **Cleaning:** Use a soft, lint-free cloth (e.g., microfiber) to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-specific cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Protection:** Consider using a screen protector (tempered glass or film) to guard against scratches and minor impacts.
- **Avoid Pressure:** Do not apply excessive pressure to the screen, as this can damage the LCD or digitizer.
- **Temperature Extremes:** Avoid exposing the phone to extreme temperatures, which can affect display performance and longevity.

TROUBLESHOOTING

If you encounter issues after installing the Lysee display, refer to the following common troubleshooting steps:

- **Display Not Turning On:**

- Ensure all flex cables are securely connected to the motherboard.
- Verify the battery is properly connected and charged.
- Perform a hard reset on your phone (refer to your phone's original manual for instructions).

- **Touch Not Responding or Inaccurate:**

- Check the digitizer flex cable connection.
- Ensure there is no debris or foreign objects between the display and the phone frame.
- Restart the phone.

- **Lines or Discoloration on Screen:**

- This may indicate a damaged flex cable or an issue with the display panel itself. Recheck connections.
- If the issue persists after rechecking connections, the display unit may be faulty.

If troubleshooting steps do not resolve the issue, contact Lysee customer support or a qualified repair technician.

SPECIFICATIONS

Feature	Detail
Brand	Lysee
Compatible Model	SONY Xperia Z L36H C6603 C6602 C6606
Type	LCD Touch Screen with Frame
Display Size	5 inches
Color (Product)	Purple (as per listing)
Unit Count	1.0 Count
ASIN	B08TLK4Z8B



Image: The packaging box for "Mobile Phone Spare Parts," indicating the type of product and potential contents like LCD Digitizer, Touch Panel, and Repair Tools.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the seller's policy or contact Lysee customer service directly. Keep your purchase receipt as proof of purchase.

Seller: GOODSBUY STORE

Return Policy: 30 days for refund/replacement (as per Amazon listing at time of purchase).