

Power Rangers F3308

Power Rangers Dino Fury 5 Team Multipack Action Figure Toys Instruction Manual

1. INTRODUCTION

This manual provides instructions for the Power Rangers Dino Fury 5 Team Multipack action figures. This set allows users to recreate action scenes and engage in imaginative play with the five core Dino Fury Power Rangers.

2. WHAT'S INCLUDED

The Power Rangers Dino Fury 5 Team Multipack includes the following components:

- Five (5) 6-inch Power Rangers Dino Fury action figures (Red, Blue, Pink, Green, Black)
- Five (5) Chromafury Saber weapon accessories
- Five (5) Dino Fury Key accessories
- One (1) Dino Fury Battle Belt buckle



Image: The Power Rangers Dino Fury 5 Team Multipack, showing the five action figures, their respective Chromafury Sabers, Dino Fury Keys, and the Dino Fury Battle Belt buckle, all within their packaging.

3. SETUP

To prepare your Power Rangers figures for play:

1. Carefully remove each figure and its accessories from the packaging.
2. Attach the Chromafury Saber weapon to the hand of each corresponding Power Ranger figure. The sabers are designed to fit securely.
3. The Dino Fury Battle Belt buckle can be used to store the Dino Fury Key accessories. Open the buckle and insert the keys as desired.

4. OPERATING THE FIGURES

The Power Rangers action figures are designed for dynamic play:

- **Articulation:** Each 6-inch figure features multiple points of articulation, allowing for various poses and action stances. Gently bend and rotate the limbs at the joints to achieve desired positions.
- **Chromafury Sabers:** The included sabers are designed to be held by the figures for battle scenarios.
- **Dino Fury Keys:** These keys are inspired by the TV series and can be used with the Dino Fury Morpher (sold separately) to unlock sounds.

- **Dino Fury Battle Belt:** The belt buckle accessory provides storage for the Dino Fury Keys.

Your browser does not support the video tag.

Video: A product overview demonstrating the Power Rangers Dino Fury 5 Team Multipack, showcasing the figures, accessories, and their features.

5. MAINTENANCE

To ensure the longevity of your Power Rangers figures:

- **Cleaning:** Wipe figures and accessories with a soft, dry cloth. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store figures and accessories in a cool, dry place away from direct sunlight to prevent discoloration or damage.

6. TROUBLESHOOTING

If you encounter any issues with your figures:

- **Stiff Joints:** Some figures may have stiff joints initially. Gently manipulate the joints to loosen them. Avoid excessive force to prevent breakage.
- **Missing Accessories:** Verify all included components against the 'What's Included' section. If an accessory is missing, contact customer support.

7. SPECIFICATIONS

- **Brand:** Power Rangers
- **Model Number:** F3308
- **Figure Size:** 6-inch (approximately 15 cm)
- **Material:** Plastic
- **Operation Mode:** Manual
- **Assembly Required:** No
- **Batteries Required:** No
- **Recommended Age:** 5 years and up



Image: A Power Rangers Dino Fury Red Ranger figure, illustrating its approximate 6-inch height.

8. SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years. Adult supervision is recommended during play.

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please refer to the manufacturer's official website or contact their customer service department. Specific warranty terms may vary by region and retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question