

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FLEXISPOT](#) /

› [FLEXISPOT 48x24 Inch White Whole Piece Desktop Instruction Manual](#)

FLEXISPOT 48x24 White

FLEXISPOT 48x24 Inch White Whole Piece Desktop Instruction Manual

Model: 48x24 White

1. PRODUCT OVERVIEW

The FLEXISPOT 48x24 inch white whole piece desktop is designed to provide a durable and aesthetically pleasing work surface for your adjustable standing desk frame. This desktop features a 1-inch thickness, soft rounded corners, and a scratch-resistant high-pressure laminate finish. It is constructed from environmentally friendly medium-density fiberboard, meeting CARB and FSC standards.



Image 1.1: FLEXISPOT 48x24 inch white desktop, showcasing its clean, minimalist design.

2. SAFETY INFORMATION

Important:

- Ensure proper assembly and anchoring to avoid tipping.
- Handle with care to prevent damage during unpacking and installation.

3. SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model	48x24 White

Shape	Rectangular
Product Dimensions	24"D x 48"W x 1"H
Color	White
Tabletop Thickness	1 Inches
Top Material Type	Engineered Wood (Chipboard, Medium-Density Fiberboard)
Finish Type	Laminated (Scratch Resistant)
Environmental Standards	Meets CARB and FSC standards
Required Assembly	Yes
Recommended People for Assembly	2



Image 3.1: Visual representation of the desktop's dimensions (48"W x 24"D x 1"H) and rounded corners.

4. SETUP

This product is a desktop only and requires a compatible standing desk frame for full functionality. Assembly of the desktop to your chosen frame is required. It is recommended that two people perform the assembly to ensure safety and proper alignment.

4.1 Unpacking and Inspection

- Carefully unpack all components and inspect for any damage.
- Ensure all parts listed in your desk frame's manual are present before beginning assembly.

4.2 Attaching to a Desk Frame

Refer to the assembly instructions provided with your specific FLEXISPOT standing desk frame for detailed steps on attaching this desktop. Typically, this involves:

1. Placing the desktop upside down on a soft, clean surface.
2. Aligning the desk frame with the pre-drilled holes (if applicable) or marking new pilot holes.
3. Securing the desktop to the frame using the provided screws and tools from your desk frame kit.



Image 4.1: The FLEXISPOT desktop is designed for DIY integration with various standing desk frames, allowing for personalized workspace creation.

5. OPERATING

Once assembled with a compatible standing desk frame, the desktop functions as your primary work surface. Its whole-piece design ensures a seamless and stable area for your equipment.

5.1 Height Adjustment

The height adjustment of your desk will be controlled by the mechanism of your chosen FLEXISPOT standing desk frame. Refer to your frame's manual for specific instructions on using its control panel, memory presets, and up/down functions.

Video 5.1: This video demonstrates the smooth height adjustment of a FLEXISPOT Classic Height Adjustable Standing Desk Series, which this desktop is compatible with. It shows the desk moving up and down quietly and efficiently.

5.2 Desktop Features

- **Whole Piece Design:** Provides a continuous, smooth surface without seams, enhancing stability and aesthetics.
- **Rounded Corners:** Softly rounded corners help reduce the possibility of bumps or bruises.
- **Scratch-Resistant Surface:** The high-pressure laminate finish offers enhanced durability against daily wear and tear.

Video 5.2: This video illustrates the stability and weight capacity of a FLEXISPOT computer workstation table, demonstrating its robust construction even under significant load.

6. MAINTENANCE

To ensure the longevity and appearance of your FLEXISPOT desktop, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface regularly with a soft, damp cloth. For tougher stains, use a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the laminate finish.
- **Protection:** While the surface is scratch-resistant, it is advisable to use coasters for drinks and desk pads for heavy or sharp objects to prevent potential damage.
- **Avoid Extreme Conditions:** Do not expose the desktop to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture.

7. TROUBLESHOOTING

This section addresses common concerns related to the desktop. For issues related to the adjustable desk frame mechanism, please refer to the troubleshooting guide provided with your specific frame.

7.1 Desktop Stability

If the desktop feels unstable, ensure that all screws attaching it to the desk frame are securely tightened. Also, verify that the desk frame itself is properly assembled and placed on a level surface.

7.2 Surface Damage

Minor scratches may be less visible due to the scratch-resistant laminate. For deeper scratches or chips, contact FLEXISPOT customer support for advice on repair options or replacement.

8. WARRANTY

The FLEXISPOT desktop comes with a limited warranty. For specific details regarding the warranty period and coverage, please refer to the warranty information provided with your purchase or visit the official FLEXISPOT website.

Additional protection plans may be available for purchase:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan)

9. SUPPORT

For further assistance, product inquiries, or to access additional resources, please visit the official FLEXISPOT store or contact their customer service.

Official FLEXISPOT Store: [Visit the FLEXISPOT Store](#)