

Raycon RBE775-23E-BLA

Raycon The Everyday Wireless Bluetooth Over Ear Headphones

Model: RBE775-23E-BLA | Brand: Raycon

INTRODUCTION

The Raycon The Everyday Headphones are designed to provide a superior audio experience with advanced features for daily use. These over-ear headphones offer active noise cancellation, an awareness mode, and a built-in microphone for clear communication. With a durable, water-resistant design and long battery life, they are suitable for various activities, from commuting to workouts.



Image: Raycon The Everyday Headphones, showcasing the sleek black design with silver accents.

WHAT'S IN THE BOX

Verify that all components are present in the packaging:

- Raycon The Everyday Headphones
- USB-C Charging Cable
- 3.5mm Audio AUX Cable
- Ear Cushions (pre-installed)
- Headband (pre-installed)
- Instruction Guide (this manual)

SETUP

Initial Charge

Before first use, fully charge your headphones. Connect the provided USB-C charging cable to the charging port on the headphones and to a compatible USB power source. A full charge provides up to 38 hours of battery life. A 15-minute charge can provide approximately 2 hours of playback.




Image: Headphones illustrating the 38-hour battery life and quick charge capability.

Bluetooth Pairing (2-Step Process)

1. **Power On:** Press and hold the power button on the headphones until the LED indicator flashes, indicating pairing mode.
2. **Connect:** On your device (smartphone, tablet, computer), go to Bluetooth settings and select "Raycon The Everyday Headphones" from the list of available devices. The LED indicator will turn solid when successfully paired.

The headphones support Bluetooth 5.0 with a range of up to 33 feet.



Image: Headphones demonstrating multipoint connection with a phone and laptop.

OPERATING INSTRUCTIONS

Controls Overview

The headphones feature intuitive controls located on the earcup:

Power Button (Middle Button):

- Press and hold for 3 seconds to Power On/Off.
- Short press once to Play/Pause audio.
- Short press once to Answer/End calls.

Volume Up (+) / Next Track:

- Short press to increase volume.
- Long press to skip to the next track.

Volume Down (-) / Previous Track:

- Short press to decrease volume.
- Long press to go to the previous track.

Noise Control Button (Separate Button):

- Short press to toggle between Active Noise Cancellation (ANC) On, Awareness Mode, and ANC Off.



Image: Detailed view of the control buttons on the right earcup.

Active Noise Cancellation (ANC)

ANC technology uses audio-neutralizing algorithms to reduce ambient noise, allowing for an immersive listening experience without external distractions. Activate ANC for environments with consistent background noise.



Image: Visual representation of Active Noise Cancellation blocking sound waves.



ACTIVE NOISE CANCELLING

Block out noise and
immerse yourself in
superior sound
anywhere.

Image: A person wearing the headphones, highlighting the Active Noise Cancelling feature.

Awareness Mode

Awareness Mode allows you to hear your surroundings while still enjoying your audio. This is useful for situations where you need to be aware of your environment, such as walking in a city or listening for announcements.



Image: Visual representation of Awareness Mode allowing ambient sound to pass through.

AWARENESS MODE

Never miss a
beat and stay
intune with the
surroundings.



Image: A person wearing the headphones, demonstrating the Awareness Mode feature.

Wired Connection

For devices without Bluetooth or when battery is low, use the included 3.5mm audio AUX cable. Plug one end into the headphone's 3.5mm jack and the other into your audio device's output.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The headphones are IPX4 water-resistant, meaning they are protected against splashing water from any direction. Do not submerge them in water.
- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.



Image: Raycon headphones shown in their folded, portable configuration.

TROUBLESHOOTING

Problem	Solution
Headphones not turning on	Ensure the headphones are fully charged.

Problem	Solution
Cannot pair via Bluetooth	<ul style="list-style-type: none">◦ Ensure headphones are in pairing mode (flashing LED).◦ Turn off and on Bluetooth on your device.◦ Forget the device in your Bluetooth settings and try pairing again.◦ Ensure headphones are within 33 ft range of your device.
No sound or low volume	<ul style="list-style-type: none">◦ Increase volume on both headphones and connected device.◦ Ensure headphones are properly paired.◦ If using wired connection, ensure cable is fully inserted and not damaged.
Active Noise Cancellation not working	Press the Noise Control button to cycle through modes and ensure ANC is activated.

SPECIFICATIONS

- **Model Name:** The Everyday Headphones - Carbon Black
- **Model Number:** RBE775-23E-BLA
- **Connectivity:** Wireless, Bluetooth 5.0
- **Noise Control:** Active Noise Cancellation, Awareness Mode
- **Battery Life:** Up to 38-40 Hours Playback
- **Quick Charge:** 15 minutes for 2 hours playback
- **Drivers:** 40mm
- **Water Resistance:** IPX4
- **Headphones Jack:** 3.5 mm Jack
- **Built-in Microphone:** Yes
- **Weight:** 0.47 Pounds (approx. 7.5 ounces)
- **Dimensions:** 6.25 x 3.25 x 8 inches
- **Material:** Plastic (headband), Hard Shell (carrying case, if included)


OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product overview of the Raycon The Everyday Headphones, highlighting key features and design.

For warranty information and customer support, please refer to the official Raycon website or contact their customer service directly. Details regarding product registration, troubleshooting assistance, and warranty claims can be found through these channels.

© 2025 Raycon Inc. All rights reserved.



lang:en score:21 filesize: 1.46 M page_count: 27 document date: 2023-07-20