

[Manuals.plus](#) /

› [Instant Pot](#) /

› Instant Pot Pro Plus Wi-Fi Smart 10-in-1, Pressure Cooker, Slow Cooker, Rice Cooker, Steamer, Saut Pan, Yogurt Maker, Warmer, Canning Pot, Sous Vide, Includes App with Over 800 Recipes, 6 Quart Black

Instant Pot 112-0124-01

Instant Pot Pro Plus Wi-Fi Smart 10-in-1 Multi-Cooker User Manual

Model: 112-0124-01

INTRODUCTION

The Instant Pot Pro Plus Wi-Fi Smart 10-in-1 Multi-Cooker is a versatile kitchen appliance designed to simplify your cooking process. It combines the functions of a pressure cooker, slow cooker, rice cooker, steamer, saut pan, yogurt maker, warmer, canning pot, and sous vide, all in one device. With intuitive touchscreen controls and Wi-Fi connectivity, you can monitor and control your cooking from anywhere using the Instant Connect App.



Image: Instant Pot Pro Plus Wi-Fi Smart 10-in-1 Multi-Cooker with a smartphone displaying the Instant Connect App interface.

SETUP

Unboxing and Components

Upon unboxing your Instant Pot Pro Plus, ensure all components are present:

- Instant Pot Pro Plus 6-quart base unit
- Stainless-steel inner cooking pot with silicone handles
- Pressure cooker lid with steam release valve
- Stainless-steel steam rack
- Extra sealing ring

2000+ Guided Smart Recipes

Easy step-by-step instructions on the free **Instant Brands Connect App**




Image: Instant Pot Pro Plus with its lid, inner pot, and steam rack displayed separately.

First Use and Cleaning

Before first use, wash the inner cooking pot and accessories with warm, soapy water. The inner pot and accessories are dishwasher-safe for quick cleanup. Wipe the exterior of the base unit with a damp cloth.


Instant Connect App Setup

The Instant Pot Pro Plus features Wi-Fi connectivity, allowing for smart guided cooking and remote control via the Instant Connect App. Download the free app from your device's app store.

**FREE on Apple & Google Play
App Stores:**



**INSTANT BRANDS®
CONNECT APP**



- **Free app with 2000+ recipes**
- **Guided step-by-step cooking instructions**
- **Save and organize recipes into collections**

Image: A smartphone displaying the Instant Brands Connect App logo and features.

Pair your Instant Pot with the app to access over 2,000 smart recipes with step-by-step instructions, monitor cooking progress, adjust settings, and even release steam remotely.

Your browser does not support the video tag.

Video: An overview of the Instant Pot Pro Plus features, including its smart capabilities and app integration.

Your browser does not support the video tag.

Video: A short promotional video highlighting the Wi-Fi features of the Instant Pot Pro Plus.

OPERATING INSTRUCTIONS

10 Cooking Functions

The Instant Pot Pro Plus offers 10 versatile cooking functions:

- **Pressure Cook:** For fast cooking under pressure.
- **Slow Cook:** For traditional slow-cooked recipes.
- **Saut :** For searing, browning, or simmering.
- **Steam:** For steaming vegetables, fish, and more.
- **Sous Vide:** For precision cooking in a water bath.
- **Can:** For home canning.
- **Rice:** Dedicated program for perfect rice.
- **Yogurt:** For making homemade yogurt.
- **NutriBoost:** Pulses gently while cooking to mix ingredients, enhancing texture and flavor.
- **Warm:** To keep food warm after cooking.

10 in 1 Cooking Functions



PRESSURE COOK



SLOW COOK



RICE



SAUTÉ



STEAM



YOGURT



SOUS VIDE



CANNING



WARMER



NUTRIBOOST

Image: Visual representation of the 10 cooking functions of the Instant Pot Pro Plus.

Controls and Display

The appliance features a large, easy-to-read display and intuitive touchscreen controls. Use the central dial to navigate menus and

adjust settings. The display provides real-time information on cooking progress, temperature, and pressure.

Smart Guided Cooking

Utilize the Instant Connect App for a seamless cooking experience. The app offers over 2,000 interactive recipes with step-by-step instructions. It automatically activates each step and provides tips for consistent results.



Guided Cooking

The step-by-step guide automatically activates each step, and offers tips, ensuring you get consistent results.

Image: A hand interacting with the Instant Pot App for guided cooking instructions.

Steam Release

The WhisperQuiet technology minimizes noise during steam release. You can release steam effortlessly and safely using the one-touch button on the control panel or directly from the Instant Connect App. Choose from Natural, Pulse, or Quick release methods.

Steam release from the app

Select from Natural, Pulse, and Quick



Image: A close-up of the Instant Pot's steam release valve and a smartphone screen showing steam release options in the app.

MAINTENANCE

Cleaning and Care

For quick and painless cleanup, the inner pot and accessories are dishwasher-safe. The exterior of the base unit should be wiped clean with a damp cloth. Always ensure the heating element area is clean and dry before use.

TROUBLESHOOTING

For common issues and error codes, please refer to the comprehensive troubleshooting guide available in the official product manual. A digital copy of the manual can be found [here](#).

SPECIFICATIONS

Feature	Detail
Brand	Instant Pot
Model Number	112-0124-01
Capacity	6 Quarts
Material	Stainless steel
Color	Black
Wattage	1500 watts
Item Weight	15.54 Pounds
Product Dimensions	13.2"D x 13"W x 12.7"H
UPC	810028582200

WARRANTY AND SUPPORT

Warranty Information

The Instant Pot Pro Plus comes with a One (1) Year Limited Warranty.

Customer Support

For additional support, product registration, or to explore more recipes, visit the official [Instant Pot Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question