

[Manuals.plus](#) /

> [Titleist](#) /

> Titleist Pro V1 Golf Balls Instruction Manual

Titleist Titleist Pro V1 AIM (T2027S-AIM)

Titleist Pro V1 Golf Balls Instruction Manual

Model: Titleist Pro V1 AIM (T2027S-AIM)

INTRODUCTION

This manual provides essential information for the proper use and care of your Titleist Pro V1 Golf Balls. The Titleist Pro V1 is engineered for total performance, offering a combination of distance, spin, and feel to enhance your golf game. Key features include:

- Longer Distance with Consistent Flight
- Very Low Long Game Spin and Penetrating Trajectory
- Increased Drop-and-Stop Short Game Control
- Softer Feel

The advanced technology incorporated includes a Softer Cast Urethane Elastomer Cover System, a Faster Low Spin Casing Layer, a Reformulated 2.0 ZG Process Core, and a New Spherically-Tiled 388 Tetrahedral Dimple Design.

PRODUCT OVERVIEW




Figure 1: Titleist Pro V1 Golf Balls in their retail packaging, showcasing the brand logo and product name.




Figure 2: A close-up view of a single Titleist Pro V1 golf ball, highlighting the "PRO V1" alignment aid printed on its surface.



Figure 3: A detailed image of a Titleist Pro V1 golf ball, showing the number '1' printed below the Titleist logo, indicating it is a low number ball.




Figure 4: Side view of the Titleist Pro V1 golf ball packaging, displaying the product name and brand information.




Figure 5: The back of the Titleist Pro V1 golf ball packaging, illustrating the internal construction and technological features of the ball.



Figure 6: An exploded diagram showing the multi-layer construction of the Titleist Pro V1 golf ball, detailing its core, casing layer, and cover system.

SETUP

Titleist Pro V1 golf balls are ready for immediate use upon removal from their packaging. No assembly or special setup is required.

1. Unpack the golf balls from the sleeve.
2. Inspect each ball for any visible defects or damage before use.
3. Ensure the ball is clean before placing it on the tee or marking it on the green.

OPERATING INSTRUCTIONS

The Titleist Pro V1 golf ball is designed for optimal performance across all aspects of the game. Follow standard golf rules and etiquette when using the ball.

Driving and Long Game

- The Pro V1's reformulated core and casing layer contribute to longer distance and very low long game spin, resulting in a penetrating flight.
- For best results, strike the ball cleanly with appropriate club selection for your desired shot shape and distance.

Short Game and Greenside Control

- The softer cast urethane elastomer cover system provides increased Drop-and-Stop greenside control.
- Utilize the ball's spin characteristics for precise approach shots, chips, and pitches around the green.

Putting

- The softer feel of the Pro V1 provides excellent feedback on putts.
- Use the "AIM" alignment marking (if present on your specific ball) to assist with aiming on the green.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your Titleist Pro V1 golf balls.

- **Cleaning:** After each round, clean golf balls with a damp cloth to remove dirt, grass, and scuff marks. A mild soap can be used for stubborn stains. Rinse thoroughly.
- **Storage:** Store golf balls in a cool, dry place away from direct sunlight and extreme temperatures. Avoid prolonged exposure to very hot or very cold conditions, as this may affect performance.
- **Inspection:** Regularly inspect balls for cuts, deep scuffs, or deformities. Damaged balls can affect flight characteristics and should be replaced.

TROUBLESHOOTING

While Titleist Pro V1 golf balls are manufactured to high standards, performance issues can sometimes be attributed to external factors. This section addresses common concerns.

Problem	Possible Cause	Solution
Reduced Distance	Ball damage (cuts, deep scuffs) Improper club contact Extreme temperature exposure	Inspect ball for damage; replace if necessary. Review swing mechanics and club selection. Ensure proper storage conditions.
Inconsistent Flight/Trajectory	Ball damage (dents, deformities) Improper strike or swing path Wind conditions	Inspect ball for damage; replace if necessary. Focus on consistent ball striking. Account for environmental factors.
Excessive Scuffing/Wear	Impact with hard surfaces (cart paths, trees) Rough club grooves Normal wear and tear	Avoid hitting off hard surfaces. Ensure club grooves are clean and not excessively sharp. Replace balls as they show significant signs of wear.

SPECIFICATIONS

Attribute	Detail
Brand	Titleist
Model Name	Titleist Pro V1 AIM
Model Number	T2027S-AIM
Color	White

Attribute	Detail
Construction Type	Core with Urethane Elastomer Cover (Note: Amazon's 'Leather Cover' specification is generic; Pro V1 uses Urethane)
Number of Items	12 (One Dozen)
Item Diameter	1.68 Inches
Item Weight (per dozen)	16 ounces (approx. 0.45 kg)
Package Dimensions	7.4 x 4.88 x 3.19 inches
Package Weight	0.56 Kilograms
Country of Origin	Thailand
UPC	084984720116

WARRANTY INFORMATION

Titleist Pro V1 Golf Balls come with a **1 Year Limited Manufacturing Defect Warranty**.

This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accident, alteration, or normal wear and tear.

For warranty claims or further details, please contact Titleist customer support.

SUPPORT AND CONTACT INFORMATION

For additional support, inquiries, or to report issues, please refer to the official Titleist resources:

- **Official Website:** Visit the [Titleist official website](#) for product information, FAQs, and contact options.
- **Customer Service:** Refer to the contact section on the Titleist website for phone numbers or email support.
- **Brand Store:** Explore more products and information at the [Titleist Amazon Brand Store](#).