

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Varmilo](#) /

› [Varmilo VBS108 Lure Bot Mechanical Keyboard Instruction Manual](#)

Varmilo VBS108



Varmilo VBS108 Lure Bot Mechanical Keyboard

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Varmilo VBS108 Lure Bot Mechanical Keyboard. This keyboard is designed for versatility and durability, featuring triple mode connectivity (Bluetooth 5.0, 2.4GHz Wireless, and USB-C), high-quality PBT dye-sub keycaps, and Cherry MX Brown switches for a tactile typing experience. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your keyboard.



Figure 1: Varmilo VBS108 Lure Bot Mechanical Keyboard

Package Contents

Please ensure all items are present in the package:

- Varmilo VBS108 Lure Bot Mechanical Keyboard
- USB-C to USB-A Cable
- 2.4GHz Wireless Dongle (typically stored in the keyboard's battery compartment or a dedicated slot)
- Keycap Puller (may be included)
- User Manual (this document)

Setup

The Varmilo VBS108 offers three connectivity modes: USB-C wired, 2.4GHz wireless, and Bluetooth 5.0.

1. USB-C Wired Connection

1. Locate the USB-C port on the keyboard (usually on the top edge).
2. Connect one end of the provided USB-C cable to the keyboard.
3. Connect the other end (USB-A) to an available USB port on your computer.
4. The keyboard will be automatically recognized and ready for use.

2. 2.4GHz Wireless Connection

1. Locate the 2.4GHz wireless dongle.
2. Plug the dongle into an available USB port on your computer.
3. Ensure the keyboard is in 2.4GHz mode (refer to the keyboard's function key combinations or a physical switch if available).
4. The keyboard should connect automatically.

3. Bluetooth 5.0 Connection

1. Ensure the keyboard is in Bluetooth pairing mode. This typically involves holding down a specific Fn key combination (e.g., Fn + 1, Fn + 2, or Fn + 3 for different profiles) until an indicator light flashes. Consult your keyboard's specific key legend for Bluetooth pairing.
2. On your computer or device, open Bluetooth settings.
3. Search for new devices and select "Varmilo VBS108" or a similar name from the list.
4. Follow any on-screen prompts to complete the pairing process.

Operating

The Varmilo VBS108 keyboard includes various function key combinations for enhanced control.

Function Key Combinations (Fn + Key)

- **Fn + F1-F12:** Multimedia controls (play/pause, volume up/down, mute, etc.). Refer to the keycap legends for specific functions.
- **Fn + Win:** Lock/Unlock Windows key.
- **Fn + Left Alt:** Switch between macOS and Windows layouts (if supported).
- **Fn + Q/W/E:** Switch between Bluetooth profiles (if applicable).
- **Fn + R:** Switch to 2.4GHz wireless mode.
- **Fn + T:** Switch to USB-C wired mode.
- **Fn + Backlight Keys:** Adjust backlight brightness or effects (if applicable).

Adjustable Flip-out Feet

The keyboard features 3-stage adjustable flip-out feet on the underside, allowing you to customize the typing angle for ergonomic comfort.



Figure 2: Adjustable Flip-out Feet

Maintenance

Proper maintenance ensures the longevity and performance of your Varmilo keyboard.

Cleaning the Keyboard

- **Keycaps:** Use a keycap puller to carefully remove keycaps. Clean them with a mild soap solution and a soft cloth, then rinse thoroughly and air dry completely before reattaching.
- **Case:** Wipe the keyboard case with a soft, slightly damp, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Between Keys:** Use compressed air to remove dust and debris from between the key switches. A small brush can also be used for stubborn particles.



Figure 3: PBT Dye-Sub Keycaps

Troubleshooting

If you encounter issues with your Varmilo VBS108 keyboard, try the following solutions:

- **Keyboard not responding (Wired):** Ensure the USB-C cable is securely connected to both the keyboard and the computer. Try a different USB port or cable.
- **Keyboard not responding (Wireless/Bluetooth):**
 - Check the battery level.
 - Ensure the keyboard is in the correct mode (2.4GHz or Bluetooth).
 - For 2.4GHz, ensure the dongle is properly inserted and try a different USB port.
 - For Bluetooth, unpair and re-pair the keyboard with your device. Ensure your device's Bluetooth is enabled.
- **Keys not registering:** Remove the keycap and check for any obstructions around the switch. Clean the area with compressed air.
- **Intermittent connection:** Ensure there are no major sources of interference (e.g., other wireless devices) near the keyboard or dongle.
- **Firmware Update:** Check the official Varmilo website for any available firmware updates for your model, which can resolve known issues.

Specifications

Feature	Detail
Brand	Varmilo
Model	VBS108 Lure Bot

Connectivity Technology	Bluetooth 5.0, 2.4GHz Wireless, USB-C
Switch Type	Cherry MX Brown
Keycap Material	PBT Dye-Sub
Number of Keys	104
Compatible Devices	PC
Color	Cherry MX Brown (keyboard color scheme)
Special Feature	3-Stage Adjustable Flip-out Feet

Warranty and Support

Varmilo products are designed for quality and reliability. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official Varmilo website. You may also contact the retailer from whom you purchased the product for assistance.

© 2023 Varmilo. All rights reserved.