

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro Gaming Hungry Hungry Hippos Dino Edition Board Game Instruction Manual

Hasbro F1359

Hasbro Gaming Hungry Hungry Hippos Dino Edition Board Game Instruction Manual

Model: F1359

1. INTRODUCTION

The Hasbro Gaming Hungry Hungry Hippos Dino Edition is a classic marble-chomping game featuring four dinosaur characters. This game is designed for 2 to 4 players, ages 4 and up. The objective is to have your dinosaur gobble up the most marbles to win.




Image 1.1: Front view of the Hungry Hungry Hippos Dino Edition game box, showing a purple dinosaur eating marbles.

Game Contents:

- Game base
- 4 dinosaur characters
- 20 plastic marbles (19 yellow, 1 red)
- Marble storage cover
- Instructions

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts may be generated. Not for children under 3 years.

Please ensure all small parts, especially the marbles, are kept away from children under 3 years of age to prevent choking hazards.

3. SETUP

Follow these steps to assemble your Hungry Hungry Hippos Dino Edition game:

1. **Unpack Components:** Carefully remove all game pieces from the box. Ensure you have the game base, four dinosaur characters, and all 20 marbles.



Image 3.1: All game components, including the base, four dinosaurs, and marbles, laid out before assembly.

2. **Attach Dinosaurs:** Place each dinosaur character into its designated slot on the game base. Ensure they are securely clicked into place and can move freely when the lever is pressed.



Image 3.2: The back of the game box illustrating the three main setup steps: releasing marbles, racing to chomp, and gobbling the most marbles.

3. **Load Marbles:** Open the marble storage cover located underneath the game board. Place all 20 marbles (19 yellow, 1 red) into the central marble release area. Close the cover securely.



Image 3.3: View of the underside of the game board, highlighting the central compartment where marbles are stored and released.

4. **Prepare for Play:** Once all dinosaurs are attached and marbles are loaded, the game is ready to begin.

4. OPERATING (HOW TO PLAY)

The Hungry Hungry Hippos Dino Edition game offers two ways to play:

Standard Game: Gobble the Most Marbles

1. **Start the Game:** All players position their hands on their dinosaur's lever.
2. **Release Marbles:** On the count of three, or a designated signal, release the marbles from the central compartment by pressing the lever or button (if applicable) on the game base.
3. **Chomp Away:** Players rapidly press their dinosaur's lever to make its head extend and retract, attempting to gobble up as many marbles as possible.



Image 4.1: The game in progress, with four colorful dinosaurs actively trying to consume yellow marbles scattered across the board.



Image 4.2: A close-up view of the purple dinosaur character with its mouth open, capturing several yellow marbles.

4. **End of Round:** The round ends when all marbles have been gobbled up.
5. **Determine Winner:** Each player counts the marbles collected by their dinosaur. The player with the most marbles wins the round.

Bonus Game: The Pink Berry Marble

For a quicker game, play with the objective of capturing the special red marble:

1. **Game Start:** Follow steps 1 and 2 from the Standard Game.
2. **Target the Red Marble:** Players rapidly chomp, focusing on capturing the single red marble among the yellow ones.



Image 4.3: An orange dinosaur extends its neck towards the center of the board, aiming to capture the distinct red marble.

3. **Instant Win:** The first player whose dinosaur successfully gobbles up the red marble immediately wins the game.

5. MAINTENANCE

Proper care will ensure the longevity of your game:

- **Cleaning:** Wipe the game board and dinosaur figures with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the game in its original box or a clean, dry place away from direct sunlight and extreme temperatures. Ensure all marbles are collected and stored in the designated compartment or a secure bag to prevent loss.
- **Marble Care:** Keep marbles clean and free of debris to ensure smooth gameplay.

6. TROUBLESHOOTING

If you encounter any issues during gameplay, consider the following:

- **Dinosaur Head Sticking:** If a dinosaur's head or lever mechanism becomes stiff or stuck, gently wiggle the lever or the dinosaur's head to free it. Ensure no foreign objects are obstructing its movement.
- **Marbles Not Releasing:** Check the central marble compartment to ensure it is not jammed and the release mechanism is functioning correctly.
- **Missing Marbles:** The game includes 20 marbles. If marbles are lost, replacements may be available from the manufacturer or similar small plastic balls can be used, ensuring they are of appropriate size and non-toxic.
- **Dinosaur Detachment:** If a dinosaur detaches from the base, simply re-attach it by aligning the pegs and pressing firmly until it clicks into place.

7. SPECIFICATIONS

Product Dimensions	4.61 x 10.51 x 10.51 inches
Item Weight	1.27 pounds
Model Number	F1359
Manufacturer Recommended Age	4 years and up
Number of Players	2 to 4 players
Release Date	September 26, 2021
Manufacturer	Hasbro

8. WARRANTY AND SUPPORT

For information regarding product warranty, replacement parts, or customer support, please visit the official Hasbro Gaming website or contact their customer service department.

You can find more information and support resources at the [Hasbro Store on Amazon](#) or the main Hasbro website.

© 2025 Hasbro. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question